

# HP xw8600 Workstation

## Service and Technical Reference Guide



**Copyright Information**

© Copyright 2008 Hewlett-Packard Development Company, L.P.

**Warranty**

Hewlett-Packard Company shall not be liable for technical or editorial errors or omissions contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. The information in this document is provided "as is" without warranty of any kind, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, and is subject to change without notice. The warranties for HP products are set forth in the express limited warranty statements accompanying such products.

Nothing herein should be construed as constituting and additional warranty.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

**Trademark Credits**

Microsoft, Windows, and XP are U.S. registered trademarks of Microsoft Corporation in the U.S. and other countries.

Intel is a trademark of Intel Corporation in the U.S. and other countries and are used under license.

ENERGY STAR is a U.S. registered mark of the United States Environmental Protection Agency.

453094-005

Fifth Edition, August 2008

---

# Table of contents

## 1 Product overview

Product features .....	1
System board architecture .....	2
Workstation components .....	2
Front panel components .....	4
Rear panel components .....	5
Serial number and COA label location .....	6
Maximizing airflow .....	6
Workstation specifications .....	7
80 Plus power supplies .....	7
Power supply specifications .....	8
Power consumption and heat dissipation .....	9
System fans .....	9
Resetting the power supply .....	10
Environmental specifications .....	10
ENERGY STAR Qualification .....	10
Dual- and quad-core processors .....	11
HP Cool Tools .....	12

## 2 Configuring and restoring the operating system

Setting up Microsoft Windows Vista Business software .....	13
Configuring the Windows Vista Business operating system .....	13
Configuring the software .....	13
Selecting a language .....	13
Creating recovery disks .....	14
Installing or upgrading device drivers .....	14
Restoring the Windows Vista Business operating system .....	14
Using the HP Backup and Restore process .....	14
Creating system recovery DVDs or CDs .....	15
Restoring from HPBR DVDs or CDs .....	15
Restoring from the recovery partition .....	15
Reclaiming hard drive space from the recovery partition .....	15
Ordering backup software .....	15
Transferring files and settings using Windows Easy Transfer .....	16
Setting up Microsoft Windows XP Professional .....	16
Configuring Windows XP Professional .....	16
Selecting a language .....	17
Creating recovery disks .....	17

Installing or upgrading device drivers .....	17
Restoring the Windows XP Professional operating system .....	17
The RestorePlus! process .....	17
Creating a RestorePlus! DVD .....	18
Restoring from RestorePlus! DVDs .....	18
Restoring from RestorePlus! on the recovery partition .....	18
Reclaiming hard drive space from the recovery partition .....	18
Using the HP Backup and Restore process .....	19
Creating system recovery DVDs or CDs .....	19
Restoring from HPBR DVDs or CDs .....	19
Restoring directly from the recovery partition .....	19
Ordering backup software .....	19
Protecting your software .....	20
HP software on your workstation .....	20
Setting up Red Hat Linux .....	20
Linux preinstalled workstations .....	20
Starting the Linux operating system .....	20
Restoring the Linux operating system on preloaded workstations .....	21
Creating restore media .....	21
Downloading the latest HP driver CD contents .....	21
Reinstalling the factory Linux image with the HP driver CD .....	21
Upgrading device drivers .....	22
Linux-enabled workstations .....	22
Verifying hardware compatibility .....	22

### 3 System management

The Computer Setup (F10) Utility .....	23
BIOS ROM .....	24
Using the Computer Setup (F10) Utility .....	24
The Computer Setup (F10) Utility menu .....	25
Workstation management .....	31
Initial workstation configuration and deployment .....	32
Installing a remote system .....	32
Replicating the setup .....	33
Copying a setup configuration to a single workstation .....	33
Copying a setup configuration to multiple workstations .....	33
Updating and managing software .....	34
HP Client Manager Software .....	34
Altiris Client Management Solutions .....	35
System Software Manager .....	35
Proactive Change Notification .....	35
Subscriber's Choice .....	35
ROM Flash .....	36

Remote ROM Flash .....	36
HPQFlash .....	36
F10 setup instruction in the BIOS SoftPak .....	36
FailSafe Boot Block ROM .....	36
Asset tracking and security .....	37
Password security .....	38
Establishing a setup password using the Computer Setup (F10) Utility .....	38
Establishing a power-on password using workstation setup .....	38
Entering a power-on password .....	39
Entering a setup password .....	39
Changing a power-on or setup password .....	40
Deleting a power-on or setup password .....	40
National keyboard delimiter characters .....	40
Clearing passwords .....	41
DriveLock .....	41
DriveLock applications .....	41
Using DriveLock .....	42
Hood Sensor (Smart Cover Sensor) (optional) .....	43
Setting the Hood Sensor protection level .....	44
Cable lock (optional) .....	44
Security lock (Padlock loop) (optional) .....	44
Universal chassis clamp lock (optional) .....	44
Fault notification and recovery .....	44
Drive Protection System .....	44
ECC fault prediction .....	44
Thermal sensors .....	45
Dual-state power button .....	45

#### 4 Removal and replacement procedures

Warnings and cautions .....	47
Service considerations .....	48
Cautions, warnings, and safety precautions .....	48
ESD information .....	48
Generating static .....	48
Preventing ESD equipment damage .....	49
Personal grounding methods and equipment .....	49
Grounding the work area .....	50
Recommended ESD prevention materials and equipment .....	50
Tools and software requirements .....	51
Special handling of components .....	51
Cables and connectors .....	51
Hard drives .....	51
Lithium coin cell battery .....	51

Customer Self-Repair .....	52
Predisassembly procedures .....	52
System board components .....	52
Removing and replacing components .....	53
Disassembly order .....	53
Security lock (Padlock loop) (optional) .....	55
Removing the security lock .....	55
Cable lock (optional) .....	55
Removing the cable lock .....	56
Universal chassis clamp lock (optional) .....	56
Removing the chassis clamp lock .....	56
Side access panel .....	57
Removing the side access panel .....	57
Replacing the side access panel .....	58
Hood Sensor (Smart Cover Sensor) (optional) .....	58
Removing the Hood Sensor .....	58
Front bezel .....	59
Removing the front bezel .....	60
Replacing the front bezel .....	60
Bezel blanks .....	60
Removing bezel blanks .....	60
Front panel I/O device assembly .....	61
Removing the front panel I/O device assembly .....	61
Installing the front panel I/O device assembly .....	63
Power button assembly .....	63
Removing the power button assembly .....	63
Optical drive .....	64
Removing an optical drive .....	65
Installing an optical drive .....	66
System speaker .....	68
Removing the system speaker .....	68
Power supply .....	69
Removing the power supply .....	69
Installing the power supply .....	70
Power connections to system components .....	71
System and memory fan assembly .....	71
Removing the system and memory fan assembly .....	72
Memory .....	72
Memory general information .....	72
System board memory module requirements .....	72
DDR2-667 Fully Buffered DIMM support .....	73
DDR2-800 Fully Buffered DIMM support .....	73
Supported system board DIMM configurations .....	73
Supported memory riser DIMM configurations .....	73

BIOS errors and warnings .....	74
System board memory .....	74
Removing a memory module .....	74
Installing a memory module .....	75
Memory riser assembly .....	77
Removing a memory riser assembly .....	78
Installing a memory riser assembly .....	79
PCI card slots .....	85
Slot lane redirection .....	86
Card configuration restrictions for power supplies .....	86
SAS rear panel cable (optional) .....	86
Installing the SAS rear panel cable .....	86
Installing the optional SAS mounting bracket .....	88
PCI card support .....	90
Removing a PCI card support .....	90
Installing a PCI card support .....	91
PCI Express cards .....	92
Removing a PCI Express card .....	92
Installing a PCI Express card .....	94
PCI card .....	95
Removing a PCI card .....	95
Installing a PCI card .....	95
Battery .....	96
Removing the battery .....	96
Installing the battery .....	97
SAS hard drive .....	97
Removing a SAS hard drive .....	97
Installing a SAS hard drive .....	98
SATA hard drive .....	101
Removing a SATA hard drive .....	101
Installing a SATA hard drive .....	102
Installing a fifth hard drive (optional) .....	104
Processor heatsink .....	106
Removing the processor heatsink .....	106
Installing the processor heatsink .....	107
System processor .....	108
Removing a system processor .....	108
Installing a system processor .....	109
System board .....	110
Removing the system board .....	111
Installing the system board .....	112
Product recycling .....	112

## 5 System diagnostics and troubleshooting

Customer Self Help .....	113
Help and Support Center .....	113
HP SoftPaq Download Manager .....	113
Diagnostic LED codes .....	114
Troubleshooting scenarios and solutions .....	116
Solving minor problems .....	116
Solving power supply problems .....	118
Testing power supply .....	118
Solving diskette problems .....	120
Solving hard drive problems .....	122
Solving display problems .....	123
Solving audio problems .....	125
Solving printer problems .....	126
Solving keyboard and mouse problems .....	126
Solving front panel component problems .....	127
Solving hardware installation problems .....	128
Solving network problems .....	129
Solving memory problems .....	130
Solving processor problems .....	131
Solving DVD problems .....	131
Solving Internet access problems .....	133
Troubleshooting checklist .....	134
LED color definitions .....	134
HP Insight Diagnostics Offline Edition .....	134
Key features and benefits .....	135
Theory of operation .....	135
Diagnostic utility on CD .....	135
Downloading the latest diagnostic utility .....	136
User Interface .....	136
Navigation .....	136
Survey tab .....	136
Test tab .....	137
Status tab .....	137
Log tab .....	138
Help tab .....	138
POST error messages .....	138

## 6 Configuring RAID devices

Configuring SAS RAID devices .....	145
Supported configurations .....	145
SAS RAID 0 configuration .....	146
SAS RAID 1 configuration .....	146



SAS RAID 1E configuration .....	147
Configuring SATA RAID devices .....	147
Attaching SATA HDDs .....	148
Configuring system BIOS .....	148
Creating RAID volumes .....	149
Deleting RAID volumes .....	149

## **7 Configuring password security and resetting CMOS**

Preparing to configure passwords .....	151
Resetting the password jumper .....	152
Clearing and Resetting the CMOS .....	152
Using the CMOS Button .....	152
Using the Computer Setup (F10) Utility to Reset CMOS .....	153

## **Appendix A Appendix A—Connector pins**

Connector pin descriptions .....	155
----------------------------------	-----

## **Appendix B Appendix B—System board designators**

## **Appendix C Appendix C—Routine care**

General cleaning safety precautions .....	169
Cleaning the workstation case .....	169
Cleaning the keyboard .....	169
Cleaning the monitor .....	170
Cleaning the mouse .....	170



---

# 1 Product overview

This chapter presents an overview of the hardware components of the HP xw8600 Workstation, including the following topics:

- [Product features on page 1](#)
- [Workstation specifications on page 7](#)
- [ENERGY STAR Qualification on page 10](#)
- [Dual- and quad-core processors on page 11](#)
- [HP Cool Tools on page 12](#)


## Product features

The following sections describe the HP xw8600 Workstation system board architecture and components.



For information about supported spare parts, see <http://partsurfer.hp.com>.

**Figure 1-2** Typical workstation components view



**Table 1-1** Component view

Item	Description	Item	Description
1	PCI card support	10	Memory modules
2	Power supply	11	Card guide/front fan (fan optional)
3	Processor heatsinks	12	Graphics card
4	Processors	13	Optical drive*
5	System and memory fans	14	PCI Express card
6	Side access panel	15	Diskette drive
7	System board	16	PCI card
8	Chassis	17	Hard drive
9	Front bezel		

\* A DVD is an example of an optical drive.

# Front panel components

The following figure shows the front panel components of a typical HP xw8600 Workstation. Drive configurations can vary.

Figure 1-3 Front panel components











Table 1-2 Front panel components


Item	Symbol	Description	Item	Symbol	Description
1		Optical drive	8		Headphone
2		Secondary drive bays (3 total)	9		USB 2.0 (2)
3		Diskette drive (optional)	10		Hard drive activity light
4		Diskette drive activity light	11		Power button
5		Diskette drive eject button	12		Power on light
6		IEEE-1394a connector	13		Optical drive activity light
7		Microphone	14		Optical drive eject button

## Rear panel components











The following figure shows the rear panel components of a typical HP xw8600 Workstation.

**Figure 1-4** Rear panel components



 **NOTE:** The rear panel connectors are labeled with industry-standard icons and colors to assist you in connecting your peripheral devices.

**Table 1-3** Rear panel components

Item	Symbol	Description	Item	Symbol	Description
1		Power cord connector	11		Graphics connector
2		Power supply Built-In Self Test (BIST) LED	12		Audio line-in connector (blue)*
3		PS/2 keyboard connector	13	ASF	RJ-45 network connector
4		USB 2.0	14		RJ-45 network connector
5		Serial connector (blue-green)	15		PS/2 mouse connector (green)
6		IEEE-1394	16		Cable lock slot
7		USB 2.0 (4)	17		Padlock loop
8		Microphone connector (pink)	18		Universal chassis clamp lock opening
9		Audio line-out connector (green)*	19		Access panel key loop

**Table 1-3 Rear panel components (continued)**


Item	Symbol	Description	Item	Symbol	Description
10		MiniSAS 4-port connector (optional)			

\* HP does not support external audio cables that are longer than three meters.

## Serial number and COA label location

As shown in the following figure, each workstation has two serial number labels (1 and 2) and a Certificate of Authentication (COA) label (2) for Microsoft® Windows® preinstalled systems only. The serial number labels can usually be found on the top panel or on the side or rear of the workstation. Keep this number available when contacting customer service for assistance.

**Figure 1-5** Location of serial number and COA label




## Maximizing airflow

- Keep your workstation in an area where airflow is not obstructed.
- Keep the workstation off from surfaces where dust can gather.



- Remove dust on the front panel (vent area) and the rear fans with a small vacuum, compressed air, or dust rag.
- Keep the front and back of the workstation at least 0.15 m (6 in.) away from a wall or other obstruction as shown in the following figure.

**Figure 1-6** Maintain proper clearance



## Workstation specifications

The following table lists the physical characteristics of the HP xw8600 Workstation.

<b>Weight</b> (Typical configuration)	14.4-19.4 kg (31.7-42.7 lb.)
<b>Chassis Dimensions</b>	<b>Height:</b> 441 mm (17.4 in.) <b>Width:</b> 165 mm (6.5 in.) <b>Depth:</b> 440 mm (17.3 in.)

## 80 Plus power supplies

Two 80 Plus® power supplies—800W and 1050W—are available in the HP xw8600 Workstation. Both are compatible with ENERGY STAR requirements. This section describes the power supplies and lists their specifications.

**Table 1-4** Power supply source voltages

Source voltage	Description
+3.3V	PCI, PCIe, audio, clocks, chipset, super I/O, BIOS ROM, IEEE1394, SAS controller, and onboard logic
+5V	Storage (hard drive, optical drive, diskette drive), PCI, PCIe, chipset, audio, keyboard/mouse, USB, and IEEE1395
+12 V-CPU0	Input to onboard regulator that supplies power to CPU0 and CPU0 fan
+12 V-CPU1	Input to onboard regulator that supplies power to CPU1 and CPU1 fan
+V12 V-M	Input to onboard regulator that supplies power to memory and system fans
+12 V-B	PCI, PCIe, and system fans
+12 V-D	Storage (hard drive, optical drive, diskette drive), and input to onboard regulator that supplies power to riser memory (1050W only)

**Table 1-4 Power supply source voltages (continued)**

Source voltage	Description
+12 V-G/G1	PCI Express auxilliary connector on 800W and 1050w power supplies
+12 V-G2	Second PCI Express auxilliary connector on 1050W power supply
+12 V-R	Input to onboard regulator that supplies power to Riser Memory (1050W power supply only)
+12 V-N	PCI and serial ports
+5 V-SB	Sleep circuitry

**Table 1-5 Maximum current per rail**

Voltage rail	800W maximum continuous current	1050W maximum continuous current
+3.3V	22.0A	22.0A
+5V	18.0A	18.0A
+12 V-CPU0	18.0A	18.0A
+12 V-CPU1	18.0A	18.0A
+V12 V-M	18.6A	18.0A
+12 V-B	18.0A	18.0A
+12 V-D	18.0A	18.0A
+12 V-G/G1	18.0A	18.0A
+12 V-G2	N/A	18.0A
+12 V-R	N/A	18.0A
+12 V-N	0.30A	0.30A
+5 V-SB	3.0A	9.0A

△ **CAUTION:** For 800W and 1050W power supplies, do not exceed 150 watts of 3.3V and 5V power combination.

For the 800W power supply, do not exceed 64.0 amps (768 watts) of 12-volt (CPU0/CPU1/M/B/D/G) power combination.

For the 1050W power supply, do not exceed 84.0 amps (1008W) of 12V (CPU0/CPU1/M/B/D/G1/G2/R) power combination.

Do not exceed 800 watts (for the 800W power supply) or 1050 watts (for 1050W power supply) of total continuous output power.

## Power supply specifications

**Table 1-6 Power supply specifications**

Item	Description	
Power supply	<b>800W</b> Wide Ranging, Active PFC	<b>1050W</b> Wide Ranging, Active PFC

**Table 1-6 Power supply specifications (continued)**

Item	Description			
Operating voltage range	90 – 269 VAC		90 – 269 VAC	
Rated voltage range	100–240 VAC	118 VAC	100–240 VAC	118 VAC
Rated line frequency	50–60 Hz	400 Hz	50–60 Hz	400 Hz
Operating line frequency range	47–66 Hz	393–407 Hz	47–66 Hz	393–407 Hz
Rated input current	10A @ 100-127 VAC 6A @ 200–240 VAC	9.5A @ 118 VAC	13.2A @ 100-127 VAC 6.6A @ 200–240 VAC	12.0A @ 118 VAC
Heat dissipation (Configuration and software dependent)	Typical 1530 BTU/hr = (386 kg-cal/hr) Maximum 2027 BTU/hr = (511 kg-cal/hr)		Typical 3136 BTU/hr = 791kg-cal/hr) Maximum 4480 BTU/hr = 1129 kg-cal/hr)	
Power supply fan	92x32 mm variable speed		92x32 mm variable speed	
80 Plus compliant	80 Plus compliant and compatible with ENERGY STAR qualified configurations.			
FEMP Standby Power compliant @115V (<2W in S5 – Power Off)	Yes		No	
Power Consumption in sleep mode (as defined by ENERGY STAR) - Suspend to RAM (S3) (Instantly Available PC)	<20 watts		<25 watts	

## Power consumption and heat dissipation

Power consumption and heat dissipation specifications are available for multiple 800W and 1050W power supply configurations. To review available specifications, see <http://www.hp.com/go/quickspecs>.

To reach zero power consumption, unplug the workstation from the power outlet or use a power strip with an on/off switch. For additional information about power-saving features, see your operating system documentation.

This product is in compliance with U.S. Executive Order 13221.

## System fans

This workstation includes:

- one rear system fan
- one processor heatsink fan
- one power supply fan
- one memory fan
- one memory controller heatsink fan

In addition, an optional front system fan is available for special environments, and some graphics cards include onboard fans.

There is one fan per processor heatsink for a standard CPU heatsink, and two fans per processor for a high performance CPU heatsink.

## Resetting the power supply

If an overload triggers the power supply overload protection, power is immediately disconnected. To reset the power supply:

1. Disconnect the power cord from the workstation.
2. Determine what caused the overload and fix the problem. For troubleshooting information, see [System diagnostics and troubleshooting on page 113](#).
3. Reconnect the power cord and reboot the workstation.

When you power off the workstation through the operating system, power consumption falls below what is considered low power consumption but does not reach zero. This low power consumption feature extends the life of the power supply.

## Environmental specifications

The following table lists the environmental specifications of your workstation.

<b>Temperature</b>	<b>Operating:</b> 5 to 35°C (40 to 95°F) <b>Non-operating:</b> -40 to 60°C (-40 to 140°F) <b>NOTE:</b> Derate by one degree C (1.4 degrees F) for every 305m (1,000 ft.) altitude over 1,524m (5,000 ft.).
<b>Humidity</b>	<b>Operating:</b> 8 to 85% RH, non-condensing <b>Non-operating:</b> 8 to 90% RH, non-condensing
<b>Altitude</b>	<b>Operating:</b> 0 to 3,048m (10,000 ft.) <b>Non-operating:</b> 0 to 9,144m (30,000 ft.)
<b>Shock</b>	<b>Operating:</b> ½-sine: 40g, 2-3ms <b>Non-operating:</b> <ul style="list-style-type: none"><li>• ½-sine: 160 cm/s, 2-3ms (~100g)</li><li>• square: 422 cm/s, 20g</li></ul> <b>NOTE:</b> Values represent individual shock events and do not indicate repetitive shock events.
<b>Vibration</b>	<b>Operating random:</b> 0.5g (rms), 5-300 Hz <b>Non-operating random:</b> 2.0g (rms), 10-500 Hz <b>NOTE:</b> Values do not indicate continuous vibration.

## ENERGY STAR Qualification

HP computers marked with the ENERGY STAR logo are compliant with the applicable U.S. Environmental Protection Agency (EPA) ENERGY STAR specifications for computers. The EPA ENERGY STAR logo does not imply endorsement by the EPA. As an ENERGY STAR Partner, Hewlett-Packard Company has determined the products marked with the ENERGY STAR logo are ENERGY STAR qualified per the applicable ENERGY STAR guidelines for energy efficiency. The following logo appears on all ENERGY STAR qualified computers.



The ENERGY STAR Computers Program was created by the EPA to promote energy efficiency and reduce air pollution through more energy-efficient equipment in homes, offices, and factories. One way products achieve this energy efficiency is by reducing power consumption when not being used through the Microsoft Windows Power Management feature.

The Power Management feature enables the workstation to enter a low-power (or “sleep”) mode after a period of inactivity. When used with an external monitor that is ENERGY STAR qualified, this feature also supports the similar power management features of the external monitor.

To take advantage of this energy savings:

- The Power Management feature has been preset to suspend the workstation to a sleep state after 30 minutes of inactivity.
- The Power Management feature has been preset to suspend the monitor to a sleep state after 15 minutes of inactivity.

Both the computer and monitor can be woken from sleep mode through user interaction with any of the computer input devices (mouse, keyboard, and so on). When configured with Wake On LAN (WOL) enabled, the workstation can also be woken by a network signal.

See the EPA ENERGY STAR Power Management Web site for more information about the energy and financial savings potential of the Power Management Feature: <http://www.energystar.gov/powermanagement>.

See the EPA ENERGY STAR Web site for more information about the ENERGY STAR program and its environmental benefits: <http://www.energystar.gov>.

---

△ **CAUTION:** Using the Energy Save Monitor feature with monitors that are not ENERGY STAR qualified can cause video distortion when an Energy Save timeout occurs.

---

📝 **NOTE:** ENERGY STAR is not supported on Linux workstations.

---

If it is necessary to restore the operating system, you must also reset the ENERGY STAR settings (if applicable) after the restore.

---

To verify the factory default power settings for your workstation, select **Start>Control Panel**, and then double-click **Power Options**.

## Dual- and quad-core processors


This HP Workstation supports dual- and quad-core processors that provide two or four true processors in a single socket. Dual- and quad-core processors are better at handling the load of multithreaded applications (such as rendering images in Digital Content Creation) and highly multitasked environments (such as running several productivity applications while listening to music).

# HP Cool Tools

An HP Workstation with Windows XP includes additional software that is not installed when you first boot your system. Additionally, a number of preinstalled tools on your workstation can enhance your workstation experience. To access or learn more about these applications:

1. Open the HP Cool Tools folder by selecting **Start>All Programs>HP Cool Tools**.
2. Select the **HP Cool Tools** icon on the desktop.
3. To learn more about these applications, select **HP Cool Tools—Learn More**.
4. To install or launch the applications, select the appropriate application.

---

 **NOTE:** In preinstalled Vista, there is no icon, shortcut, or folder, but several of the tool programs are included, such as Performance Tuning Framework.

---

---

## 2 Configuring and restoring the operating system

This chapter describes how to install and restore the operating system and includes the following topics.

- [Setting up Microsoft Windows Vista Business software on page 13](#)
- [Setting up Microsoft Windows XP Professional on page 16](#)
- [Protecting your software on page 20](#)
- [HP software on your workstation on page 20](#)
- [Setting up Red Hat Linux on page 20](#)

If your workstation includes a preinstalled operating system, it is configured the first time you power on the workstation.

△ **CAUTION:** Do not add optional hardware or third-party devices to the HP workstation until the operating system is installed. Adding hardware might cause errors and prevent the operating system from installing correctly.

---

### Setting up Microsoft Windows Vista Business software

This section describes how to install and restore Microsoft Windows Vista® Business on your workstation.

#### Configuring the Windows Vista Business operating system

This section describes how to configure the Windows Vista Business operating system on your HP workstation.

##### Configuring the software

When you power on the workstation, the operating system is configured. Configuration takes approximately 5 to 10 minutes. Carefully follow the instructions on the screen to complete the configuration.

△ **CAUTION:** After configuration begins, do not power off your workstation until the process is complete. Powering off your workstation can damage the software that runs the system.

---

If it is necessary to reinstall the operating system, see the operating system documentation included with your workstation. Additional information is available from the online help tool after you configure the operating system.

##### Selecting a language

When the preinstalled operating system is first booted, you might be prompted to select a language for the operating system. After selecting the language, read and follow the instructions on the screen to complete the installation. This process might take a while, depending on the system hardware configuration and language choice. During the process, do not power off your workstation unless you are prompted to do so.

After you select a language during the initial boot of the operating system, the language is locked on the hard drive. If you restore the system using HP Backup and Recovery, only the previously selected language can be installed. If you use RestorePlus!, the DVD searches for the language stored on the hard drive and restores only the original preinstalled language. If a new hard drive is installed or no language is found on the disk, RestorePlus! installs any language requested.

## Creating recovery disks

For details about creating recovery disks using the HP Backup and Recovery process, see [Restoring the Windows Vista Business operating system on page 14](#).

## Installing or upgrading device drivers

To install hardware devices after the operating system is installed, you must install the appropriate device drivers before you install the devices. In addition, for optimum performance, your operating system must have the most recent updates, patches, and software fixes. For additional driver and software update information, consider the following resources:

- The Microsoft Web site provides updates for your operating system, including current patches and software fixes.
- Device drivers are provided on CDs supplied with peripheral devices.
- Some peripheral device drivers developed for Windows XP or Vista might not be included with your workstation. Current device drivers are available at [http://www.hp.com/support/workstation\\_swdrivers](http://www.hp.com/support/workstation_swdrivers).
- Driver installation and workstation operation documentation is available at [http://www.hp.com/support/workstation\\_manuals/](http://www.hp.com/support/workstation_manuals/).

## Restoring the Windows Vista Business operating system

There are several methods to restore the Windows Vista Business operating system on your workstation to a near-factory state, or to the state of the system at a predefined restore point. Your workstation has a recovery partition on the system hard drive that contains the software and data required for the restore process described in the following sections.

If you must restore the operating system with Windows Vista Business Original Equipment Manufacturer (OEM) DVDs (that is, if you install without using Restore Plus!), you must activate Vista after it is installed.

For activation, you need a 25-character PID (Product ID)—the one on the Microsoft COA sticker does not work. To obtain a valid PID, you must call Microsoft and provide your Stock Keeping Unit (SKU) number.

The SKU information is listed on the service tag. It appears as the OS product number in the lower right hand portion of the tag in this format: "OS: XXXXXXXX," where "XXXXXXX" is the OS product number.

## Using the HP Backup and Restore process

You can reinstall the Windows operating system and device drivers (for devices included with the system) using the HP Backup and Restore (HPBR) process, from either a DVD or from the recovery partition on your system hard drive.

To launch the HPBR, select **Start>All Programs>HP Backup & Recovery>HP Backup and Recovery Manager**.



## Creating system recovery DVDs or CDs

You can create a set of system recovery DVDs or CDs if you have a writable optical drive. After launching the HP Backup and Restore Manager, you can create International Standards Organization (ISO) images of the factory image, or you can write them directly to CD or DVD. You can also create a supplemental HP Backup and Recovery Manager CD. (You might need to create additional CDs depending on the options you purchased.) You can also move CD images to another location, such as a network share, or to be copied to a DVD or CD at a later time or from another system.

## Restoring from HPBR DVDs or CDs

To start the system recovery process, boot from the DVD or CD you created, then carefully follow the online instructions.

## Restoring from the recovery partition

To start the HPBR system restore process from the Recovery Manager, follow these steps:

1. Boot the workstation.
2. When prompted on the boot splash screen to enter the Recovery Manager, press **F11**.
3. Follow the prompts to restore the system to factory-like condition.

## Reclaiming hard drive space from the recovery partition

To free up hard drive space, you can remove only the recovery partition, or you can completely uninstall the HP Backup and Recovery Manager application.

---

△ **CAUTION:** If you remove the recovery partition:

- The **F11** Emergency Recovery function becomes unavailable.
  - The ability to recover the system is lost.
  - Recovery images in the recovery partition are deleted.
  - The ability to create a recovery media set is lost.
- 

△ **CAUTION:** If you uninstall the HP Backup and Recovery Manager application, emergency recovery and data backup and recovery can no longer be performed.

---

- **Removing only the recovery partition**—You can remove the recovery partition by selecting **Remove HP Recovery Partition** from the HP Backup and Recovery program folder. When the HP Recovery Partition is removed, the recovery partition is deleted, the user partition is extended to reclaim the unused hard drive space, and the F11 boot prompt is removed. The HP Backup and Recovery Manager application remains and can be used for data backup and restore.
- **Uninstalling the HP Backup and Recovery Manager application**—You can uninstall the HP Backup and Recovery Manager application using the Programs and Features utility under Windows Control Panel>Programs and Features. When the application is uninstalled, the recovery partition is deleted, the user partition is extended to reclaim the unused space, and the F11 boot prompt is removed. After the application is uninstalled, emergency recovery and data backup and recovery can no longer be performed.

---

△ **CAUTION:** Deleting the recovery partition or uninstalling the HP Backup and Recovery Manager application reduces or eliminates the ability to recover the system.

---

## Ordering backup software

If you cannot create system recovery CDs or DVDs, you can order a recovery disk set from the HP support center. To obtain the support center telephone number for your region:

1. Before calling HP to order the software, have your workstation serial number available.
2. Go to [http://welcome.hp.com/country/us/en/wwcontact\\_us.html](http://welcome.hp.com/country/us/en/wwcontact_us.html).
3. Select your region.
4. Under the Call HP heading, select **Technical support after you buy**.

## Transferring files and settings using Windows Easy Transfer

Windows Easy Transfer, a Microsoft data migration tool, provides a guide that helps you choose the files and data to transfer from another Windows computer to your Windows Vista Business workstation and explains how to transfer it. You can use one of the following methods to migrate data:

- **Network**—Use when the source computer and your workstation are connected to the same network.
- **Easy Transfer cable**—Use this specially designed USB cable to connect the source computer to your workstation. Although an Easy Transfer cable is not a standard USB cable, it is commonly available from local electronics suppliers.
- **DVDs or CDs**—Use if you have writeable DVD or CD drives on the source computer and your workstation.
- **USB flash drive or an external hard drive**—Use to access the source computer and your workstation.

To use the Windows Easy Transfer tool, select **Start>All Programs>Accessories>System Tools>Windows Easy Transfer**.

For more information about using Windows Easy Transfer, see <http://www.microsoft.com/windows/products/windowsvista/features/details/easytransfer.mspx>.

## Setting up Microsoft Windows XP Professional

This section describes how to configure and restore Microsoft® Windows XP™ Professional on your workstation.

### Configuring Windows XP Professional

This section describes how to configure Windows XP on your workstation.

When you first power on the workstation, the operating system is configured. Configuration takes approximately 5 to 10 minutes. Carefully follow the instructions on the screen to complete the configuration.

---

△ **CAUTION:** After configuration begins, do not power off your workstation until the process is complete. Powering off your workstation can damage the software that runs the system.

---

If it is necessary to reinstall the operating system, see the operating system documentation included with your workstation. Additional information is available from the online help tool after you configure the operating system.

## Selecting a language

When the preinstalled operating system is first booted, you might be prompted to select a language for the operating system. After selecting the language, read and follow the instructions on the screen to complete the installation. This process might take quite a while, depending on the system hardware configuration and the language choice. During the process, do not power off your workstation unless you are prompted to do so.

After you select a language during the initial boot of the operating system, the language is locked on the hard drive. If you restore the system using HP Backup and Recovery, only the previously selected language can be installed. If you use RestorePlus!, the DVD searches for the language stored on the hard drive and restores only the original preinstalled language. If a new hard drive is installed, or no language is found on the disk, RestorePlus! installs any language requested.

## Creating recovery disks

For details about creating recovery disks using the HP Backup and Recovery process, see [Restoring the Windows XP Professional operating system on page 17](#).

## Installing or upgrading device drivers

To install hardware devices after the operating system is installed, you must install the appropriate device drivers before you install the devices. In addition, for optimum performance, your operating system must have the most recent updates, patches, and software fixes. For additional driver and software update information, consider the following resources:

- The Microsoft Web site provides updates for your operating system, including current patches and software fixes.
- Device drivers are provided on CD supplied with peripheral devices.
- Some peripheral device drivers developed for Windows XP or Vista might not be included with your workstation. Current device drivers are available at: <http://www.hp.com/support/>.
- For documentation on installing drivers and workstation operation, see [http://www.hp.com/support/workstation\\_manuals/](http://www.hp.com/support/workstation_manuals/).

## Restoring the Windows XP Professional operating system

There are several methods to restore the Windows XP operating system on your workstation to a near-factory state, or to the state of the system at a predefined snapshot in time. Your workstation has a recovery partition on the system hard drive that contains the software and data required for the restore process as described in the following sections.

### The RestorePlus! process

You can reinstall the Windows operating system and device drivers (for devices included with the system) using the RestorePlus! process. Some application software might not be restored using this process. If software is not restored, install it from the appropriate application DVD. You can use the RestorePlus! process from a DVD or the recovery partition on your system hard drive.

---

△ **CAUTION:** Before you restore the operating system, back up your data.

When you run RestorePlus! from media, the process deletes all information on the primary hard drive, including all partitions. If you run RestorePlus! from the recovery partition, only the root (C:) partition is affected.

---

## Creating a RestorePlus! DVD

You can create a set of the system recovery DVDs if you have a writable optical drive. When you first boot the workstation, you are prompted to create DVDs for RestorePlus!, the Windows operating system, and a supplemental HP Backup and Recovery Manager. (There might be additional DVDs you can create depending on the options.) You can also move DVD images to another location, such as a network share, to be copied to DVD at a later time, or from another system.

## Restoring from RestorePlus! DVDs

Boot from the RestorePlus! DVD to start the RestorePlus! process.

### Restoring from RestorePlus! on the recovery partition

To start the RestorePlus! process from the Emergency Recovery menu, follow these steps :

1. Boot the workstation.
2. When prompted to select the Emergency Recovery menu, press **F11** . The F11 prompt appears briefly during the boot process.

If you have a recovery partition but the F11 prompt is not visible:

- a. To access the setup menu, press **F10**. (For details, see [Using the Computer Setup \(F10\) Utility on page 24.](#))
  - b. From the dropdown menu, select **Advanced**.
  - c. Select **Power-On Options**.
  - d. Verify that the F11 prompt is set to **Displayed**.
  - e. Verify that Factory Recovery Boot Support is set to **Enabled**.
  - f. Reboot the workstation and press **F11** when prompted.
3. From the Emergency Recovery menu select **Recover PC's factory installed operating system, drivers, utilities, and applications**.

Some applications might not be restored using this method.

### Reclaiming hard drive space from the recovery partition

To reclaim hard drive space, you can remove the recovery partition.

---

△ **CAUTION:** If you remove the recovery partition:

- The **F11** Emergency Recovery function becomes unavailable.
  - The ability to recover the system from data on the recovery partition is lost.
  - Recovery images in the recovery partition are deleted.
  - The ability to create a recovery media set is lost.
- 

To free up hard drive space, you can uninstall the HP Backup and Recovery Manager application.

△ **CAUTION:** If you uninstall the HP Backup and Recovery Manager application, Emergency Recovery and data backup and recovery can no additional software is longer be performed.

- Removing only the recovery partition—You can remove the recovery partition by selecting **Remove HP Recovery Partition** from the HP Backup and Recovery program folder. When the HP Recovery Partition is removed, the recovery partition is deleted, the user partition is extended to reclaim the unused hard drive space, and the F11 boot prompt is removed. The HP Backup and Recovery Manager application remains, and can be used for data backup and restore.
- Uninstalling the HP Backup and Recovery Manager application—Use **Control Panel >Add or Remove Programs** for XP to uninstall the HP Backup and Recovery Manager application. When the application is uninstalled, the recovery partition is deleted, the user partition is extended to reclaim the unused space, and the F11 boot prompt is removed. After the application is uninstalled, emergency recovery and data backup and recovery can no longer be performed.

△ **CAUTION:** Deleting the recovery partition or uninstalling the HP Backup and Recovery Manager application reduces or eliminates the ability to recover the system.

## Using the HP Backup and Restore process

You can reinstall the Windows operating system and device drivers (for devices included with the system) using the HP Backup and Restore (HPBR) process, from a DVD, CD, or the recovery partition on your system hard drive.

To launch the HPBR, select **Start>All Programs>HP Backup & Recovery>HP Backup and Recovery Manager**.

△ **CAUTION:** Before you restore the operating system, back up your data. Data on the Windows partition is deleted when you perform a system restore using the HPBR process. However, the recovery partition on the system drive and other partitions are not affected.

## Creating system recovery DVDs or CDs

You can create a set of system recovery DVDs or CDs if you have a writable optical drive. After launching the HP Backup and Restore Manager, you can create International Standards Organization (ISO) images of the factory image, or you can write them to CD or DVD. You can also create a supplemental HP Backup and Recovery Manager CD. (You might need to create additional CDs depending on the options you purchased.) You can also move CD images to another location, such as a network share, or to be copied to a DVD or CD at a later time or from another system.

## Restoring from HPBR DVDs or CDs

To start the system recovery process, boot from the DVD or CD you created, then follow the online instructions.

## Restoring directly from the recovery partition

To start the HPBR system restore process from the Recovery Manager, follow these steps:

1. Boot the workstation.
2. When prompted on the boot splash screen to enter the Recovery Manager, press **F11**.
3. Follow the prompts to restore the system to factory-like condition.

## Ordering backup software

If you cannot create system recovery CDs or DVDs, you can order a recovery disk set from the HP support center. To obtain the support center telephone number for your region:

1. Have your workstation serial number available before calling HP to order the software.
2. Go to <http://www.hp.com/support/contactHP>.
3. Select your region.
4. Under the Call HP heading, select **Technical support after you buy**.

## Protecting your software

To protect your software from loss or damage, keep a backup copy of system software and related files. For instructions on making backup copies of data files, see the operating system or backup utility documentation.

## HP software on your workstation

The following HP software might be installed on your workstation, depending on the operating system and options purchased:

- Computer Setup (F10) Utility and diagnostics
- HP support software, including device drivers
- Security management tools (optional)
- Software support management tools

Additional software is available for download:

- HP Client Manager Software is available at [.](#)
- System Software Manager is available at [.](#)

In some situations, additional HP software might be required

## Setting up Red Hat Linux

This section describes how to install and restore the Red Hat Linux operating system on your workstation.

### Linux preinstalled workstations

With Linux preinstalled, follow the instructions in this section to set up your operating system and software.

After the boot process is complete, you can view additional HP Linux documentation by opening your browser. The browser is set to use the local HP documentation page as its default. You can also access Linux links for Red Hat by using your browser.

For additional information about setting up Linux-preinstalled or Linux-enabled workstations, see the *HP User Manual for Linux* at [http://www.hp.com/support/linux\\_user\\_manual](http://www.hp.com/support/linux_user_manual).

For more information about HP and Linux, see <http://www.hp.com/linux>.

### Starting the Linux operating system


The first time you boot your workstation, the Red Hat First Boot utility appears. This program enables you to enter your password, network, graphics, time, and keyboard settings for your workstation.

- △ **CAUTION:** After the automatic installation begins, do not power down your workstation until the process is complete. Powering down your workstation during the installation might damage the software that runs your workstation or prevent its proper installation.

When you enable the YPBind feature in the Network tab of the Linux Setup Tool, you might get a blank screen for 15–30 seconds after you select and save your settings and exit the utility. This behavior is expected. The boot process continues its execution after the screen returns.

## Restoring the Linux operating system on preloaded workstations


The HP Driver CD and Red Hat Enterprise Linux (RHEL) restore media are required to restore the Linux operating system. Download the most recent HP Driver CD to obtain enhancements.

-  **NOTE:** Linux does not support mixed drive types in a manufacturing preload. When you restore the operating system, mixed drive types can be handled with the restoration media.

### Creating restore media

HP Red Hat Enterprise Linux includes a Red Hat ISO icon on the desktop. You can click this icon to go to the /iso directory. The /iso directory contains all iso images used to preload your workstation.

To recover or restore the original image, follow the instructions in the readme file in the /iso directory to copy the ISO image file onto CDs.

-  **NOTE:** Make copies of the ISO recovery images on CD as backup files in case your workstation experiences a hard drive failure.

The /iso directory also contains an ISO image of the HP Driver CD used to create your preloaded system. You can use this version or download the latest version from the HP Website.

### Downloading the latest HP driver CD contents

To download the latest HP Driver CD:

1. Go to <http://www.hp.com> and select **Software and Drive Downloads**.
2. Locate your workstation and operating system.
3. Select your driver CD and then follow the directions under the Release Notes.

### Reinstalling the factory Linux image with the HP driver CD

1. Boot your workstation from the Red Hat box set, Binary CD 1.
2. When prompted, insert the Linux operating system restore media CDs.
3. Continue following the prompts until the operating system is installed.
4. Configure the X server to start on reboot.
5. Reboot your workstation.
6. Follow the onscreen prompts to set up your system with the Red Hat First Boot utility.
7. When prompted by First Boot to add CDs, insert the HP Driver CD into the drive on your workstation.
8. Select **Install** next to Additional CDs.  
The HP Driver CD window opens.
9. To begin the installation, select **Press to continue**.

When installation is complete, you are given two options: **Reboot now...** (on the left side), and **Press to continue, reboot later...** (on the right side).

10. Select **Reboot now...**

## Upgrading device drivers

To upgrade a Linux device driver, see [http://www.hp.com/support/workstation\\_swdrivers](http://www.hp.com/support/workstation_swdrivers).

## Linux-enabled workstations

Linux-enabled workstations do not have Linux preinstalled, nor do they include installation media for a Linux distribution. To install Linux, you must have the installation binary set for a Linux distribution (CD or DVD media, or a version on your network), and the HP Installer Kit for Linux.

The installer kit includes the HP CDs necessary to complete the installation of all versions of the distribution box set that are supported by HP workstation hardware.

To determine which versions are supported on your workstation, see the Linux hardware support matrix at [http://www.hp.com/support/linux\\_hardware\\_matrix](http://www.hp.com/support/linux_hardware_matrix).

To use the drivers in the HP Installer kit for Linux other than RHEL, you must manually extract the drivers from the HP Driver CD and install them. HP does not test the installation of these drivers on other Linux distributions, nor does HP support this operation.

## Verifying hardware compatibility

To determine which Linux versions are supported on your HP workstation hardware:

1. See [http://www.hp.com/support/linux\\_hardware\\_matrix](http://www.hp.com/support/linux_hardware_matrix).
2. Select your HP workstation model.



---

## 3 System management

This section describes the tools and utilities that provide system management for your workstation and includes the following topics:

- [The Computer Setup \(F10\) Utility on page 23](#)
- [Workstation management on page 31](#)

### The Computer Setup (F10) Utility

The Computer Setup (F10) Utility enables you to:

- Change factory default settings and set or change the system configuration, which might be necessary when you add or remove hardware.
- Determine if all devices installed on the workstation are recognized by the system and functioning.
- Determine information about the operating environment of the workstation.
- Solve system configuration errors that are detected but not fixed during the Power-On Self-Test (POST).
- Establish and manage passwords and other security features.
- Establish and manage energy-saving time-outs (not supported on Linux platforms).
- Modify or restore factory default settings.
- Set the system date and time.
- Set, view, change, or verify the system configuration, including settings for processor, graphics, memory, audio, storage, communications, and input devices.
- Set PCIe lane allocation between Slot four and Slot five.
- Modify the boot order of installed mass storage devices such as SATA, SAS, diskette drives, optical drives, network drives, and LS-120 drives.
- Configure the boot priority of SATA and SAS hard-drive controllers.
- Enable or disable Network Server Mode, which enables the workstation to boot the operating system when the power-on password is enabled with or without a keyboard or mouse attached. When attached to the system, the keyboard and mouse remain locked until the power-on password is entered.
- Enable or disable POST Messages to change the display status of POST messages. POST Messages suppresses most POST messages, such as memory count, product name, and other nonerror text messages. If a POST error occurs, the error is displayed regardless of the mode selected. To manually switch to POST Messages Enabled during POST, press any key except [F1](#) through [F12](#).
- Specify an Ownership Tag, which appears when the system is powered on or restarted.
- Specify the Asset Tag or property identification number assigned by your company to this workstation.

- Enable power-on password prompts during system restarts (warm-boots) and power on.
- Hide or show the integrated I/O functionality, including serial, USB, or parallel ports, audio, or embedded NIC. Hidden devices are inaccessible, which increases system security.
- Enable or disable removable media boot ability.
- Enable or disable removable media write ability (if supported by hardware).
- Replicate your system setup by saving system configuration information on CD or diskette and restoring it on workstations.
- Execute self-tests on specified SATA and SAS hard drives (if supported by the drive).

## BIOS ROM

The BIOS ROM is a collection of machine language programs stored as firmware in ROM. It includes functions such as POST, PCI device initialization, Plug and Play support, power management, and the Computer Setup (F10) Utility. The BIOS ROM is a 1-MB Serial Peripheral Interface (SPI) port. The firmware in the BIOS ROM supports the following systems and specifications:

- Advanced Configuration and Power Management Interface, Version 2.0
- Alert Standard Format Specification, Version 2.0
- AT Attachment 6 with Packet Interface (ATA/ATAPI – 6), Revision 3b
- ATAPI Removable Media Device BIOS Specification Version 1.0
- BIOS Boot Specification V1.01
- Standard BIOS 32-bit Service Directory Proposal
- "El Torito" Bootable CD-ROM Format Specification Version 1.0
- Enhanced Disk Drive Specification Version 1.1
- BIOS Enhanced Disk Drive Specification Version 3.0
- Enhanced Host Controller Interface Specification for Universal Serial Bus, Revision 1.0
- PCI Local Bus Specification, Revision 2.3
- PCI Power Management Specification, Revision 1.1
- PCI Express Base Specification, Revision 2.0
- Serial ATA Specification, Revision 1.0a
- Serial ATA II: Extensions to Serial ATA 1.0, Revision 1.0
- System Management BIOS Reference Specification, Version 2.5
- PC SDRAM Serial Presence Detect (SPD) Specification, Revision 1.2B
- TCG TPM Specification Version 1.2
- Universal Host Controller Interface Design Guide, Revision 1.1
- Universal Serial Bus Revision 1.1 Specification
- Universal Serial Bus Revision 2.0 Specification

## Using the Computer Setup (F10) Utility


You can only open the Computer Setup (F10) Utility by powering on or restarting the workstation.

To access the Computer Setup (F10) Utility menu:

1. Power on or restart the workstation.
2. As soon as your display is active and **F10=Setup** appears in the lower right corner of the screen, press **F10**.  
  
If you do not press **F10** at the appropriate time, try again. Turn the workstation off, then on, and press **F10** again to access the utility. You can also press the **Ctrl + Alt + Delete** keys before boot if you miss the opportunity to press **F10**.
3. Select your language from the list and press the **Enter** key.  
  
In the Computer Setup (F10) Utility menu, five headings are displayed: File, Storage, Security, Power, and Advanced.
4. Use the left and right arrow keys to select the appropriate heading, use the up and down arrow keys to select an option, and then press **Enter**.
5. Choose from the following:
  - To apply and save changes, select **File>Save Changes**, and then select **F10=YES**.
  - To remove changes you have made, select **Ignore Changes** and then select **F10=YES**.
  - To reset to factory settings, select **File>Default setup>Restore Factory Settings as Default**. Press **F10** to accept the changes, and then select **Apply Defaults and Exit**. This restores the original factory system defaults.

△ **CAUTION:** Do not power off the workstation while the ROM is saving your Computer Setup (F10) Utility changes because the Complementary Metal-Oxide Semiconductor (CMOS) could become corrupted. After you exit the F10 Setup screen, you can disconnect power from the workstation.

## The Computer Setup (F10) Utility menu

 **NOTE:** With new BIOS releases, the following content is subject to change so your menu might be different than shown.

**Table 3-1 Computer Setup (F10) Utility menu descriptions**

Heading	Option	Description
File	System Information	Displays the following system characteristics: <ul style="list-style-type: none"><li>• Product Name</li><li>• SKU Number</li><li>• Processor Type/Speed/Stepping</li><li>• Cache Size (L1/L2)</li><li>• Installed Memory Size</li><li>• Integrated MAC 1 and 2</li><li>• System BIOS</li><li>• Boot block date</li><li>• Chassis Serial Number</li><li>• Asset Tracking Number</li></ul>
	About	Displays copyright information.

**Table 3-1 Computer Setup (F10) Utility menu descriptions (continued)**

Heading	Option	Description
	System Temperatures	Displays system temperatures for CPU0 and CPU1, and fan speeds for processors, memory, chipsets, chassis, and PCI cards.
	Set Time and Date	Enables you to set system time and date.
	Flash System ROM	Enables you to upgrade the BIOS from a ROM image on diskette, CD, or USB.
	Replicated Setup	Provides these options: <ul style="list-style-type: none"> <li>• Save to Removable Media—Saves the system configuration, including CMOS, in the qsetup.txt file. This file can be saved to a formatted, blank 1.44-MB diskette, or to a USB device.</li> <li>• Restore from Removable Media—Restores the system configuration from a diskette or a USB device.</li> </ul>
	Default Setup	Provides these options: <ul style="list-style-type: none"> <li>• Save Current Settings as Default—Saves the current settings as default settings for the next operation.</li> </ul> Restore Factory Settings as Default—Restores the factory settings as the default settings for the next operation.
	Apply Defaults and Exit	Restores the default settings defined in Default Setup.
	Ignore Changes and Exit	Exits computer setup without applying or saving changes.
	Save Changes and Exit	Saves changes to system configuration and exits the computer setup.
Storage	Device Configuration	Lists installed non-SCSI storage devices (except SATA devices) and provides options for obtaining specific information about each device: <ul style="list-style-type: none"> <li>• Hard Disk—Provides information about the hard drives in the system.</li> <li>• CD-ROM—Provides information about the optical drives in the system.</li> <li>• Diskette Type (for legacy diskette drives only)—Identifies the highest capacity media type accepted by the diskette drive. Options are 3.5" (1.44 MB), 5.25" (1.2 MB), and Not Installed.</li> <li>• Default Values—Resets devices to their default configuration (SATA is the default). <ul style="list-style-type: none"> <li>◦ Multisector Transfers—Defines the transfer of data per interrupt. Options are 8, 16, and Disable (16 is the default).</li> <li>◦ Transfer Mode—Specifies the active data transfer mode. Options (subject to device capabilities) are Max UDMA, PIO 0, Max PIO, Enhanced DMA, and Ultra DMA0. (Max UDMA is the default).</li> <li>◦ Translation Mode—Enables the BIOS to determine the translation mode used to configure a formatted SATA or USB mass storage device. This prevents you from needing to know how the mass storage device was formatted. Options are Automatic, Bit Shift, LBA Assisted, Use (Cylinders, Heads, Sectors), and Off. Automatic is the default.</li> </ul> <p>Ordinarily, you should not change the translation mode selected by the BIOS. If the selected translation mode is not compatible with the translation mode that was active when the drive was partitioned and formatted, the data on the disk is inaccessible.</p> </li> </ul>

**Table 3-1 Computer Setup (F10) Utility menu descriptions (continued)**

Heading	Option	Description
	Storage Options	<p>Provides these options:</p> <ul style="list-style-type: none"> <li>Removable Media Boot—Enables and disables the ability to boot the system from removable media.</li> <li>Legacy Diskette Write—Enables and disables the ability to write data to removable media.</li> <li>BIOS DMA Data Transfers—Enables and disables DMA data transfers.</li> <li>SATA Emulation—Sets the SATA emulation mode with the following options: <ul style="list-style-type: none"> <li>RAID + AHCI—both the RAID and AHCI OROMs execute. This emulation mode is the default and offers the best performance and most functionality.</li> <li>Separate IDE Controller—offers standard SATA supports (four ports only).</li> <li>Combined IDE Controller—makes the SATA controller look like an IDE controller and offers best IDE compatibility (two ports only).</li> </ul> </li> <li>SATA PORT0–5—enables and disables SATA ports 0–5.</li> <li>SATA/eSATA SPEED PORT4 Setup—Enables you to set the following port speeds: <ul style="list-style-type: none"> <li>GEN2/3.0 Gbps (Internal Only)</li> <li>GEN1/1.5 Gbps (eSATA Only)</li> </ul> </li> <li>SATA/eSATA PORT5 Setup—Enables you to set the following port speeds: <ul style="list-style-type: none"> <li>GEN2/3.0 Gbps (Internal Only)</li> <li>GEN1/1.5 Gbps (eSATA Only)</li> </ul> </li> </ul>
	DPS Self-test	<p>Select a drive—Enables you to select a drive to test.</p> <p>The DPS Self-test tells an IDE hard disk to go run its own internal self-test and report the results. If the SATA controller is not in IDE emulation mode—either Separate IDE Controller or Combined IDE Controller—the DPS Self-test option is not displayed in the Setup menu.</p> <p><b>NOTE:</b> This selection only appears when at least one drive capable of performing the IDE DPS self-test is attached to the system. By default, the SATA controller is in RAID+AHCI mode, so this option is not displayed.</p>
	Boot Order	<p>Enables you to configure the boot, diskette drive, and hard drive orders by physically reordering the menu entries. The following is the default boot order presented in the menu:</p> <ul style="list-style-type: none"> <li>Optical Drive</li> <li>Diskette Drive</li> <li>USB Device</li> <li>Hard Drive</li> <li>Broadcom Ethernet controller 1</li> <li>Broadcom Ethernet controller 2</li> </ul> <p>To drag a device to a preferred place, press <a href="#">Enter</a>. To remove the device from consideration as a bootable device, press <a href="#">F5</a>.</p> <p>MS-DOS drive lettering assignments might not apply after an operating system other than MS-DOS has started.</p> <p>Boot devices can be disabled in the boot order process. These order changes are stored in the physical ROM when the F10 Setup changes are confirmed with File&gt;Save Changes and Exit.</p> <p>You can temporarily override the boot order. To boot one time from a device other than the default device specified in Boot Order, restart the workstation and press <a href="#">F9</a> when the F9=Boot Menu message appears on the screen. After POST completes, a list of bootable devices is displayed.</p>

**Table 3-1 Computer Setup (F10) Utility menu descriptions (continued)**

Heading	Option	Description
		Use the arrow keys to select the preferred bootable device and press <a href="#">Enter</a> . The workstation then boots from the selected nondefault device for this one time.
Security	Setup Password	Enables you to set and enable a setup password for the administrator.  If you create a setup password, you must use it to change computer setup options, to flash the ROM, and to make changes to certain Plug and Play settings under Windows.
	Power-On Password	Enables you to set and enable the power-on password.
	Password Options	This option becomes available when you create a setup or power-on password. It provides these options: <ul style="list-style-type: none"> <li>• Lock Legacy Resources—Prevents the operating system from changing resources to serial, parallel, or diskette controller.</li> <li>• Network Server Mode—Enables network server mode.</li> <li>• Password Prompt on Warm Boot—Enables a password prompt on a warm boot.</li> </ul>
	Smart Cover	Allows you to enable and disable the cover removal sensor, or to notify you if the sensor is activated.
	Device Security	Makes the following devices available or hidden to the system: <ul style="list-style-type: none"> <li>• Serial Port</li> <li>• All USB Ports</li> <li>• Front USB Port</li> <li>• System Audio</li> <li>• IDE Controller Security</li> <li>• SATA Controller Security</li> <li>• IEEE 1394 Controller</li> <li>• Network Controller 1</li> <li>• Network Controller 2</li> <li>• SAS Controller</li> <li>• Embedded Security Device</li> </ul>
	Embedded Security Device	This option becomes available if Embedded Device is set to Available.  Embedded Security Device (Hidden or Available) turns the Trusted Platform Mechanism (TPM) on and off. Device Hidden is the default. If this option is made available, the following options become available: <ul style="list-style-type: none"> <li>• Power-On Authentication Support—Enables and disables an authentication feature that requires you to enter a TPM user key password to boot the system. This feature uses the TPM to generate and store the authentication password.</li> <li>• Reset Authentication Credential—Resets the authentication functionality and clears authentication credentials.</li> </ul> <p>To enable the Embedded Security Device and to access any security features associated with the device, you must enter a setup password.</p> <p>Setting a device to Available enables the operating system to access the device. Hidden makes the device unavailable. It is disabled by the BIOS and cannot be enabled by the operating system.</p>
	Network Service Boot	Enables or disables the ability to boot to the network using the <a href="#">F12</a> key or the boot order.
	System IDs	Provides these options:

**Table 3-1 Computer Setup (F10) Utility menu descriptions (continued)**

Heading	Option	Description
		<ul style="list-style-type: none"> <li>Asset Tag—A 16-byte string identifying the system.</li> <li>Ownership Tag—An 80-byte string identifying ownership of the system. This tag appears on the screen during POST.</li> <li>Universal Unique Identifier (UUID)—Can only be updated if the current chassis serial number is invalid. (These ID numbers are normally set in the factory and are used to uniquely identify the system.)</li> <li>Keyboard—Enables you to set the keyboard locale for System ID entry.</li> </ul>
	OS Security	<p>Provides these options:</p> <ul style="list-style-type: none"> <li>Data Execution Prevention—Enables or disables Data Execution Prevention mode in the processors. This mode prohibits code from running in pages that were set up as data pages, and prevents attacks such as buffer overflows. Operating system support is required for this feature.</li> <li>Intel Virtualization Technology (VTx)—Enables or disables Intel Virtualization Technology to increase workstation performance.</li> <li>Intel IO Virtualization—Enables or disables Virtualization Technology to increase workstation I/O performance.</li> <li>OS Management of Embedded Security Device—Enables or disables the ability of the operating system to control the TPM device, including turning it on and off, initializing it, and resetting it.</li> <li>Reset of Embedded Security Device through OS—Enables or disables the ability of the operating system to reset the TPM.</li> </ul>
Power	OS Power Management	<p>Enables or disables:</p> <ul style="list-style-type: none"> <li>Runtime Power Management</li> <li>Idle Power Savings</li> <li>Idle Power Savings (C2 Extended)</li> <li>ACPI S3 Hard Disk Reset</li> <li>ACPI S3 PS 2 Mouse Wakeup</li> <li>USB Wake on Device Insertion</li> </ul>
	Hardware Power Management	Enables or disables SATA Power Management
	Thermal	Enables you to set the rate of the system fan when the processor is in idle.
Advanced**	Power-On Options	<p>Enables you to set the following:</p> <ul style="list-style-type: none"> <li>POST Messages—Enables or disables the splash screen during POST.</li> <li>F1 Prompt on Recoverable Errors—Enables or disables the presentation of the F1 prompt on recoverable errors.</li> <li>F9 Prompt (Displayed or Hidden)—Selecting <b>Displayed</b> displays the <b>F9=Boot Menu</b> during POST. Selecting <b>Hidden</b> prevents the text from being displayed. However, pressing F9 still accesses the boot menu.</li> <li>F10 Prompt (Displayed or Hidden)—Selecting <b>Displayed</b> displays <b>F10=Setup</b> during POST. Selecting <b>Hidden</b> prevents the text from being displayed, but pressing F10 still accesses the Setup screen.</li> <li>F11 Prompt (Displayed or Hidden)—Selecting <b>Displayed</b> makes the Factory Recovery option visible during POST. Selecting <b>Hidden</b> prevents the text from being displayed, but pressing F10 still accesses the Setup screen. Factory Recovery Boot Support must be enabled to use this option.</li> </ul>

**Table 3-1 Computer Setup (F10) Utility menu descriptions (continued)**

Heading	Option	Description
		<ul style="list-style-type: none"> <li>F12 Prompt (Displayed or Hidden)—Selecting <b>Displayed</b> displays <b>F12=Network Service Boot</b> during POST. Selecting <b>Hidden</b> prevents the text from being displayed but pressing F12 still forces the system to attempt booting from the network.</li> <li>Factory Recovery Boot Support (Enable or Disable)—Recovery partition hard disk drive (HDD) option available. The Vista factory setting has this support enabled.</li> <li>Option ROM prompt* (Enable or Disable)—Enabling this feature causes the system to display a message before loading options ROMs.</li> <li>Remote Wakeup Boot Source—Enables you to set the remote wakeup boot source as: <ul style="list-style-type: none"> <li>Local Hard Drive</li> <li>Remote Server</li> </ul> </li> <li>After Power Loss (On, Off, Previous State)—Enabling this option directs the previous state to be the default.</li> <li>POST Delay (in seconds) (5, 10, 15, 20, None)—Adds a specified delay to the POST process. This delay is sometimes needed for hard drives on some PCI cards that spin up slowly (so slowly that they are not ready to boot by the time POST is finished). The POST delay also gives you time to select F10 to enter the Computer Setup (F10) Utility.</li> <li>Setup Browse Mode (Enable/Disable)—Enables or disables browse mode setup.</li> </ul>
	BIOS Power-On	Enables you to disable or specify a weekday and time for BIOS power-on.
	Processors	<p>Provides these options:</p> <ul style="list-style-type: none"> <li>Multi Core Support (Enable or Disable)—Select a single core or multiple cores per socket.</li> <li>Limit CPUID Maximum Value to 3 (Enable or Disable)—Sets the number of allowable CPU IDs.</li> </ul>
	Onboard Devices	Enables you to set resources for or disable onboard system devices such as serial ports, parallel ports, and diskette controllers. Operating system parameters generally override Onboard Devices settings.
	Chipset/ Memory	<p>Provides these options:</p> <ul style="list-style-type: none"> <li>PCI SERR# Generation (Enable or Disable)—Controls PCI SERR# generation for ill-behaved PCI add-in cards (that can generate SERR# spuriously).</li> <li>PCI VGA Palette Snooping (Enable or Disable)—Controls PCI VGA Palette Snooping for compatibility purposes.</li> <li>MCH Error Handling—Sets the following signals to use on serious MCH (North Bridge) errors: <ul style="list-style-type: none"> <li>SMI, which is handled by the BIOS and causes a reboot.</li> <li>NMI and Machine-Check Error, which are handled by the operating system and cause a crash.</li> <li>Ignore.</li> </ul> </li> <li>Memory Write Combining (Enable or Disable)—Implements special caching for rapid I/O.</li> <li>PCIe Lane Allocation (SLOT4:SOT5)—Defines the number of lanes assigned to a slot: <ul style="list-style-type: none"> <li>Auto</li> <li>x16:x1</li> <li>x8:x8</li> </ul> </li> </ul>



**Table 3-1 Computer Setup (F10) Utility menu descriptions (continued)**

Heading	Option	Description
	Device Options	<p>Enables you to set the following device options:</p> <ul style="list-style-type: none"> <li>• Num Lock State at Power-On (On or Off)</li> <li>• S5 Wake-on-LAN (Enable or Disable)</li> <li>• Unique Sleep State Blink Rates (Enable or Disable)</li> <li>• Monitor Tracking (Enable or Disable)</li> <li>• NIC PXE Option ROM* Download (Enable or Disable)</li> <li>• SAS Option ROM* Download (Enable or Disable)</li> <li>• SATA RAID Option ROM* Download (Enable or Disable)</li> <li>• PCIIX Secondary Latency Timer: <ul style="list-style-type: none"> <li>◦ Default</li> <li>◦ # PCI Clocks</li> </ul> </li> <li>• SAS Latency Timer: <ul style="list-style-type: none"> <li>◦ Default</li> <li>◦ # PCI Clocks</li> </ul> </li> <li>• Peer-to-Peer Reads</li> <li>• Fast Delayed Transaction Timer</li> </ul>
	Slot 1 - PCI	Slot 1 option ROM download (Enable or Disable), and latency timer.
	Slot 2 - PCIe x16	Slot 2 option ROM download (Enable or Disable).
	Slot 3 - PCIe x8 (4)	Slot 3 option ROM download (Enable or Disable).
	Slot 4 - PCIe x16 (8)***	Slot 4 option ROM download (Enable or Disable).
	Slot 5 - PCIe x8***	Slot 5 option ROM download (Enable or Disable).
	Slot 6 - PCIe x8 (4)	Slot 6 option ROM download (Enable or Disable).
	Slot 7 - PCI-X 133	Slot 7 option ROM download (Enable or Disable), and latency timer and speed.

\* Available on selected models.

\*\* These options should be used by advanced users only.

\*\*\* For information about specifying lane allocation, see *PCI Lane Allocation* under the Advanced, Chipset/Memory description above.

## Workstation management

The HP Client Management Solutions (CMS), available for download from <http://www.hp.com/go/easydeploy>, are standards-based solutions for managing and controlling workstations in a networked

environment. This section summarizes capabilities, features, and key components of workstation management, including:

- [Initial workstation configuration and deployment on page 32](#)
- [Installing a remote system on page 32](#)
- [Replicating the setup on page 33](#)
- [Updating and managing software on page 34](#)
- [ROM Flash on page 36](#)
- [F10 setup instruction in the BIOS SoftPaq on page 36](#)
- [Asset tracking and security on page 37](#)
- [Fault notification and recovery on page 44](#)
- [Dual-state power button on page 45](#)

Support for specific features described in this guide can vary by model and software version.

## Initial workstation configuration and deployment

Your workstation includes a preinstalled system software image. After a brief software unbundling process, the workstation is ready to use.

If you prefer to replace the preinstalled software image with a customized set of system and application software, several methods are available for deploying a customized software image, including:

- Installing additional software applications after unbundling the preinstalled software image
- Using a disk cloning process to copy the contents from one hard drive to another

The best deployment method depends on your information technology environment and processes. To help you select the best deployment method, see the PC Deployment section of the HP Lifecycle Solutions Web site (<http://www.hp.com/support/HPLS>).

The Restore Plus! CD, ROM-based setup, and ACPI hardware provide further assistance with recovery of system software, configuration management and troubleshooting, and power management.

## Installing a remote system

Remote system installation enables you to start and set up your system using software and configuration information on a network server. This feature is usually used as a system setup and configuration tool and can be used for the following tasks:

- Deploying a software image on new PCs
- Formatting a hard drive
- Installing application software or drivers
- Updating the operating system, application software, or drivers

To initiate a remote system installation, press **F12** when **F12=Network Service Boot** appears in the lower right corner of the HP logo screen. Follow the onscreen instructions to continue the installation process. The default boot order is a BIOS configuration setting that can be changed to always attempt a PXE boot.


## Replicating the setup

The following procedures enable you to copy one setup configuration to other workstations of the same model for faster, more consistent configuration of multiple workstations. Procedures require a diskette drive or a USB device such as an HP Drive Key.

### Copying a setup configuration to a single workstation

△ **CAUTION:** A setup configuration is model-specific. File system corruption can result if source and target workstations are not the same model. For example, do not copy the setup configuration from an HP xw4200 Workstation to an HP xw8600 Workstation.

1. Select a setup configuration to copy, and then reboot the workstation.
2. As soon as the workstation powers on, press and hold **F10** until you enter the Computer Setup (F10) Utility. If necessary, press **Enter** to bypass the title screen.

 **NOTE:** If you do not press **F10** at the appropriate time, you must restart the workstation, and then press and hold **F10** again to access the utility.

If you are using a PS 2 keyboard, you might see a keyboard error message. Disregard it.

3. If you are using a diskette or other storage device, insert it now.
4. Select **File>Replicated Setup>Save to Removable Media**. Follow the instructions on the screen to create the configuration diskette or USB media device.
5. Power off the workstation you are configuring and insert the configuration diskette into the diskette drive or USB media device.
6. Power on the workstation you are configuring.
7. Press and hold the **F10** key until you enter the Computer Setup (F10) Utility. If necessary, press **Enter** to bypass the title screen.
8. Select **File>Replicated Setup>Restore from Removable Media**, and then follow the instructions on the screen.
9. Restart the workstation when the configuration is complete.


### Copying a setup configuration to multiple workstations

△ **CAUTION:** A setup configuration is model-specific. If source and target workstations are not the same model, file system corruption can result. For example, do not copy the setup configuration from an HP xw4200 Workstation to an HP xw8600 Workstation.

This method takes longer to prepare the configuration diskette, but copying the configuration to target workstations is fast.

A bootable diskette is required for this procedure. If Windows XP is not available to create a bootable diskette, use the method for copying to a single workstation instead (see [Copying a setup configuration to a single workstation on page 33.](#))

1. Create a bootable diskette or USB media device.
2. Select a setup configuration to copy.
3. Restart the workstation.
4. As soon as the workstation powers on, press and hold **F10** until you enter the Computer Setup (F10) Utility. If necessary, press **Enter** to bypass the title screen.

 **NOTE:** If you do not press the **F10** key at the appropriate time, you must restart the workstation, and then press and hold the **F10** key again to access the utility.

If you are using a PS 2 keyboard, you might see a keyboard error message. Disregard it.

5. If you are using a diskette or other storage device, insert it now.
6. Select **File>Replicated Setup>Save to Removable Media**, and follow the instructions on the screen to create the configuration diskette or USB media device.
7. Download a BIOS utility for replicating setup (repset.exe), and copy it to the configuration diskette or USB media device. To obtain this utility, see <http://www.hp.com/support/files>.
8. Enter the model number of the workstation.
9. On the configuration diskette, create an autoexec.bat file containing `repset.exe` and `cpqsetup.txt`.
10. Power off the workstation you are configuring, insert the configuration diskette, and then power on the workstation. The configuration utility runs automatically.
11. When the configuration is complete, restart the workstation.

## Updating and managing software

HP provides several tools for managing and updating software on desktops and workstations:

- HP Client Manager Software
- System Software Manager
- Altiris Client Management Solutions
- Proactive Change Notification
- Subscriber's Choice

### HP Client Manager Software

HP Client Manager Software (HP CMS) assists customers in managing workstation hardware. It offers:

- Detailed views of hardware inventory for asset management
- PC health-check monitoring and diagnostics
- Proactive notification of changes in the hardware environment
- Web-accessible reporting of business-critical details such as thermal warnings and memory alerts
- Remote updating of system software such as device drivers and ROM BIOS
- Remote changing of boot order
- Configuration of system BIOS settings

For more information about the HP Client Manager, see <http://www.hp.com/go/ssm>.

## Altiris Client Management Solutions

Altiris and HP have partnered to provide comprehensive, tightly integrated systems management solutions to reduce the cost of owning HP client PCs. The HP CMS is the foundation for additional Altiris Client Management Solutions that address:

- Inventory and asset management
- Deployment and migration
- Help desk and problem resolution
- Software and operations management

For more information about the following topics, go to <http://www.hp.com/go/ssm>:

- How HP CMS works
- Which solutions are compatible with your operating system
- How to download a fully functional, 30-day evaluation version of Altiris solutions

## System Software Manager

System Software Manager (SSM) is a utility that enables you to update system-level software on multiple systems simultaneously. When executed on a PC client system, SSM detects hardware and software versions and then updates the software from a central repository, known as a *file store*. Driver versions supported by SSM are noted with a special icon on the software, the driver download Web site, and on the Support Software CD. To download the utility or to obtain more information about SSM, see <http://www.hp.com/go/ssm>.

## Proactive Change Notification

The Proactive Change Notification program uses the Subscriber's Choice Web site to:

- Send Proactive Change Notification (PCN) e-mail informing you up to 60 days in advance of hardware and software changes to most commercial workstations and servers
- Send you e-mail containing customer bulletins, customer advisories, customer notes, and driver alerts for most commercial workstations and servers

You can create your own profile to ensure that you only receive the information relevant to your specific IT environment.

To learn more about the PCN program and to create a custom profile, see [Subscriber's Choice on page 35](#).

## Subscriber's Choice

Subscriber's Choice is a client-based service from HP that supplies you with personalized product tips, feature articles, and driver and support alerts and notifications based on your profile.

Subscriber's Choice Driver and Support Alerts and Notifications delivers e-mail notifying you that the information you subscribed to in your profile is available for review and retrieval.

To learn more about Subscriber's Choice and create a custom profile, see <http://www.hp.com/subscriberschoice>.

## ROM Flash

Your HP workstation comes with a programmable flash ROM. By establishing a setup password in the Computer Setup (F10) Utility, you can protect the ROM from being inadvertently updated or overwritten. This function is important to ensure the operating integrity of the workstation.

To upgrade the ROM, download the latest SoftPaq images from <http://www.hp.com//support/files>.

For maximum ROM protection, establish a setup password. The setup password prevents unauthorized ROM upgrades. SSM enables you to create the setup password on several workstations simultaneously. For more information, see <http://www.hp.com/go/ssm>.

## Remote ROM Flash

Remote ROM Flash allows system administrators to safely upgrade the ROM on remote HP workstations from a centralized network management console, resulting in a consistent deployment of, and greater control over, HP PC ROM images over the network.

To use Remote ROM Flash, the workstation must be powered on, or turned on using Remote Wakeup.

For more information about Remote ROM Flash, see the HP Client Manager Software or System Software Manager sections at <http://www.hp.com/go/ssm>.

## HPQFlash

The HPQFlash utility is used to locally update or restore the system ROM on PCs using a Windows operating system.

For more information about HPQFlash, see <http://www.hp.com/go/ssm>, and enter the name of your workstation.

## F10 setup instruction in the BIOS SoftPaq

### FailSafe Boot Block ROM

The FailSafe Boot Block ROM enables system recovery in the unlikely event of a ROM flash failure. For example, if a power failure occurs during a ROM upgrade, the Boot Block uses a flash-protected section of the ROM to verify a valid system ROM flash when power is restored to the system.

If the system ROM is valid, the system starts normally.

If the system ROM fails the validation check, the FailSafe Boot Block ROM provides enough support to start the system from a BIOS image CD created from a SoftPaq. The BIOS image CD programs the system ROM with a valid image.

When Boot Block detects an invalid system ROM, the workstation power LED blinks red eight times and the workstation beeps eight times; then the workstation pauses for two seconds. On some models, a Boot Block recovery mode message appears.

In preparation for system recovery, use the BIOS CD media file in the SoftPaq to create a BIOS image CD.

To recover the system after it enters Boot Block recovery mode:

1. If there is media in the diskette or optical drives, remove it.
2. Insert a BIOS image CD into the CD drive.

You can also use USB media such as an HP DriveKey.

3. Power off, then power on the workstation.  
If no BIOS image CD or USB is found, you are prompted to insert one and restart the workstation.  
If a setup password has been established, the Caps Lock light illuminates and you are prompted for the password.
4. Enter the setup password.  
If the system starts from the CD or USB and successfully reprograms the ROM, three keyboard lights illuminate. A rising-tone series of beeps also signals successful recovery.
5. Remove the CD or USB media and power off the workstation.
6. Restart the workstation.

## Asset tracking and security

Asset tracking features incorporated into your workstation provide asset tracking data that can be managed using HP Systems Insight Manager (HP SIM), HP CMS, or other systems-management applications.

Seamless, automatic integration between asset tracking features and these products enables you to choose the management tool that is best suited to your environment and to leverage investments in existing tools.

HP also offers several solutions for controlling access to valuable components and information:

- HP ProtectTools Embedded Security prevents unauthorized access to data, checks system integrity, and authenticates third-party users attempting system access.
- Security features such as ProtectTools and the Hood Sensor (Smart Cover Sensor) help prevent unauthorized access to your data and to the internal components of the workstation.
- By disabling parallel, serial, or USB ports, or by disabling removable-media boot capability, you can protect valuable data assets.
- Memory Change and Hood Sensor (Smart Cover Sensor) alerts can be forwarded to system management applications to deliver proactive notification of tampering with a workstation's internal components.

ProtectTools, the Hood Sensor (Smart Cover Sensor), and the (Smart Cover Lock) are available as options on select systems.

Use the following utilities to manage security settings on the HP workstation:

- Locally, using the Computer Setup (F10) Utility
- Remotely, using the HP CMS or System SSM, which enables the secure, consistent deployment and control of security settings from a simple command line utility

The following table and sections refer to the management of workstation security through the Computer Setup (F10) Utility

**Table 3-2 Security features overview**

Feature	Purpose	How it is established
Removable Media Boot Control	Prevents booting from removable media drives	From the Computer Setup (F10) Utility menu
Serial, Parallel, USB, or Infrared Interface Control	Prevents transfer of data through the integrated serial, parallel, USB, or infrared interface	From the Computer Setup (F10) Utility menu

**Table 3-2 Security features overview (continued)**


Feature	Purpose	How it is established
Power-On Password	Prevents use of the workstation until the password is entered (applies to initial system startup and restarts)	From the Computer Setup (F10) Utility menu
Setup Password	Prevents reconfiguration of the workstation (use of the Setup utility) until the password is entered	From the Computer Setup (F10) Utility menu
Network Server Mode	Provides unique security features for workstations used as servers	From the Computer Setup (F10) Utility menu

**NOTE:** For more information about the Computer Setup (F10) Utility, see [The Computer Setup \(F10\) Utility menu on page 25](#).

## Password security

The power-on password prevents unauthorized use of the workstation by requiring entry of a password to access applications or data when the workstation is powered on or restarted. The setup password specifically prevents unauthorized access to the Computer Setup (F10) Utility and can also be used as an override to the power-on password. When prompted for the power-on password, entering the setup password instead enables access to the workstation.

You can establish a network-wide setup password to enable the system administrator to log in to all network systems to perform maintenance without needing to know the power-on password.

 **NOTE:** HP SSM and HP CMS enable remote management of setup passwords and other BIOS settings in a networked environment. For more information, see <http://www.hp.com/go/easydeploy>.

### Establishing a setup password using the Computer Setup (F10) Utility

Establishing a setup password through the Computer Setup (F10) Utility prevents reconfiguration of the workstation (through the use of the Computer Setup (F10) Utility) until the password is entered.

To establish a setup password using the Computer Setup (F10) menu:

1. Power on or restart the workstation.
2. As soon as the computer is powered on, press and hold **F10** until you enter the Computer Setup (F10) Utility. Press **Enter** to bypass the title screen, if necessary.

If you do not press **F10** at the appropriate time, you must restart the workstation, and then press and hold **F10** again to access the utility.

If you are using a PS 2 keyboard, you might see a keyboard error message. Disregard it.

3. Select **Security>Setup Password** and then follow the onscreen instructions.
4. Before exiting, select **File>Save Changes and Exit**.

### Establishing a power-on password using workstation setup

Establishing a power-on password through the Computer Setup (F10) Utility prevents access to the workstation when power is connected, unless you specify the password. When a power-on password is set, the Computer Setup (F10) Utility presents Password Options in the Security menu. The password options include Network Server Mode and Password Prompt on Warm Boot.

When Network Server Mode is disabled, you must specify the password when the workstation is powered on when the key icon appears on the monitor. When Password Prompt on Warm Boot is enabled, you must enter the password must also be entered each time the workstation is rebooted.



When Network Server Mode is enabled, the password prompt is not presented during POST, but an attached PS/2 keyboard remains locked until you enter the power-on password.

To enable Network Server Mode, you set a power-on password. The option to set this password is available under **Advanced>Password Options**. This option enables the system to boot without requiring the power-on password, but the keyboard and mouse are locked until you enter the password. The keyboard LEDs rotate constantly when the system is in locked mode.

To establish a power-on password through the Computer (F10) menu:

1. Power on or restart the workstation.
2. As soon as your workstation is powered on, press and hold **F10** until you enter the Computer Setup (F10) Utility. Press **Enter** to bypass the title screen, if necessary.  
  
If you do not press **F10** at the appropriate time, you must restart the workstation and then press and hold **F10** again to access the utility.  
  
If you are using a PS 2 keyboard, you might see a keyboard error message. Disregard it.
3. Select **Security>Power-On Password** and then follow the onscreen instructions.
4. Before exiting, select **File>Save Changes and Exit**.

### Entering a power-on password

1. Restart the workstation.
2. When the key icon appears on the monitor, enter the current password, and then press **Enter**.

Type carefully. For security reasons, the characters you enter do not appear on the screen.

If you enter the password incorrectly, a broken key icon appears. Try again. After three unsuccessful tries, you will enter the F10 setup screen with read-only permission. (See the Setup Browse Mode option under the Power-On options.)

### Entering a setup password

If a setup password has been established on the workstation, you will be prompted to enter it each time you run the Computer Setup (F10) Utility.

To enter a setup password:

1. Restart the workstation.
2. As soon as the workstation is powered on, press and hold **F10** until you enter the Computer Setup (F10) Utility. Press **Enter** to bypass the title screen, if necessary.  
  
If you do not press **F10** at the appropriate time, you must restart the workstation and press and hold **F10** again to access the utility.  
  
If you are using a PS 2 keyboard, you might see a keyboard error message. Disregard it.
3. When the key icon appears on the monitor, enter the setup password, and press **Enter**.

Type carefully. For security reasons, the characters you enter do not appear on the screen.

If you enter the password incorrectly, a broken key icon appears. Try again. After three unsuccessful tries, you must restart the workstation before you can continue.

## Changing a power-on or setup password

1. Restart the workstation.
2. To change the power-on password, go to step 4.
3. To change the setup password, as soon as the workstation is powered on, press and hold **F10** until you enter the Computer Setup (F10) Utility. Press **Enter** to bypass the title screen, if necessary.

If you do not press **F10** at the appropriate time, you must restart the workstation, and then press and hold the **F10** key again to access the utility.

If you are using a PS 2 keyboard, you might see a keyboard error message. Disregard it.

4. When the key icon appears, enter the current password, a slash (/) or alternative delimiter character, your new password, another slash (/) or alternative delimiter character, and your new password again as shown:

*current password/new password/new password*

For information about the alternative delimiter characters, see [National keyboard delimiter characters on page 40](#).

Type carefully. For security reasons, the characters you enter do not appear on the screen.

5. Press **Enter**.

The new password takes effect the next time you power on the workstation.

The power-on and setup passwords can also be changed using the Security options in the Computer Setup (F10) Utility.

## Deleting a power-on or setup password

1. Power on or restart the workstation.
2. Choose from the following:
  - To delete the power-on password, go to step 4.
  - To delete the setup password, as soon as the workstation is powered on, press and hold **F10** until you enter the Computer Setup (F10) Utility. Press **Enter** to bypass the title screen, if necessary.

If you do not press **F10** at the appropriate time, you must restart the computer and then press and hold **F10** again to access the utility.

Use the appropriate operating system shutdown process.

3. When the key icon appears, enter your current password followed by a slash (/) or alternative delimiter character: *current password/*.

For information about the alternative delimiter characters see [National keyboard delimiter characters on page 40](#).

4. Press **Enter**.

## National keyboard delimiter characters

Each keyboard meets country-specific requirements. The syntax and keys you use for changing or deleting passwords depend on the keyboard included with your workstation.

**Table 3-3 National keyboard delimiter characters**

Language	Delimiter	Language	Delimiter	Language	Delimiter
Arabic	/	Greek	-	Russian	/
Belgian	=	Hebrew	.	Slovakian	-
BHCSY*	-	Hungarian	-	Spanish	-
Brazilian	/	Italian	-	Swedish/Finnish	/
Chinese	/	Japanese	/	Swiss	-
Czech	-	Korean	/	Taiwanese	/
Danish	-	Latin American	-	Thai	/
French	!	Norwegian	-	Turkish	.
French Canadian	é	Polish	-	U.K. English	/
German	-	Portuguese	-	U.S. English	/

**NOTE:** \* Bosnia-Herzegovina, Croatia, Slovenia, and Yugoslavia

## Clearing passwords

If you forget your password, you cannot access the workstation. For instructions about clearing passwords, see [Resetting the password jumper on page 152](#).

## DriveLock

**⚠ WARNING!** Enabling DriveLock can render a hard drive permanently inaccessible if the master password is lost or forgotten. No method exists to recover the password or access the data.

DriveLock uses an industry-standard security feature that prevents unauthorized access to data on an ATA hard drive. DriveLock has been implemented as an extension to Computer Setup (F10) functions. It is only available when hard drives that support the ATA security command set are detected. On HP workstations, it is not available when the SATA emulation mode is RAID+AHCI or RAID.

DriveLock is for HP customers for whom data security is a paramount concern. For such customers, the cost of a hard drive and the loss of the data stored on it is inconsequential when compared to the damage that could result from unauthorized access to its contents.

To balance this level of security with the need to address the issue of a forgotten password, the HP implementation of DriveLock employs a two-password security scheme. One password is intended to be set and used by a system administrator, while the other is typically set and used by the user.

No "back door" can be used to unlock the drive if both passwords are lost. Therefore, DriveLock is most safely used when the data contained on the hard drive is replicated on a corporate information system or is regularly backed up.

If both DriveLock passwords are lost, the hard drive is rendered unusable. For users who do not fit the previously defined customer profile, this might not be acceptable. For users who fit this profile, it might be a tolerable risk, given the nature of the data stored on the hard drive.

## DriveLock applications

The most practical use of DriveLock is in a corporate environment. The system administrator would be responsible for configuring the hard drive, which involves setting the DriveLock master password and

a temporary user password. If you forget the user password or if the equipment is passed on to another employee, the master password can be used to reset the user password and regain access to the hard drive.

HP recommends that corporate system administrators who enable DriveLock also establish a corporate policy for setting and maintaining master passwords. This should be done to prevent a situation where an employee sets both DriveLock passwords before leaving the company. In such a scenario, the hard drive is unusable and requires replacement. Likewise, by not setting a master password, system administrators might find themselves locked out of a hard drive and unable to perform routine checks for unauthorized software, other asset control functions, and support.

For users with less stringent security requirements, HP does not recommend enabling DriveLock. Users in this category include personal users, or users who do not maintain sensitive data on their hard drives as a common practice. For these users, the potential loss of a hard drive resulting from forgetting both passwords is much greater than the value of the data DriveLock protects.

Access to Computer Setup (F10) and DriveLock can be restricted through the setup password. By specifying a setup password and not giving it to users, system administrators can restrict users from enabling DriveLock.

## Using DriveLock

When hard drives that support the ATA security command set are detected, DriveLock appears under the Security menu in the Computer Setup (F10) menu. You are presented with options to set the master password and to enable DriveLock. You must provide a user password to enable DriveLock. Because the initial configuration of DriveLock is typically performed by a system administrator, a master password should be set first.

HP encourages system administrators to set a master password whether they plan to enable DriveLock or not. This gives the administrator the ability to modify DriveLock settings if the drive is locked in the future. After the master password is set, the system administrator can enable DriveLock or leave it disabled.

If a locked hard drive is present, POST requires a password to unlock the device. If a power-on password is set and it matches the device's user password, POST does not prompt the user to re-enter the password. Otherwise, the user is prompted to enter a DriveLock password.

For a cold boot, use the master or user password. For a warm boot, enter the same password used to unlock the drive during the preceding cold boot.

Users have two attempts to enter a correct password. During cold boot, if neither attempt succeeds, POST continues but the drive remains inaccessible. During a warm-boot or restart from Windows, if neither attempt succeeds, POST halts and the user is instructed to cycle power.

To enable and set the DriveLock user password:

1. Power on or restart the workstation.
2. As soon as the workstation is powered on, press and hold **F10** until you enter the Computer Setup (F10) Utility. Press **Enter** to bypass the title screen, if necessary.

If you do not press **F10** at the appropriate time, you must restart the workstation, and then press and hold **F10** again to access the utility.

If you are using a PS2 keyboard, you might see a keyboard error message. Disregard it.

3. Select **Security>DriveLock Security**.
4. For each DriveLock-capable drive, select a drive by pressing **F10** to accept.

5. Under Enable/Disable DriveLock options, select **Enable**, and then press **F10** to enable DriveLock for a specific drive.

△ **CAUTION:** Forgetting the DriveLock password renders the drive unusable.

6. Enter a new user password, and then press **F10** to accept. This password may be 1 to 32 characters long.
7. Enter the password again in the Enter New Password Again field. If you forget this password, the drive is rendered permanently disabled.
8. Select **File>Save Changes and Exit**, and then press **F10**. After you press **F10**, the system performs a cold boot before invoking the DriveLock function.

You can also use this process to set the DriveLock master password by selecting **Master** in Step 5.

When the workstation starts, you are prompted to enter the DriveLock password for each DriveLock-capable drive for which you have set a password. You have two attempts to enter the password correctly. If the password is not entered correctly, the workstation attempts to boot anyway. However, the boot process most likely fails because data from a locked drive cannot be accessed.

In a single drive workstation, if the drive has DriveLock enabled, the workstation might not be able to boot to the operating system, and might try to boot from the network or from another storage device (depending on the boot ordering options). Regardless of the outcome of the boot attempts, the drive-locked drive remains inaccessible without the DriveLock password.

In a two-drive workstation that has a boot drive and a data drive, you can apply the DriveLock feature to the data drive only. In this case, the workstation can always boot, but the data drive is accessible only when the DriveLock password is entered.

Cold boots require that you enter DriveLock passwords. However, DriveLock passwords are also required for warm boots. For example, if you boot to DOS and press **Ctrl+Alt+Del**, you must enter the DriveLock password before the workstation completes the next boot cycle. This warm-boot behavior is consistent with the DriveLock feature.

## Hood Sensor (Smart Cover Sensor) (optional)


The optional Hood Sensor is a combination of hardware and software technology that can alert you when the workstation side access panel has been removed (if the sensor has been configured in the Computer Setup (F10) Utility). The three levels of Hood Sensor protection are shown in the following table:

**Table 3-4 Hood Sensor protection levels**

Level	Setting	Description
Level 0	Disabled	Hood Sensor* is disabled (default).
Level 1	Notify User	When the workstation restarts, a message appears indicating that the workstation side access panel has been removed.
Level 2	Setup Password	When the workstation is restarted, a message appears indicating that the workstation side access panel has been removed. You must enter the setup password to continue.

\* Hood Sensor settings can be changed using the Computer Setup (F10) Utility.

## Setting the Hood Sensor protection level

1. Power on or restart the workstation.
  2. As soon as the workstation is powered on, press and hold the **F10** key until you enter the Computer Setup (F10) Utility. Press **Enter** to bypass the title screen, if necessary.
- 
-  **NOTE:** If you do not press the **F10** key at the appropriate time, you must restart the computer, and then press and hold the **F10** key again to access the Computer Setup (F10) Utility.
- 
- If you are using a PS 2 keyboard, you might see a keyboard error message. Disregard it.
- 
3. Select **Security>Smart Cover>Cover Removal Sensor**, and follow the onscreen instructions.
  4. Before exiting, select **File>Save Changes and Exit**.

## Cable lock (optional)

To prevent theft, the rear chassis panel of your workstation accommodates a keyed cable lock. This cable lock attaches to the chassis and secures it to the work area.

## Security lock (Padlock loop) (optional)

The rear chassis panel of your workstation provides a padlock loop. A padlock can be attached in this loop to prevent workstation access panel removal.

## Universal chassis clamp lock (optional)

The universal chassis clamp lock secures the access panel to the chassis using a screw-type attachment. A built in key lock prevents access to the securing screw. In addition, you can add cables to the universal chassis clamp lock to secure workstation peripherals, and to secure the workstation to the work area.

## Fault notification and recovery

Fault notification and recovery features combine innovative hardware and software technology to prevent the loss of critical data and minimize unplanned downtime.

If the workstation is connected to a network that is managed by HP CMS, the computer sends a fault notice to the network management application. With HP CMS, you can also remotely schedule diagnostics to run on managed PCs and create a summary report of failed tests.

## Drive Protection System

The Drive Protection System (DPS) is a diagnostic tool built into hard drives and is installed in select HP workstations. The DPS helps diagnose problems that might result in unwarranted hard drive replacement.

When HP workstations are built, each installed hard drive is tested using the DPS, and a permanent record of key information is written onto each drive. Every time the DPS is run, test results are written to the hard drive. The service provider can use this information to help diagnose conditions that required you to run the DPS software.

## ECC fault prediction

When the workstation encounters an excessive number of error checking and correcting (ECC) memory errors, it displays a local alert message. This message contains information about the errant memory module, enabling you to take action before you experience noncorrectable memory errors. ECC memory modules are standard on the HP xw8600 Workstation.

## Thermal sensors

Several thermal sensors in your HP Workstation regulate workstation fans to maintain an acceptable, efficient chassis temperature.

## Dual-state power button

With ACPI enabled, the power button can function as an on/off switch or as a button. This feature does not completely turn off power, but instead causes the workstation to enter a low-power standby state. This enables you to go to standby without closing applications, and to return to the same operational state without any data loss.

To change the power button configuration:

1. Select **Start**, and then select **Control Panel>Power Options**.
2. In Power Options Properties, select the **Advanced** tab.
3. In the Power Button section, select **Hibernate**.

Hibernate must be enabled in the Hibernate tab.

After configuring the power button to function as a button, you can press the power button to put the system in a very low power state. Press the button again to bring the system out of this low power state to full power state. To completely turn off power to the system, press and hold the power button for four seconds.

---

△ **CAUTION:** Do not use the power button to power off the workstation unless the system is not responding; turning off the power without operating system interaction can cause data loss.

---








---


## 4 Removal and replacement procedures

This chapter describes the removal and replacement procedures for most internal workstation components including the following topics:

- [Warnings and cautions on page 47](#)
- [Service considerations on page 48](#)
- [Customer Self-Repair on page 52](#)
- [Predisassembly procedures on page 52](#)
- [System board components on page 52](#)
- [Removing and replacing components on page 53](#)
- [Product recycling on page 112](#)

### Warnings and cautions

- 
- ⚠ **WARNING!**  Any surface or area of the equipment marked with this symbol indicates the presence of a hot surface or hot component. If this surface is contacted, the potential for injury exists. To reduce the risk of injury from a hot component, enable the surface to cool before touching.
- 
- ⚠ **WARNING!**  Any surface or area of the equipment marked with this symbol indicates the presence of an electrical shock hazard. To reduce the risk of injury from electrical shock, do not open any enclosed area marked with this symbol.
- 
- ⚠ **WARNING!** To reduce the risk of electric shock or damage to your equipment:
- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
  - Plug the power cord in a grounded (earthed) outlet that is easily accessible at all times.
  - Disconnect power from the equipment by unplugging the power cord from the electrical outlet.
- 
- ⚠ **WARNING!** To reduce the risk of serious injury, read the *Safety & Comfort Guide*. It describes proper workstation setup, posture, health, and work habits for computer users, and provides important electrical and mechanical safety information. This guide is located at <http://www.hp.com/ergo> and on the documentation CD (if one is included with the product).
- 
- ⚠ **WARNING!** If a product is shipped in packaging marked with this symbol, , the product must always be lifted by two persons to avoid personal injury due to product weight.
- 
- ⚠ **CAUTION:** Static electricity can damage the electronic components of the workstation. Before beginning these procedures, be sure you discharge static electricity by briefly touching a grounded metal object.
-

- 
- △ **CAUTION:** Observe the following cautions when removing or replacing a processor:
- Installing a processor incorrectly can damage the system board. Contact an HP authorized reseller or service provider to install the processor. If you plan to install the processor yourself, read all of the instructions carefully before you begin.
  - Failure to follow the workstation preparation instructions can result in an improperly installed processor, causing extensive workstation damage.
  - Processor socket pins are delicate and bend easily. Use extreme care when placing the processor in the socket.
- 
- △ **CAUTION:** To prevent damage to the workstation, observe the following Electrostatic Discharge (ESD) precautions while performing the system parts removal and replacement procedures:
- Work on a static-free mat.
  - Wear a static strap to ensure that any accumulated electrostatic charge is discharged from your body to the ground.
  - Create a common ground for the equipment you are working on by connecting the static-free mat, static strap, and peripheral units to that piece of equipment.
- 
-  **NOTE:** HP accessories are for use in HP Workstation products. They have been extensively tested for reliability and are manufactured to high quality standards.
- 

## Service considerations

The following sections describe service considerations that you should review and practice before removing and replacing system components.

- 
- △ **WARNING!** Do not use the front bezel as a handle or lifting point when lifting or moving the workstation. Lifting the workstation from the front bezel, or lifting it incorrectly, could cause the workstation to fall, causing possible injury to you and damage to the workstation. To properly and safely lift the workstation, use the handles. If your workstation is not equipped with handles, lift from the bottom of the workstation.
- 

## Cautions, warnings, and safety precautions

For your safety, review the cautions, warnings, and safety precautions before accessing the workstation components. Also, review the *Safety and Regulatory Guide* that came with your workstation for more information.

## ESD information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often, the discharge is neither felt nor heard, but damage occurs nonetheless. An electronic device exposed to ESD might not appear to be affected at all and can function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.

Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.

## Generating static

The following table shows that different activities generate different amounts of static electricity. Static electricity increases as humidity decreases.

**Table 4-1 Static electricity**

Event	Relative humidity		
	55%	40%	10%
Walking across carpet	7,500V	15,000V	35,000V
Walking across vinyl floor	3,000V	5,000V	12,000V
Motions of bench worker	400V	800V	6,000V
Removing bubble pack from PCB	7,000V	20,000V	26,500V
Packing PCBs in foam-lined box	5,000V	11,000V	21,000V

**CAUTION:** 700 volts can degrade a product.

## Preventing ESD equipment damage

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity. The following packaging and grounding precautions are necessary to prevent damage to electric components and accessories:

- Transport products in static-safe containers such as tubes, bags, or boxes, to avoid hand contact.
- Protect electrostatic parts and assemblies with nonconductive or approved containers or packaging.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from containers.
- When handling or touching a sensitive component or assembly, ground yourself by touching the chassis.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or nonconductive foam.

## Personal grounding methods and equipment

Use the following items to help prevent ESD damage to equipment:

- **Wrist straps**—These are flexible straps with a maximum of one megohm  $\pm$  10% resistance in the ground cords. To provide a proper ground, wear the strap against bare skin. The ground cord must be connected and fit snugly into the banana plug connector on the grounding mat or workstation.
- **Heel straps, toe straps, and boot straps**—These can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of one megohm  $\pm$  10% resistance between the operator and ground.

The following table shows protection levels available from static shielding materials.

**Table 4-2 Static shielding protection levels**

Method	Voltage
Antistatic plastic	1,500V
Carbon-loaded plastic	7,500V

**Table 4-2 Static shielding protection levels (continued)**

Method	Voltage
Metallized laminate	15,000V

## Grounding the work area

To prevent static damage in your work area:

- Cover the work surface with approved static-dissipative material. Use a wrist strap connected to the work surface, and properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic-sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only in static-free work areas.
- Disconnect power and input signals before inserting and removing connectors or test equipment.
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.
- Keep work area free of nonconductive materials, such as plastic assembly aids and Styrofoam.
- Use field service tools (such as cutters, screwdrivers, and vacuums) that are conductive.

## Recommended ESD prevention materials and equipment

Materials and equipment that are recommended for use in preventing static electricity include:

- Antistatic tape
- Antistatic smocks, aprons, and sleeve protectors
- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with a ground cord of one megohm  $\pm$  10% resistance
- Static-dissipative table or floor mats with a hard-tie to ground
- Field service kits
- Static awareness labels
- Wrist straps and footwear straps providing one megohm  $\pm$  10% resistance
- Material-handling packages
- Conductive plastic bags
- Conductive plastic tubes
- Conductive tote boxes
- Opaque shielding bags
- Transparent metallized shielding bags
- Transparent shielding tubes

## Tools and software requirements

- Torx T-15 driver
- Flat blade and cross-tip screwdrivers
- Diagnostics software

## Special handling of components

The components included in this section require special handling when servicing the workstation.

- ⚠ **WARNING!** Do not use the front bezel as a handle or lifting point when lifting or moving the workstation. Lifting the workstation from the front bezel, or lifting it incorrectly, could cause the workstation to fall, causing possible injury to you and damage to the workstation. To properly and safely lift the workstation, lift from the bottom of the workstation.
- 

## Cables and connectors

Handle cables with care to avoid damage. Apply only the tension required to seat or unseat cables during insertion or removal from the connector. When possible, handle cables by the connector or pull-strap. In all cases, avoid bending or twisting the cables, and be sure that the cables are routed in such a way that they cannot be caught or snagged by parts being removed or replaced.

When servicing the workstation, be sure that cables are placed in their proper location during the reassembly process. Improper cable placement can damage the workstation.

## Hard drives

Hard drives are fragile, precision components. Avoid subjecting them to physical shock and vibration. The following guidelines apply to all drives, including failed drives, replacement drives, and spares.

- Do not remove hard drives from the shipping package for storage. Keep hard drives in their protective packaging until they are mounted in the workstation.
- Avoid dropping hard drives from any height.
- If you are inserting or removing a hard drive, power off the workstation. Do not remove a hard drive while the workstation is powered on or in standby mode.
- Before handling a drive, be sure that you discharge static electricity. While handling a drive, avoid touching the connector. For more information about preventing electrostatic damage, see [ESD information on page 48](#).

To prevent possible ESD damage when the drive is installed, connect the drive power cable before connecting the data cable. This discharges accumulated static electricity through the drive power cable to the workstation chassis.

- When inserting a drive, do not use excessive force.
- Avoid exposing a hard drive to liquids, temperature extremes, or products with magnetic fields such as monitors or speakers.

## Lithium coin cell battery

The battery included with the workstation provides power to the real-time clock and has a lifetime of about three years.

For instructions on battery removal and replacement, see [Battery on page 96](#).

⚠ **WARNING!** This workstation contains a lithium battery. There is a risk of fire and chemical burn if the battery is handled improperly. Do not disassemble, crush, puncture, short the external contacts, dispose of in water or fire, or expose the battery to temperatures higher than 60° Centigrade (140° Fahrenheit).

📝 **NOTE:** Do not dispose of batteries, battery packs, and accumulators with general household waste.

## Customer Self-Repair

Customer Self-Repair enables you to obtain replacement parts and install them on the workstation. For more information, see <http://www.hp.com/go/selfrepair/>.

## Predisassembly procedures


Perform the following steps before servicing a workstation:

1. Close all open software applications.
2. Remove all diskettes, CDs, and DVDs from the workstation.
3. Shut down the operating system.
4. Power off the workstation and all peripheral devices connected to it.
5. Remove or disengage security devices that prevent you from opening the workstation.
6. Disconnect the power cord from the electrical outlet and then from the workstation.
7. Disconnect peripheral device cables from the workstation.

## System board components

The following figure shows the system board connectors and sockets on the HP xw8600 Workstation.

**Figure 4-1** System board component identification



**Table 4-3 System board components**

Item	Component	Item	Component	Item	Component
1	Memory fan connector	15	SAS connectors	29	PCI Express x8 (4) slot**
2	Main power connector	16	Front USB connector	30	PCI Express x16 GEN2 slot*
3	Memory card sockets	17	Battery	31	PCI 32/33 slot
4	Primary processor (XU1)	18	HDD activity LED connector	32	Rear chassis fan connector
5	Processor power connector	19	Front control panel connector	33	Audio jacks
6	Primary processor (XU1) fan power	20	Internal USB connector	34	Memory power connector
7	Second processor (XU2)	21	Crisis recovery jumper	35	Network (ASF)/USB
8	Second processor (XU2) fan power	22	Front 1394 connector	36	Network and USB
9	Diskette drive connector	23	Front audio connector	37	1394 connector
10	IDE (PATA) connector	24	Auxiliary audio connector	38	Serial connector
11	Clear CMOS button	25	PCI-X 133 slot	39	USB connector
12	SATA connectors	26	PCI Express x8 (4) slot**	40	Keyboard/mouse connector
13	Password jumper	27	PCI Express x8 (1,8) (GEN2 for x8) slot**		
14	Front chassis fan connector	28	PCI Express x16 (16,8) GEN2 slot		

\* Electrically x16 bandwidth

\*\* Open-ended slot that allows installation of x16 card.

For related system architecture information, see [System board architecture on page 2](#).

## Removing and replacing components

This section provides procedures to remove and install hardware components on your workstation.

1. Before servicing your workstation, review the safety information and precautions in [Service considerations on page 48](#) and the *Safety and Regulatory Information* for your workstation.
2. Locate and clear a suitable work area.
3. Power down the workstation and disconnect power from the workstation.
4. Gather your tools.
5. Service the workstation.
6. Restore power to the workstation.

## Disassembly order

Use the following table to determine the sequence in which to remove major workstation components.

**Table 4-4 Workstation component disassembly order**

Predisassembly ( <a href="#">Predisassembly procedures on page 52</a> )
Security lock ( <a href="#">Security lock (Padlock loop) (optional) on page 55</a> )
Cable lock ( <a href="#">Cable lock (optional) on page 55</a> )
Universal chassis clamp lock ( <a href="#">Universal chassis clamp lock (optional) on page 56</a> )
Side access panel ( <a href="#">Side access panel on page 57</a> )
Hood Sensor ( <a href="#">Hood Sensor (Smart Cover Sensor) (optional) on page 58</a> )
Front bezel ( <a href="#">Front bezel on page 59</a> )
Bezel blanks ( <a href="#">Bezel blanks on page 60</a> )
Front panel I/O device assembly ( <a href="#">Front panel I/O device assembly on page 61</a> )
Power button assembly ( <a href="#">Power button assembly on page 63</a> )
Optical drives ( <a href="#">Optical drive on page 64</a> )
System speaker ( <a href="#">System speaker on page 68</a> )
Power supply ( <a href="#">Power supply on page 69</a> )
System fan ( <a href="#">System and memory fan assembly on page 71</a> )
Memory ( <a href="#">Memory on page 72</a> )
SAS rear panel cable ( <a href="#">SAS rear panel cable (optional) on page 86</a> )
PCI card support ( <a href="#">PCI card support on page 90</a> )
PCI Express card ( <a href="#">PCI Express cards on page 92</a> )
PCI card ( <a href="#">PCI card on page 95</a> )
Battery ( <a href="#">Battery on page 96</a> )
Hard drives ( <a href="#">SAS hard drive on page 97</a> ), <a href="#">SATA hard drive on page 101</a> )
Processor heatsink ( <a href="#">Processor heatsink on page 106</a> )



**Table 4-4 Workstation component disassembly order (continued)**

Processor ( <a href="#">System processor on page 108</a> )
System board ( <a href="#">System board on page 110</a> )

## Security lock (Padlock loop) (optional)

If a security padlock is installed on your workstation, remove it before servicing the workstation.

### Removing the security lock

To remove the padlock, unlock it and slide it out of the padlock loop as shown in the following figure.

**Figure 4-2** Removing the security lock



## Cable lock (optional)

If a cable lock is installed on your workstation, remove it before servicing the workstation.

## Removing the cable lock

To remove the cable lock, unlock it and pull it out of the cable lock slot as shown in the following figure.

**Figure 4-3** Removing the cable lock



## Universal chassis clamp lock (optional)

If a universal chassis clamp lock is installed on your workstation, remove it before servicing the workstation.

## Removing the chassis clamp lock

To remove the lock:

1. Unlock the device and remove the locking mechanism as shown in the following figure.

**Figure 4-4** Unlocking the device



2. Remove the screw attaching the lock to the chassis as shown in the following figure.

**Figure 4-5** Removing the lock screws



## Side access panel

Before accessing the internal components of the workstation, you must remove the side access panel.

This section describes how to remove and replace the side access panel.

### Removing the side access panel

To remove the side access panel:

⚠ **WARNING!** Before removing the workstation side access panel, be sure that the workstation is powered off and that the power cord is disconnected from the electrical outlet.

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Unlock locks that are present (such as security lock, cable lock, or universal chassis clamp lock).

3. Pull up on the handle and rotate the cover off the chassis as shown in the following figure.

**Figure 4-6** Removing the access panel



### Replacing the side access panel

To replace the side access panel:

1. Align the bottom groove of the side panel with the bottom edge of the chassis.
2. Rotate the side panel toward the chassis and press firmly until the latch engages.

### Hood Sensor (Smart Cover Sensor) (optional)

This section describes how to remove the Hood Sensor.


#### Removing the Hood Sensor

To remove the Hood Sensor:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Disconnect the hood sensor connector from the inline connector attached to the front panel harness.


4. Slide the hood sensor forward, push the hood sensor down, and then remove it from the chassis (1) as shown in the following figure.

**Figure 4-7** Removing the Hood Sensor



5. If desired, remove the hood sensor bracket, remove the two hood sensor bracket screws, and then remove the bracket and sensor as a unit (2).

---

 **NOTE:** To replace the Hood Sensor, reverse the previous steps.

---

## Front bezel


This section describes how to remove and replace the front bezel.

## Removing the front bezel

To remove the front bezel:

1. Lift the three release snaps located on the front bezel (1) as shown in the following figure.

**Figure 4-8** Removing the front bezel



2. Rotate the front bezel away from the chassis to remove the bezel (2).

## Replacing the front bezel

To replace the front bezel, align the bezel hooks with the chassis holes, and then rotate in until it snaps into place.

## Bezel blanks

This section describes how to remove bezel blanks


### Removing bezel blanks

To remove bezel blanks:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the front bezel (see [Removing the front bezel on page 60](#)).

3. Gently squeeze in on the tabs (1), and push the bezel blanks out of the front bezel (2) as shown in the following figure.

**Figure 4-9** Removing the bezel blanks



A bezel blank has a hook on both sides. It is symmetric and can be installed upside down without issue. To replace a blank, align its hook on one side with the slot in the bezel, then rotate it until it snaps into place.

## Front panel I/O device assembly

This section describes how to remove and install a front panel I/O device assembly.


### Removing the front panel I/O device assembly

To remove the front panel I/O device assembly:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#) ).
2. Remove the side access panel (see [Removing the side access panel on page 57](#) ).
3. Remove the front bezel (see [Removing the front bezel on page 60](#) ).


4. Unlatch the plastic snap that secures the cables inside the chassis (1) as shown in the following figure.


**Figure 4-10** Removing front panel I/O device cables



5. Disconnect the front panel I/O device assembly cables from the system board (2).
6. Using the following figure, remove the three smaller Torx screws that hold the front panel I/O device assembly and bracket to the chassis (1).

**Figure 4-11** Removing the front panel I/O device assembly



 **NOTE:** Although not required, you can separate the mounting bracket from the front panel I/O device assembly by removing the two larger Torx screws (2).

7. Pull the front panel I/O device assembly out about two inches from the chassis.
8. Pull the front panel cables through the chassis and through the front of the workstation.  
You might need to slide the cables out one at a time.




## Installing the front panel I/O device assembly

To instal the front panel I/O device assembly:

1. Thread each front panel I/O device assembly cable through the same holes from which they were removed.
2. Push the front panel I/O device assembly into the chassis. Using your fingers, orient the cables so there is enough room for the front panel I/O device assembly to easily fit in its slot.
3. Loosely place the bracket on the front panel I/O device assembly and hook the bracket to the chassis.
4. If the bracket was removed, screw the bracket to the front panel I/O device assembly, and then screw the bracket to the chassis.
5. Using the following figure, complete the following:
  - a. Connect the front audio cable to the audio connector (1).
  - b. Connect the front 1394 cable to the control panel connector (2).
  - c. Connect the front USB cable to the USB connector (3).

**Figure 4-12** Attaching the front panel I/O device assembly cables



## Power button assembly

This section describes how to remove the power button assembly.


### Removing the power button assembly

To remove the power button assembly:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Remove the front bezel (see [Removing the front bezel on page 60](#)).
4. Remove the three screws from the front panel I/O device assembly and pull it slightly out from the chassis (see [Removing the front panel I/O device assembly on page 61](#)).


5. Disconnect the power button assembly cable from the system board as shown in the following figure.

**Figure 4-13** Removing the power button assembly cable



6. Disconnect the speaker wire and the hood sensor from the in-line connectors on the power button assembly cable.
7. Remove the screw that secures the power button assembly to the chassis (1) as shown in the following figure.

**Figure 4-14** Removing the power button assembly



8. Pull the power button assembly away from the front of the chassis, and then rotate the assembly out from the front of the chassis (2).

To replace the power button assembly, reverse the previous steps.


## Optical drive

This section describes how to remove and install an optical disk drive.

## Removing an optical drive


1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
  2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
- △ **CAUTION:** To prevent damage to the workstation, observe the following Electrostatic Discharge (ESD) precautions while performing the system parts removal and replacement procedures:
- Work on a static-free mat.
  - Wear a static strap to ensure that any accumulated electrostatic charge is discharged from your body to the ground.
  - Create a common ground for the equipment you are working on by connecting the static-free mat, static strap, and peripheral units to that piece of equipment.
3. Remove the front bezel (see [Removing the front bezel on page 60](#)).
  4. Disconnect the data (1) and power (2) cables from the optical drive as shown in the following figure.

**Figure 4-15** Disconnecting the optical drive cables



5. Lift the green drive-lock release lever (1) and gently slide the drive out of the chassis (2) as shown in the following figure.

**Figure 4-16** Removing the optical drive from the chassis




6. If you are not installing another optical drive, add a bezel blank filler to the front bezel, and an EMI filler to the optical drive slot.


## Installing an optical drive

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
  2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
  3. Remove the front bezel (see [Removing the front bezel on page 60](#)).
  4. If you are adding an additional drive, remove the blank filler and the EMI filler.
  5. Lift the green drivelock release lever while sliding the optical drive into the bay. When the optical drive is partially inserted, release the drivelock release lever and slide the drive completely into the bay until the drive is secured.
- 
- △ **CAUTION:** Verify that the optical drive is secure in the workstation chassis by pulling on the drive to see if it can be easily disengaged. Failure to properly secure the drive can damage the drive when moving the workstation.
- 
6. Replace the workstation front bezel.

7. Connect the power and data cables to the drive and system board as shown in the following figure.

**Figure 4-17** Connecting the optical drive cables



 **NOTE:** The HP xw8600 Workstation BIOS Configuration Mode can be set to affect optical and hard drives. The workstation is set to RAID+AHCI at shipment.

The following constraints apply when the Configuration Mode is set to:

**Separate IDE controller**—Only SATA ports 0, 1, 2, 3 are available.


**Combined IDE controller**—Only SATA ports 0, 1, 2, and 3 are available.

**RAID + AHCI**—System BIOS cannot be updated from the optical drive. In this mode, the option ROM might not allow certain DOS drive letter access at this time.

Other than the reduction of available SATA ports, there are no limitations if your workstation is running in IDE mode.

8. For multiple optical drives, the following figure shows how to route the data cables.

**Figure 4-18** Routing the optical drive cables



## System speaker

This section describes how to remove the system speaker.


### Removing the system speaker

To remove the system speaker:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Disconnect the speaker cable from the inline front panel I/O device assembly cable.

4. Slide the speaker away from the three chassis flanges and remove it from the chassis as shown in the following figure.

**Figure 4-19** Removing the system speaker



To replace the speaker, reverse the previous steps.

## Power supply


This section describes how to remove the power supply.

### Removing the power supply

To remove the power supply:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. If your workstation includes a memory riser, remove it from the chassis (see [Removing a memory riser assembly on page 78](#)).
4. If your workstation is equipped with high performance heatsinks, they must be removed before you can remove the power supply. Follow the instructions in the [Removing the processor heatsink on page 106](#) section to remove the high performance heatsinks.
5. To ease installation of the power supply, write down the numbers on the cables so you can easily reconnect the cables to the correct devices.
6. Disconnect power supply cables from the system board, drives, and cards.


---

 **TIP:** If your workstation does not include a memory riser, lift the memory fan to disconnect the memory power connector on the motherboard.

---

7. Remove the four screws from the back panel (1) as shown in the following figure.

**Figure 4-20** Removing the power supply



8. Slide the power supply toward the front of the chassis, and then lift it out of the chassis (2).

### Installing the power supply

To replace the power supply, reverse the steps in the previous section.


If you have removed high performance processor heatsinks, follow the instructions in the [Installing the processor heatsink on page 107](#) section to reinstall the heatsinks.



## Power connections to system components

For help with identifying power cables, see the following figure and table. Ensure that all cables are routed or tied so they cannot interfere with the processor heatsink fans.

**Figure 4-21** Identifying the workstation power connectors for a typical configuration



**Table 4-5** Workstation power connector description

Item	Description	Item	Description
A	Power supply	I	Optical drive
B	Main power	J	Optical drive
C	Memory power	K	Diskette drive
D	Processor power	L	Hard drive
E	PCI Express auxiliary power	M	Hard drive
F	PCI Express auxiliary power	N	Hard drive
G	Memory riser*	O	Hard drive
H	Optical drive	P	Hard drive

\* This connector is included only on workstations with the 1050-watt power supply.

## System and memory fan assembly


This section describes how to remove the system and memory fan assembly.

## Removing the system and memory fan assembly

To remove the system and memory fan assembly:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Disconnect the system fan (1) and the memory fan (2) wire connectors from the system board as shown in the following figure.

**Figure 4-22** Removing the system and memory fan assembly



4. Press the green tab at the base of the memory fan and lift it up (3).
5. Press down on the ribbed portion of the system fan housing (4), rotate the fan housing down, and lift the assembly out of the chassis.

To install the system fan assembly, reverse these steps.

## Memory

This section presents memory configuration information and removal/installation procedures.

### Memory general information

This section describes supported memory modules and configurations.

#### System board memory module requirements

- Install only HP approved, Fully Buffered DIMMs.
- △ **CAUTION:** HP only ships DIMMs that are electrically and thermally compatible with this workstation. Because third-party DIMMs might not be electrically or thermally compatible, they are not supported by HP.
- DIMMs and their sockets are keyed for proper installation. Ensure these guides line up when installing DIMMs.

- If multiple DIMMs are installed in a workstation, install them in pairs of the same rank, DRAM technology, speed and capacity in each channel.
- DDR2-667 and DDR2-800 DIMMs cannot be mixed in the same system.

### DDR2-667 Fully Buffered DIMM support

The HP xw8600 Workstation supports the following DDR2-667 Fully Buffered DIMMs:

- Double Data Rate 2-667 MHz (DDR2-667), Fully Buffered DIMMs (FBD)
- PC2-5300F FBD, Error Checking and Correcting (ECC) (72-bit ECC)
- 512-MB, 1-GB, 2-GB, 4-GB and 8-GB DIMMs
- Cannot be used with 1600-MHz Front Side Bus (FSB) processors
- Cannot be intermixed with DDR2-800 Fully Buffered DIMMs



**NOTE:** The 8-GB DDR2-667 DIMM is not supported on the system board.

### DDR2-800 Fully Buffered DIMM support

The HP xw8600 Workstation supports the following DDR2-800 Fully Buffered DIMMs:

- Double Data Rate 2-800 MHz (DDR2-800), Fully Buffered DIMMs (FBD)
- PC2-6400F FBD, Error Checking and Correcting (ECC) (72-bit ECC)
- 1-GB, 2-GB, and 4-GB DIMMs
- Must be used only with 1600-MHz Front Sided Bus (FSB) processors
- Cannot be intermixed with DDR2-667 Fully Buffered DIMMs



**NOTE:** The 4-GB DDR2-800 DIMM is not supported on the system board.

### Supported system board DIMM configurations

The HP xw8600 Workstation supports the following Dual Inline Memory Module (DIMM) configurations on the system board:

- Eight DIMM slots
- Configurable for Single Channel (one DIMM), Dual Channel (two DIMMs), or Quad Channel (sets of four DIMMs)
- No support for mirroring
- No support for DIMM sparing

### Supported memory riser DIMM configurations

The HP xw8600 Workstation supports the following memory module configurations with memory risers:

- Four memory riser cards with four slots each (maximum of 16 DIMMs)
- Loaded in pairs only
- No support for mirroring
- No support for DIMM sparing

Further details on supported memory module configurations are given in the following sections.

## BIOS errors and warnings

The BIOS generates warnings/errors on invalid memory configurations:

- If the BIOS can find a valid memory configuration by disabling plugged-in memory, it does so and reports a warning during POST. The system can still be booted. The warning will indicate the location of the failed DIMM on the system board or memory riser.
- If there is no way for the BIOS to obtain a valid memory configuration by disabling plugged-in memory, the BIOS halts with a diagnostics 2006 code for memory error (five beeps and blinks).

## System board memory


This section presents system board memory information, including removal and installation procedures.

### Removing a memory module

This section describes how to remove a system board memory module.


1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
  2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
- 
- △ **CAUTION:** To ensure that memory modules are not damaged during removal or installation, power off the workstation and unplug the power cord from the AC power outlet. If you do not unplug the power cord before installing memory, the modules might be damaged and the system will not recognize the memory changes.
- 
3. Press the green tab at the base of the memory fan (1) and lift it up to expose the memory modules (2) as shown in the following figure.

**Figure 4-23** Rotating the memory fan



4. Push gently outward on the socket levers (1) as shown in the following figure.

**Figure 4-24** Removing a memory module



5. Lift the DIMM straight up and out of the socket (2), then store the DIMM in an antistatic bag.

### Installing a memory module

This section presents system board memory module installation information.

#### DIM slot identification

The following illustration identifies the system board memory slots:

**Figure 4-25** Identifying DIMM slots




#### Required system board DIMM installation order


Use the figure below as a guide for installing memory:

- If installing only one DIMM, install it in socket 1.
- If installing only two DIMMs, install them in socket pair: 1/5.

- If installing four DIMMs, install them in socket pairs: 1/3 and 5/7.
- If installing six DIMMs, install them in socket pairs: 1/3, 5/7, and 2/4.
- If installing eight DIMMs, install them in socket pairs: 1/3, 5/7, 2/4, and 6/8.

Each pair must be matched in rank, DRAM technology, speed, and capacity.

 **NOTE:** If adding DIMMs to a system that originally contained only two DIMMs, move the DIMM from socket five to socket three to maintain proper pairing.


 **TIP:** For best performance, load the largest DIMM pairs in the black slots.

## Installing a system board memory module

To install a memory module:


1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Press the green tab at the base of the memory fan (1) and lift it up to expose the memory modules (2) as shown in the following figure.

**Figure 4-26** Rotating the memory fan




4. Push gently outward on the socket levers as shown in the following figure.


**Figure 4-27** Opening the DIMM socket levers




5. Align the DIMM connector key with the DIMM socket key, and then seat the DIMM firmly in the socket (1) as shown in the following figure.

 **NOTE:** Note the keyed slot about midway across the bottom of the DIMM in the figure below.

**Figure 4-28** Installing a memory module



6. Secure the socket levers (2).
7. Lower the memory fan until it snaps into place.

 **NOTE:** Ensure that all cables are clear of the fan housing when you lower the fan.

## Memory riser assembly

This section presents configuration and removal/installation information for the memory riser assembly.




## Removing a memory riser assembly

The following steps describe how to remove a memory riser assembly.


1. Remove the memory duct assembly by loosening the assembly thumb screws (1), and then removing the assembly from the chassis (2) as shown in the following figure.

**Figure 4-29** Removing the memory duct assembly




2. Disconnect the memory card power cable from the power connector on each memory card as shown in the following figure.

---

 **TIP:** Push in on the latch, and then pull up on the connector.

---

**Figure 4-30** Disconnecting the riser card power cables




3. Remove the memory riser cards from the card cage by grasping each card at its corners and pulling straight up.

There is no need to unlatch the system board connectors when removing the riser cards.




4. Pull up on the card guide to remove it from the chassis as shown in the following figure.

**Figure 4-31** Removing the riser card guide



5. Disconnect the memory riser cable from power supply cable P18 as shown in the following figure.

**Figure 4-32** Disconnecting the memory riser cable from the power supply cable




### Installing a memory riser assembly

### Memory riser DIMM installation order


DIMMs can be added to memory risers on the HP xw8600 Workstation in this manner:

- DIMMS must be added in pairs, in the order shown in the figure below.

**Figure 4-33** Memory riser DIMM installation order




- Each pair must be matched in rank, DRAM technology, speed, and capacity.

 **TIP:** For best performance, load the largest capacity DIMM pairs closest to the system board.

### Installing a memory riser assembly and DIMMs

The following steps describe how to install memory riser DIMMs and a memory riser assembly.


- △ **CAUTION:** To use a memory riser assembly, your workstation must be equipped with a 1050W power supply and two high performance processor heatsinks.

 **NOTE:** All four memory risers must be present with card cage and memory duct assembly properly installed during operation.

---


1. Connect the memory riser cable to power supply cable P18 as shown in the following figure.

**Figure 4-34** Connecting the memory riser cable to the power supply cable




2. Open all memory slot latches as shown in the following figure.

**Figure 4-35** Opening the memory slot latches




3. Install the memory riser card guide into memory slots 2, 4, 6, and 8 in the workstation chassis. Align the card guide, and then press it securely into the slots as shown in the following figure.

**Figure 4-36** Installing the riser card guide



4. Install the memory DIMMs in the memory riser cards as shown in the following figure. Begin installing DIMMs in the lower-most slots, nearest the system board.


**Figure 4-37** Installing DIMMs in the memory riser board



5. To assure proper airflow to the DIMMs, install blank memory riser fillers in all unused slots on the riser board.


6. Install the loaded memory riser cards in the riser card cage as shown in the following figure.

**Figure 4-38** Installing memory riser cards in the card cage




7. Install the memory riser card power cable by connecting each memory card power cable connector into the power connector on a memory card as shown.

**Figure 4-39** Installing the riser card power cable




8. Insert the memory riser card power cable into the notch on the riser card guide as shown in the following figure.

**Figure 4-40** Inserting the riser card cable into card the guide notch



9. As shown in the following figure, install the memory fan/duct assembly by placing the rear of the assembly under the chassis lip, lowering it into the chassis (1), and then securing the assembly thumbscrews (2).


**Figure 4-41** Installing the memory fan duct assembly



## PCI card slots

The following figure illustrates the xw8600 Workstation PCI card slots.

**Figure 4-42** Identifying PCI card slots



**Table 4-6** PCI slots

Slot	Type	Slot power (Maximum)
1	PCI 32/33	25W
2	PCI Express x16 GEN2*	75W
3	PCI Express x8 (x4)	25W
4	PCI Express x16 (x16, x8) GEN2**	75W
5	PCI Express x8 (1), Gen2 x8 (8)	25W
6	PCI Express x8 (x4)	25W
7	PCI-X 133	25W

\* Primary graphics slot

\*\* Secondary graphics slot

△ **CAUTION:** To prevent damage, the overall power consumption of the system (including I/O cards, processor, and memory) must not exceed the maximum rating of the system power supply. For power supply information, refer to [Power supply specifications on page 8](#).

Slots three, five, and six use open-ended PCI Express connectors, so a PCI Express x16 card can be plugged into them.

An x16 graphics card runs at the bandwidth (x1, x4, or x8) of the slot it is plugged into.

Graphics cards greater than 75 watts require the use of a graphics cable adapter.



## Slot lane redirection

The workstation BIOS enables you to determine lane allocation for slots four and five. In the F10 (Setup) Utility, under Advanced>Chipset/Memory>PCIe Lane Allocation, you can select these lane allocations for slots four and five:

- Auto—Automatic mode selection
- x16:x1—Slot 4 runs in x16 mode and slot 5 runs in x1 mode
- x8:x8—Slot 4 runs in x8 mode and slot 5 runs in x8 mode

This feature offers optimum throughput automatically to your cards. For automatic lane reallocation, select Auto.

When this option is selected, the workstation automatically re-allocates eight lanes from slot four to slot five when a PCI-Express card less than x16 is inserted in slot four.

Inserting an x16 card in Slot four configures Slot four to an x16 mode, and Slot five to an x1 mode

To review the specific BIOS selections, refer to the Advanced and Device Options settings in [The Computer Setup \(F10\) Utility menu on page 25](#).

## Card configuration restrictions for power supplies

- △ **CAUTION:** To prevent damage, the overall power consumption of the system (including I/O cards, processor, and memory) must not exceed the maximum rating of the system power supply. For power supply information, see [Power supply specifications on page 8](#).

The maximum graphics configuration with an 800W power supply can include two 75-watt cards (one in slot two, one in slot four), or one 175-watt card in slot two or slot four.

If a graphics card greater than 75 watts is used, leave the adjacent slot empty and follow any additional workstation configuration restrictions.

The maximum graphics configuration with a 1050W power supply can include up to two 175-watt cards in slots two and four.

If a graphics card greater than 75 watts is used, leave the adjacent slot empty. The maximum graphics power is dependent on processor and memory selections. Follow any additional workstation configuration restrictions.

## SAS rear panel cable (optional)

This section describes how to install a SAS rear panel cable and the optional mounting bracket in your workstation.

Refer to <http://www.hp.com/accessories/workstations> for information on approved, compatible cards.

## Installing the SAS rear panel cable


To install the SAS rear panel cable:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).




3. Locate the SAS connectors by reviewing the system board layout illustration on the service label of your workstation access panel as shown next.


**Figure 4-43** System board components



4. Attach the SAS cables of the SAS rear panel cable assembly to the SAS connectors (1) on the system board as shown in the following figure.

 **NOTE:** If all four connectors are not available because you already have SAS devices installed, connect the cable assembly to the remaining free connectors. Bandwidth will be proportional to the number of connectors attached.


**Figure 4-44** Attaching SAS rear panel cables



5. Place the tab of the MiniSAS 4X connector into the chassis slot, and then use a mounting screw (2) to attach the connector to the rear of the chassis.

6. Adhere the external SAS label to the outside of the chassis near the connector as shown next.


**Figure 4-45** Attaching the label



### Installing the optional SAS mounting bracket


1. Depress the PCI retention clamp clips and lift the retention clamp (1). Remove the PCI slot cover from PCI slot one (2) as shown in the following figure.

**Figure 4-46** Removing the slot cover




2. Place the tab of the MiniSAS 4X connector into the mounting bracket slot, and then attach the connector to the SAS mounting bracket as shown in the following figure.

**Figure 4-47** Attaching the connector to the bracket



3. Install the SAS mounting bracket in slot one of the workstation (1) as shown below.  
Connect the SAS cables to the SAS connectors on the system board (2), or to an approved, compatible plug in card.

**Figure 4-48** Installing the bracket and the cables



4. Adhere the external SAS label to the outside of the SAS mounting bracket as shown in the figure below.

**Figure 4-49** Attaching the label



## PCI card support

To prevent card movement during shipping, a PCI card support is installed.


### Removing a PCI card support

To remove a PCI card support:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).

3. For short or tall cards, lift the PCI support arm (1) with one hand and press in on the support sides (2) as shown in the following figure.

**Figure 4-50** Removing a PCI card support



4. Rotate the support out of the chassis (3).


### Installing a PCI card support

To install the PCI card support:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).

3. For short or tall PCI cards, attach the hooks of the PCI support in the slots on the rear of the chassis (1) as shown in the following figure.

**Figure 4-51** Installing a PCI card support bracket



4. Rotate the card support down until the support arm supports the card (2).

## PCI Express cards

PCI Express I/O slots can support other PCI Express cards with less bus bandwidth than what is physically defined for the slot. Use the following table to determine PCI Express card compatibility.

**Table 4-7 HP xw8600 Workstation PCI Express compatibility matrix**

Slot	Mechanical compatibility	Electrical compatibility
<b>Slots 2 and 4</b>	x1, x4, x8, x16 cards	x1, x4, x8, x16 modes
<b>Slots 3 and 6</b>	x1, x4, x8 and x16 cards	x1, x4 modes
Slot 5*	x1, x4, x8, x16 cards	x1, x4, x8

\* The x4 and x8 electrical compatibility modes apply to slot five only if it is set up as an x8 slot.

When configured as x8, slots two, four, and five are PCIe GEN2 slots.

A PCI Express x8 slot is open ended, so a PCI Express x16 card can be plugged into it.

Graphics cards greater than 75 watts require the use of a graphics cable adapter.


## Removing a PCI Express card

To remove a PCI Express card:


1. Disconnect power from the system (see [Predisasassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Remove the PCI card support (see [PCI card support on page 90](#)).
4. Remove any cables connected to the PCI Express card.

5. Open the PCI card retention clamp. Press the retention clamp levers down to unsnap, and then rotate them up (1) as shown in the following figure.

**Figure 4-52** Removing a PCI Express card



6. If you are removing a PCI Express high performance graphics card from slot two or four, perform the following steps:
  - a. Disconnect the auxiliary power cable (not illustrated).
  - b. Press in on the card slot release lever (2) to release the card.
  - c. Lift the card out of the chassis (3).
  - d. Store the card in an antistatic bag.

 **TIP:** When removing a long card, lift it slightly out of connector, then release the card guide latch at the front.

7. If you are removing a PCI Express card without a release lever, lift the card out of the slot.
8. Install a PCI slot cover and close the PCI retention clamp.

If the PCI retention clamp levers do not close, ensure that all cards are properly seated, and then try again.

## Installing a PCI Express card

△ **CAUTION:** To prevent overheating, your HP xw8600 Workstation might need a front PCI fan if:

- your workstation includes dual high performance\* graphics cards.
- your workstation includes a single high performance graphics card and an adjacent IO card that is located near the inlet of the high performance graphics card fan.

If your HP xw8600 Workstation includes dual high performance graphics cards and lacks a front PCI fan, the BIOS detects an illegal cooling configuration at boot up and reports that the front PCI fan is missing.


Visit <http://www.hp.com/go/quickspecs> to learn which graphics cards are supported in your workstation, how much memory each graphics card includes, and graphics card power requirements.

\* Graphics cards that have greater than 512 MB of video memory

To install a PCI Express card:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Remove the PCI card support (see [PCI card support on page 90](#)), if installed.
4. Open the PCI card retention clamp by pressing the retention clamp levers down to unsnap, and then rotating them up (1) as shown in the following figure.

**Figure 4-53** Installing a PCI Express card



5. Remove the PCI slot cover (2).
6. Align the PCI card keyway with the slot key, and then firmly seat the card in the slot (3).  
If required by the card, connect the auxiliary power cable to the card (not illustrated).
7. Close the PCI card retention clamp by rotating the clamp downward and pressing the two green clamp levers from the rear panel of the chassis (4).  
If the PCI retention clamp levers do not close, ensure that all cards are properly seated, and then try again.



## PCI card


This section describes removing and installing a PCI card.

### Removing a PCI card

To remove a PCI card:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Remove the PCI card support bracket (see [PCI card support on page 90](#)).
4. Remove cables connected to the PCI card.
5. Open the PCI card retention clamp by pressing the retention clamp levers down to unsnap, and then rotating them up (1) as shown in the following figure.

**Figure 4-54** Removing a PCI card



6. Lift the PCI card out of the chassis (2) and store it in an antistatic bag.
7. Install a PCI slot cover and close the PCI retention clamp.

If the PCI retention clamp levers do not close, ensure that all cards are properly seated, and then try again.


### Installing a PCI card

To install a PCI card:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Remove the PCI card support bracket (see [PCI card support on page 90](#)).

4. Open the PCI card retention clamp by pressing the retention clamp levers down to unsnap, and then rotating them up (1) as shown in the following figure.

**Figure 4-55** Installing a PCI card



5. Remove the PCI slot cover (2).
6. Align the PCI card keyway with the slot key, and then firmly seat the card in the slot (3).
7. Close the PCI retention clamp by rotating it downward and pressing the two green clamp levers from the rear panel of the chassis (4).

If the PCI retention clamp levers do not close, ensure that all cards are properly seated, and then try again.

## Battery

This section describes how to remove and install the battery.

The battery that comes with the workstation provides power to the real-time clock and has a minimum lifetime of about three years.

**⚠ WARNING!** This workstation includes a lithium battery. There is a risk of fire and chemical burn if the battery is handled improperly. Do not disassemble, crush, puncture, short external contacts, dispose in water or fire, or expose it to temperatures higher than 60°C (140°F).

**⚠ CAUTION:** Before removing the battery, back up the CMOS settings in case they are lost when the battery is removed. To back up the CMOS settings, select the **Save to Diskette** option in the Computer Setup (F10) Utility.

**📝 NOTE:** Do not dispose of batteries, battery packs, and accumulators with general household waste.

## Removing the battery

To remove the battery:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).


3. On the system board, press the release tab of the battery holder.
4. Rotate the battery enough to get beyond the latch, and then lift it straight up.

## Installing the battery

To install the battery:

1. Confirm the polarity (positive or negative) of the battery to position it correctly in the battery holder.
2. Place the battery edge under the plastic housing tab and press gently until it snaps into place as shown in the following figure.

**Figure 4-56** Removing the battery



## SAS hard drive

This section describes how to remove and install a SAS hard drive.

### Removing a SAS hard drive

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).

△ **CAUTION:** To prevent damage to the workstation, observe the following Electrostatic Discharge (ESD) precautions while performing the system parts removal and replacement procedures:


— Work on a static-free mat.

— Wear a static strap to ensure that any accumulated electrostatic charge is discharged from your body to the ground.

— Create a common ground for the equipment you are working on by connecting the static-free mat, static strap, and peripheral units to that piece of equipment.


3. Disconnect the power (1) and data (2) cables from the hard drive as shown in the following figure.

**Figure 4-57** Disconnecting SAS hard drive cables




4. Press the green drive-lock release tabs (1), and then slide the hard drive out of the chassis (2) as shown in the following figure.

**Figure 4-58** Removing a SAS hard drive



## Installing a SAS hard drive

 **NOTE:** The HP xw8600 Workstation chassis hard drive bays can be configured to hold small form factor (SFF) hard drives.


For SFF hard drive installation information, refer to *HP xw Workstation series - Small form factor bay converter and hard drive installation* at [http://www.hp.com/support/x8600\\_manuals](http://www.hp.com/support/x8600_manuals).

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).

3. Select a drive bay in which to install the drive.


If you are installing more than one hard drive, use the hard drive order shown in the following figure.

**Figure 4-59** Identifying hard drive order




4. Squeeze the green tabs, and slide the rails out of the empty bay.
5. Attach the rails to the hard drive by aligning the pins on the rails with the hard drive holes, and then snapping the rails into place as shown in the following figure.

**Figure 4-60** Attaching the rails to the hard drive




6. Attach a SAS-to-SATA cable adapter to the connector on the SAS hard drive as shown in the following figure.

**Figure 4-61** Attaching the SAS-to-SATA adapter



7. Push the drive into the selected bay until it snaps into place (1) as shown in the following figure.

**Figure 4-62** Installing the SAS hard drive



8. Attach a power cable (2) to the drive, and attach a data cable (3) from a SAS connector on the system board to the SAS hard drive.

Use lower-numbered SAS connectors first on the system board. To identify SAS connectors, refer to the workstation service label on the side access cover.

9. Replace the side access cover.

## SATA hard drive

For more information about SATA hard drives and SATA RAID configurations, see [Configuring RAID devices on page 145](#).


This section describes how to remove and install a SATA hard drive.

### Removing a SATA hard drive

To remove a SATA hard drive:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
  2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
- △ **CAUTION:** To prevent damage to the workstation, observe the following Electrostatic Discharge (ESD) precautions while performing the system parts removal and replacement procedures:
- Work on a static-free mat.
  - Wear a static strap to ensure that any accumulated electrostatic charge is discharged from your body to the ground.
  - Create a common ground for the equipment you are working on by connecting the static-free mat, static strap, and peripheral units to that piece of equipment.
3. Disconnect the data (1) and power (2) cables from the SATA hard drive as shown in the following figure.


**Figure 4-63** Disconnecting the SATA hard drive cables






4. Lift the green drive-lock release tab (1) and slide the hard drive out of the chassis (2) as shown in the following figure.

**Figure 4-64** Removing the SATA hard drive



## Installing a SATA hard drive

 **NOTE:** The HP xw8600 Workstation chassis hard drive bays can be configured to hold small form factor (SFF) hard drives.

For SFF hard drive installation information, refer to *HP xw Workstation series - Small form factor bay converter and hard drive installation* at [http://www.hp.com/support/x8600\\_manuals](http://www.hp.com/support/x8600_manuals).


To install one or two SATA hard drives:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).




3. Select a drive bay in which to install the drive. If you are installing more than one hard drive, use the hard drive order shown in the following figure.

**Figure 4-65** Identifying hard drive order




4. Squeeze the green tabs, and slide the rails out of the empty bay.
5. Attach the rails to the hard drive by aligning the pins on the rails with the hard drive holes, and then snapping the rails into place as shown in the following figure.

**Figure 4-66** Attaching the rails to the hard drive



6. Push the drive into the selected bay until it snaps into place (1) as shown in the following figure.

**Figure 4-67** Installing the SAS hard drive



7. Attach a power cable (2) to the hard drive, and attach a data cable (3) from a SATA connector on the system board to the hard drive.

Connect data cables to lower-numbered SATA connectors first on the system board. To identify SATA connectors, refer to the workstation service label on the side access panel.


8. Replace the side access cover.

### Installing a fifth hard drive (optional)

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).


3. Place the workstation on its side and remove the three drive screws that are located on the bottom of the chassis as shown in the following figure.

**Figure 4-68** Removing the drive screws



4. Insert the drive into bay 5, and align the holes in the bottom of the hard drive with the screw holes at the base of the chassis.
5. Insert the screws through the base, and tighten them to secure the hard drive to the chassis.
6. For a SAS hard drive, attach a SAS-to-SATA adapter to the connector on the hard drive before connecting the data cable.
7. Attach a data cable from the appropriate connector on the system board to the hard drive as shown below.


**Figure 4-69** Connecting the data cable



8. Connect a power cable to the drive. The power cable is a separate cable with a single connector located in a cable clip in front of the Power Supply.
9. Replace the side access panel.

## Processor heatsink

This section describes how to remove and install a processor heatsink.

 **NOTE:** Not all heatsinks are the same. The heatsink shown in the following figures is an example of what might be installed in your workstation.


### Removing the processor heatsink

Tall heatsinks are used in workstation configurations that include a memory riser or 120-watt or greater processors. All other workstation configurations use short heatsinks.


To remove a heatsink:

1. Power down the workstation (see [Predisassembly procedures on page 52](#)).
2. Disconnect power from the workstation (see [Predisassembly procedures on page 52](#)).
3. Remove the side access panel (see [Removing the side access panel on page 57](#)).
4. If a memory riser assembly is installed, remove the memory riser duct (see [Removing a memory riser assembly on page 78](#)).
5. Slowly and evenly loosen one pair of diagonally opposite screws from the processor until the screw shanks disengage from the system board (1), and then loosen the remaining pair (2). (Refer to the figure below.)

△ **CAUTION:** Do *not* fully loosen one screw, and then move on to the next. Instead, loosen all screws a little at a time, ensuring that the processor remains level.


 **NOTE:** The figure below illustrates a high power processor heatsink. Your workstation may include a low power heatsink.

**Figure 4-70** Identifying the proper screw loosening sequence



6. Disconnect the processor heatsink fan cable from the system board (1) as shown in the following figure.

**Figure 4-71** Removing the processor heatsink



7. Before lifting the heatsink, gently twist the heatsink to break the thermal compound between the processor and the heatsink.
8. Lift the processor heatsink out of the chassis (2).
9. Use alcohol and a soft cloth to clean the thermal interface residue from the processor and the heatsink, allowing the alcohol on the processor and processor heatsink to dry completely.

## Installing the processor heatsink

To install a heatsink:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Remove the processor heatsink (see [Removing the processor heatsink on page 106](#)).
4. Perform one of the following tasks:
  - If you are reusing the original heatsink, apply thermal compound to the center of the processor top surface.
  - If you are using a new processor heatsink, do not apply thermal compound to the processor because the new heatsink already has thermal compound applied to the heatsink surface. Instead, remove the thermal compound protective liner from the bottom of the new heatsink.
5. Align the four mounting screws with the mounting holes in the system board and carefully place the heatsink on the processor.

Ensure that the heatsink is placed properly with the fans positioned toward the front.

If there is no heatsink holding the board in place, ensure that the system board standoffs are all properly engaged. Also, ensure that the board is slid to the rear so that the heatsink holes in the system board align with the standoffs under the board.


- △ **CAUTION:** If a second heatsink is installed, do not pinch the processor 1 heatsink fan wire under the processor 2 heatsink.

Do not overtighten the heatsink screws. If you overtighten them, you might strip the threads in the system board tray.

Do *not* fully tighten one screw and then move on to the next. Instead, tighten all screws a little at a time, ensuring that the processor remains level.

6. Tighten all screws partially so the processor heatsink remains level.
7. Tighten each set of diagonally opposed screws a little at a time to 6 in.-lbs. of torque as shown in the following illustration.

**Figure 4-72** Identifying the proper screw tightening sequence



8. Connect the processor heatsink fan connector to the system board.
9. Replace the memory riser duct, if necessary, and then replace the side access cover.

## System processor


This section describes how to remove and install a system processor.

### Removing a system processor

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Remove the processor heatsink (see [Removing the processor heatsink on page 106](#)).

4. Raise the processor socket lever (1) and open the cover (2) as shown in the following figure.

**Figure 4-73** Removing the system processor



△ **CAUTION:** Do not touch the processor socket contacts or the gold pads underneath the processor. Use extreme care and handle the processor only by the edges.

5. Pull the processor straight out of the socket (3), and store the processor in a static free container in a safe place where it cannot be damaged

## Installing a system processor

📋 **NOTE:** If installing a second processor, it *must* be of the same type as the first processor.


1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. Remove the processor heatsink (see [Removing the processor heatsink on page 106](#)).
4. Remove the processor (see [Removing a system processor on page 108](#)).
5. Using extreme care, fully raise the processor socket lever and cover.

△ **CAUTION:** The processor socket contacts are delicate. To avoid bending the contacts, use extreme care when installing the processor in the socket.

6. If you are adding a second processor to a single-processor system:
  - Remove the plastic cover from the second processor socket.


- If there is a plastic plug in the second processor heatsink hole, ensure that the processor socket handle is raised (1), and remove the plug (2), as shown next.

**Figure 4-74** Removing the plastic plug



7. Align the notches in the processor base with the tabs on the socket as shown in the figure below. Seat the processor into the socket. Ensure that the underside of the processor is level with the top of the processor socket.

**Figure 4-75** Seating the processor



8. Close the processor cover plate by lightly pressing down on the processor cover plate while closing the socket lever.
9. Replace the processor heatsink, and then close the side access cover.

## System board


This section describes removing and installing the system board.



## Removing the system board


To remove the system board:

1. Disconnect power from the system (see [Predisassembly procedures on page 52](#)).
2. Remove the side access panel (see [Removing the side access panel on page 57](#)).
3. If a memory riser is installed, remove it (see [Removing a memory riser assembly on page 78](#)).
4. Remove expansion boards and graphics cards (see [Removing a PCI Express card on page 92](#), [Removing a PCI card on page 95](#)), and then remove the processor heatsink (see [Removing the processor heatsink on page 106](#)).
5. If an airflow duct is installed, remove the system and memory fan assembly (see [System and memory fan assembly on page 71](#)).

 **TIP:** Make a note of the cable connections before disconnecting them from the system board. For more information, refer to [Power connections to system components on page 71](#).

6. Disconnect all cabling from the system board.
7. To disengage the metal mounting standoffs from the chassis (1), slide the system board forward as shown in the following figure.

**Figure 4-76** Removing the system board



8. Lift the system board out of the chassis, being careful not to damage the cables and rear panel connectors (2).

## Installing the system board

To install the system board:

1. Insert the system board straight down, ensuring that all system board standoffs engage with the keyholes in the chassis.  
Ensure the system board connectors engage correctly with the rear I/O panel.
2. Push back on the board while maintaining downward pressure on the board, so all standoffs remain engaged.
3. Reinstall all removed components and cables. (Refer to [Power connections to system components on page 71](#) to identify power cables.)

## Product recycling

The Planet Partners recycling service provides an easy way to recycle computer equipment, rechargeable batteries, or HP printing supplies. HP processes ensure that unwanted hardware or empty HP printing supplies are recycled responsibly.

For information about recycling HP components or products, see <http://www.hp.com/go/recycle>.

---

## 5 System diagnostics and troubleshooting

This chapter describes the tools available for diagnosing and troubleshooting system issues, and includes these topics:

- [Customer Self Help on page 113](#)
- [Troubleshooting checklist on page 134](#)
- [LED color definitions on page 134](#)
- [HP Insight Diagnostics Offline Edition on page 134](#)
- [POST error messages on page 138](#)

### Customer Self Help

#### Help and Support Center

The HP Help and Support Center (HSC) provides online access to technical support information, software updates and downloads, diagnostic tools, and HP support contact information.

To open the online HSC from your desktop, select **Start>Help and Support**.

HSC contains the following support areas:

- HP Product Information (requires Internet access)—Links to the HP Technical Support website for your product. You can access all related documentation, downloads and updates, tools, and more.
- HP Software and Driver Downloads (requires Internet access)—Links to software downloads and updates for specific HP products.
- HP Support Tools (requires Internet access)—Links to self-help tools and diagnostics offered by HP Instant Support Professional Edition.
- Contact HP for Support (does not require Internet access)—Provides two options:
  - Chat with an expert online (requires Internet access)—Provides a tool to communicate with a support specialist online through Active Chat.
  - Call a support agent—Provides hardware details about your workstation and HP support phone numbers worldwide.

#### HP SoftPaq Download Manager

The HP SoftPaq Download Manager enables you to download software updates for your workstation from the HP support site. You can download the HP Softpaq Manager from <http://h20331.www2.hp.com/Hpsub/cache/509658-0-0-225-121.html> and install it on your workstation.

With the HP SoftPaq Download Manager installed, you can use it to download software updates for your workstation:

1. When download manager software is installed, run the application and go to <http://h20331.www2.hp.com/Hpsub/cache/509658-0-0-225-121.html>.
2. Select your workstation model, operating system, and language, and then click **Find Available SoftPaqs**.

All available SoftPaqs matching the selected criteria are displayed.

3. Select the updates you want to download.
4. Select **Download**.

## Diagnostic LED codes

Workstation beeps are emitted from the chassis speaker. The flashing lights and beeps repeat for five cycles. After five cycles, only the flashing lights repeat.

**Table 5-1 Diagnostic LED codes**

Chassis indicator LEDs	
Power LED and sound activity	Diagnosis and service action
None	<p>Workstation does not power on. Press the power button. If the hard drive LED is green, then perform the following:</p> <p>OR</p> <ol style="list-style-type: none"><li>1. Locate a faulty device by removing all devices one at a time:<ol style="list-style-type: none"><li>a. Disconnect AC power to the workstation.</li><li>b. Remove the device.</li><li>c. Reconnect AC power and attempt power-on.</li></ol></li><li>2. Remove the graphics card last.</li><li>3. Replace the device causing the failure.</li><li>4. If a faulty device cannot be found, replace the system board.</li></ol> <ol style="list-style-type: none"><li>1. Verify that the workstation is plugged into a working AC outlet.</li><li>2. Open the access panel and verify that the power button harness is connected to the inline front panel I/O device assembly connector.</li><li>3. Verify that the power supply cables are connected to the system board.</li><li>4. Verify power supply functionality.<ol style="list-style-type: none"><li>a. Disconnect AC power.</li><li>b. Remove internal power supply cables from the system board.</li><li>c. Plug in AC power.<ul style="list-style-type: none"><li>◦ If the power supply fan spins and the LED illuminates (see <a href="#">Testing power supply on page 118</a>), the power supply is good. Replace the system board.</li><li>◦ If the power supply fan does not spin or the LED does not illuminate (see <a href="#">Testing power supply on page 118</a>), replace the power supply.</li></ul></li></ol></li></ol>

**Table 5-1 Diagnostic LED codes (continued)**

Chassis indicator LEDs	
Power LED and sound activity	Diagnosis and service action
Blinks red 2 times (once per second), then a 2-second pause, and then 2 beeps	<p>Thermal shutdown has occurred. Perform the following:</p> <ol style="list-style-type: none"> <li>1. Ensure that the workstation air vents are not blocked.</li> <li>2. Open the access panel and press the workstation power button.</li> <li>3. Verify that the system fan is running.</li> <li>4. Verify that the processor heatsink fan spins. If it does not spin, ensure that the fan cable is plugged into the system board connector. Ensure that the heatsink is properly seated.</li> <li>5. Replace the processor heatsink.</li> </ol>
Blinks red 3 times (once per second), then a 2-second pause, and then 3 beeps	<p>Processor is not installed. Perform the following:</p> <ol style="list-style-type: none"> <li>1. Install the processor.</li> <li>2. Reseat the processor.</li> <li>3. If the problem persists, replace the processor.</li> </ol>
Blinks red 4 times (once per second), then a 2-second pause, and then 4 beeps	<p>Power failure. Perform the following:</p> <ol style="list-style-type: none"> <li>1. Perform the power supply self-test.</li> <li>2. Open the access panel and verify that the necessary power supply cables are connected to the system board.</li> <li>3. Locate a faulty device by removing all devices, and then reinstalling them one at a time until the workstation fails: <ol style="list-style-type: none"> <li>a. Disconnect AC power to the workstation.</li> <li>b. Remove all devices.</li> <li>c. Reinstall a device</li> <li>d. Reconnect AC power.</li> </ol> </li> <li>4. Replace the device causing the failure.</li> <li>5. Continue adding devices to ensure all are functioning properly.</li> <li>6. Verify power supply functionality. Perform the following: <ol style="list-style-type: none"> <li>a. Disconnect AC power.</li> <li>b. Remove all internal power supply cables from the system board.</li> <li>c. Plug in AC power. <ul style="list-style-type: none"> <li>• If the power supply fan spins and the LED illuminates (see <a href="#">Testing power supply on page 118</a>), the power supply is good. Replace the system board.</li> <li>• If the power supply fan does not spin or the LED does not illuminate (see <a href="#">Testing power supply on page 118</a>), replace the power supply.</li> </ul> </li> </ol> </li> </ol>
Blinks red 5 times (once per second), then a 2-second pause, and then 5 beeps	<p>Pre-video memory error</p> <ol style="list-style-type: none"> <li>1. Ensure that the memory modules are loaded correctly (<a href="#">Required system board DIMM installation order on page 75</a>).</li> <li>2. Reseat memory modules.</li> <li>3. Replace memory modules one at a time to find the faulty module.</li> </ol>

**Table 5-1 Diagnostic LED codes (continued)**

Chassis indicator LEDs	
Power LED and sound activity	Diagnosis and service action
	<ol style="list-style-type: none"> <li>4. Replace third-party modules with HP memory.</li> <li>5. If necessary, replace the system board.</li> </ol>
Blinks red 6 times (once per second), then a 2-second pause, and then 6 beeps	Pre-video graphic card error. Perform the following: <ol style="list-style-type: none"> <li>1. Reseat the graphic card and then power on the workstation.</li> <li>2. Replace the graphics card.</li> <li>3. If necessary, replace the system board.</li> </ol>
Blinks red 7 times (once per second), then a 2-second pause, and then 7 beeps	System board failure (ROM detected a failure before video). <ol style="list-style-type: none"> <li>1. Reflash the system ROM (see <a href="#">ROM Flash on page 36.</a>).</li> <li>2. If necessary, replace the system board.</li> </ol>
Blinks red 8 times (once per second), then a 2-second pause, and then 8 beeps	Invalid system ROM based on bad checksum. Workstation enters FailSafe (Boot Block) recovery mode. Perform the following: <ol style="list-style-type: none"> <li>1. Reflash the system ROM (see <a href="#">FailSafe Boot Block ROM on page 36.</a>).</li> <li>2. If necessary, replace the system board.</li> </ol>
Blinks red 9 times (once per second), then a 2-second pause, and then 9 beeps	System power is on, but workstation is unable to boot. <ol style="list-style-type: none"> <li>1. Replace the system board.</li> <li>2. If necessary, replace the processor.</li> </ol>

## Troubleshooting scenarios and solutions

This section presents an extensive overview of various troubleshooting scenarios and includes possible solutions for each.



**NOTE:** For Linux troubleshooting information, refer to the *HP Workstations for Linux User Manual* at [http://www.hp.com/support/xw8600\\_manuals](http://www.hp.com/support/xw8600_manuals).

## Solving minor problems

**Table 5-2 Minor problems**

Problem	Cause	Possible Solution
Workstation appears frozen and does not shut down when the power button is pressed.	Software control of the power switch is not functional.	<ol style="list-style-type: none"> <li>1. Press and hold the power button for at least four seconds until the workstation shuts down.</li> <li>2. Disconnect the electrical plug from the outlet.</li> <li>3. Restart the workstation.</li> </ol>
Workstation seems to be frozen.	Program in use has stopped responding to commands.	<ol style="list-style-type: none"> <li>1. If possible, use the Windows Task Manager to isolate and terminate the offending process.</li> <li>2. Attempt the normal Windows shutdown procedure.</li> <li>3. Restart the workstation using the power button.</li> </ol>
Workstation date and time display is incorrect.	Real-time clock (RTC) battery might need replacement.	<ol style="list-style-type: none"> <li>1. Reset the date and time in the Control Panel.</li> <li>2. Replace the RTC battery.</li> </ol>

**Table 5-2 Minor problems (continued)**

Problem	Cause	Possible Solution
Workstation appears to pause periodically.	Network driver is loaded and no network connection is established.	Establish a network connection, or use the Computer Setup (F10) Utility or the Microsoft Windows Device Manager to disable the network controller.
Cursor does not move using the arrow keys on the keypad.	The <b>Num Lock</b> key might be on.	Press <b>Num Lock</b> . The Num Lock key can be disabled or enabled in the Computer Setup (F10) Utility.
Poor performance is experienced.	Processor is hot.	<ol style="list-style-type: none"> <li>1. Verify that airflow to the workstation is not blocked.</li> <li>2. Verify that chassis fans are connected and working properly. Some fans operate only when needed.</li> <li>3. Verify that the processor heatsink is installed properly.</li> </ol>
	Hard drive is full.	Transfer data from the hard drive to create more space on the hard drive.
Workstation powered off automatically and the Power LED flashes red 2 times (once every second), followed by a 2-second pause, and then two simultaneous beeps sounded.	Processor thermal protection is activated.	<ol style="list-style-type: none"> <li>1. Verify that the workstation air vents are not blocked.</li> <li>2. Open the access panel and press the workstation power button.</li> <li>3. Verify that the system fan is running.</li> <li>4. Verify that the processor heatsink fan spins. If the fan is not spinning, verify that the heatsink fan cable is plugged into the system board connector and that the heatsink is properly seated.</li> <li>5. Replace the processor heatsink.</li> </ol>
	<p>A fan might be blocked or not turning.</p> <p>OR</p> <p>The processor heatsink is not properly attached to the processor.</p>	
System does not power on, and the LEDs on the front of the workstation are not flashing.	System cannot power on.	Press and hold the power button for less than four seconds. If the hard drive LED turns green, then perform the following steps.
		<p>OR</p> <ol style="list-style-type: none"> <li>1. To find a faulty device, remove all devices one at a time: <ol style="list-style-type: none"> <li>a. Disconnect AC power to the workstation.</li> <li>b. Remove a device.</li> <li>c. Reconnect AC power and power on the workstation.</li> </ol> </li> <li>2. Repeat this process until the faulty device is identified. Remove the graphics card last. Replace the faulty device.</li> <li>3. If no faulty device is found, replace the system board.</li> <li>1. Press and hold the power button for less than four seconds. If the hard drive LED does not illuminate, then perform the following step:</li> <li>2. Press and hold the power button for <i>less than</i> four seconds. If the hard drive LED does not illuminate, then perform the following tasks: <ol style="list-style-type: none"> <li>a. Verify that the workstation is plugged into a working AC outlet.</li> <li>b. Verify that the power button harness is connected to the inline front panel I/O device assembly connector.</li> </ol> </li> </ol>

**Table 5-2 Minor problems (continued)**

Problem	Cause	Possible Solution
		<ol style="list-style-type: none"><li>3. Verify that the power supply cables are connected to the system board.</li><li>4. Verify power supply functionality:<ol style="list-style-type: none"><li>a. Disconnect AC power.</li><li>b. Remove internal power supply cables from the system board.</li><li>c. Plug in AC power.<ul style="list-style-type: none"><li>• If the power supply fan spins and the BIST LED illuminates (see <a href="#">Testing power supply on page 118</a>), the power supply is good. Replace the system board.</li><li>• If the power supply fan does not spin or the LED does not illuminate (see <a href="#">Testing power supply on page 118</a>), replace the power supply.</li></ul></li></ol></li></ol>

## Solving power supply problems

This section presents power supply troubleshooting scenarios.

### Testing power supply


Before replacing the power supply, use the Built-In Self-Test (BIST) feature to learn if the power supply still works.



To test the power supply:

1. Unplug the AC power.
2. Disconnect internal power supply cables from the system board.
3. Plug in AC power and verify the following:
  - If the green LED (illustrated below) on the rear of the workstation is illuminated *and* the fan is spinning, the power supply is functional.
  - If the green LED is not illuminated *or* the fan is not spinning, replace the power supply.

**Figure 5-1** Testing power supply with LED



**Table 5-3** Power supply problems

Problem	Cause	Solution
Power supply shuts down intermittently.	Power supply fault.	Replace the power supply.
Workstation powers off and the Power LED flashes red 2 times (once every second), followed by a 2-second pause.	Processor thermal protection is activated. A fan might be blocked or not turning. OR The processor heatsink fan assembly is not properly attached to the processor.	<ol style="list-style-type: none"> <li>1. Ensure that the workstation air vents are not blocked.</li> <li>2. Open the access panel and press the workstation power button.</li> <li>3. Verify that the system fan is running.</li> <li>4. Verify that the processor heatsink fan spins.  If the heatsink fan is not spinning, verify that the fan cable is plugged into the system board connector. Verify that the fan is properly seated.</li> <li>5. Replace the processor heatsink.</li> </ol>
Power LED flashes red (once every 2 seconds).	Power failure (power supply is overloaded).	<ol style="list-style-type: none"> <li>1. Determine whether a device is causing the problem by performing the following:               <ol style="list-style-type: none"> <li>a. Disconnect AC power.</li> <li>b. Remove all attached devices.</li> <li>c. Power on the workstation.</li> </ol>  If the system enters the POST, perform the following:             </li> </ol>

**Table 5-3 Power supply problems (continued)**

Problem	Cause	Solution
		<ol style="list-style-type: none"> <li>a. Power off the workstation.</li> <li>b. Replace one device at a time and repeat this procedure until a failure occurs.</li> <li>c. Replace the device causing the failure</li> <li>d. Continue adding devices one at a time to verify that all devices are functioning.</li> </ol>
		<ol style="list-style-type: none"> <li>2. Verify power supply functionality.               <ol style="list-style-type: none"> <li>a. Disconnect AC power.</li> <li>b. Remove all internal power supply cables from the system board.</li> <li>c. Plug in AC power.                   <ul style="list-style-type: none"> <li>• If the power supply fan spins and the LED illuminates (see <a href="#">Testing power supply on page 118</a>), the power supply is good. Replace the system board.</li> <li>• If the power supply fan does not spin or the LED does not illuminate (see <a href="#">Testing power supply on page 118</a>), replace the power supply.</li> </ul> </li> </ol> </li> </ol>

## Solving diskette problems

**Table 5-4 Diskette problems**

Problem	Cause	Solution
Diskette drive light stays on.	Diskette is damaged.	<ol style="list-style-type: none"> <li>1. Right-click <b>Start</b>, select <b>Explore</b>, and then select a drive.</li> <li>2. Select <b>File&gt;Properties&gt;Tools</b>.</li> <li>3. Under Error-checking, select <b>Check Now</b>.</li> </ol>
	Diskette is incorrectly inserted.	Remove and reinsert diskette.
	Files on the diskette are damaged.	Verify the program diskettes.
	Drive cable is not properly connected.	Reconnect the power cable and verify that all four pins are connected.
Drive not found.	Cable is loose.	Reseat the diskette drive data and power cables.
	Removable drive is not seated properly.	Reseat the drive.

**Table 5-4 Diskette problems (continued)**

Problem	Cause	Solution
Diskette drive cannot write to a diskette.	Diskette is not formatted.	Format the diskette.
	Diskette is write-protected.	Use another diskette or remove the write protection.
	Writing to the wrong drive.	Verify the drive letter in the path statement.
	There is not enough space on the diskette.	Use another diskette.
	Diskette write-control is enabled.	Use the Computer Setup (F10) Utility to verify the storage security feature disabled settings.
	Diskette is damaged.	Replace the damaged disk.
Cannot format diskette.	Invalid media reported.	When formatting a disk in MS-DOS, you might need to specify diskette capacity.  For example, to format a 1.44-MB diskette, enter the following command at the MS-DOS prompt: <b>FORMAT A: /F:1440</b>
A problem has occurred with a disk transaction.	The directory structure is bad, or there is a problem with a file.	<ol style="list-style-type: none"> <li>1. Right-click <b>Start</b>, select <b>Explore</b>, and then select a drive.</li> <li>2. Select <b>File&gt;Properties&gt;Tools</b>.</li> <li>3. Under Error-checking, select <b>Check Now</b>.</li> </ol>
Diskette drive cannot read a diskette.	Diskette is not formatted.	Format the diskette.
	You are using the wrong diskette type for the drive type.	Verify the type of drive that you are using and use the correct diskette type.
	You are reading the wrong drive.	Verify the drive letter in the path statement.
	Diskette is damaged.	Replace the diskette with a new one.
<b>Invalid system disk</b> is displayed.	A diskette that does not contain the system files needed to start the workstation has been inserted into the drive.	When drive activity stops, remove the diskette and press the Spacebar. The workstation attempts to boot from the next device in the boot order.
	Diskette error has occurred.	Restart the workstation by pressing the power button.
Cannot Boot to Diskette.	Diskette is not bootable.	Replace with a bootable diskette.
	Diskette boot has been disabled in Computer Setup.	Run the Computer Setup (F10) Utility and enable diskette boot in Storage>Boot Order.
	Removable media boot has been disabled in Computer Setup.	Run the Computer Setup (F10) Utility and enable Removable Media Boot in Storage>Storage Options.
	Diskette MBR validation is enabled.	Run the Computer Setup (F10) Utility and disable Diskette MBR Validation in <b>Storage&gt;Storage Options</b> .

## Solving hard drive problems

**Table 5-5 Hard drive problems**

Problem	Cause	Solution
Hard drive error occurs.	Hard disk has bad sectors or has failed.	Use a utility to locate and block usage of bad sectors. If necessary, reformat the hard disk.  If the drive is detected by the BIOS, run DPS Self-test.
Disk transaction problem.	The directory structure is bad, or there is a problem with a file.	<ol style="list-style-type: none"> <li>1. Right-click <b>Start</b>, select <b>Explore</b>, and select a drive.</li> <li>2. Select <b>File&gt;Properties&gt;Tools</b>.</li> <li>3. Under Error-checking, select <b>Check Now</b>.</li> </ol>
Drive not found (identified).	Loose cable.	Verify cable connections.
	The system might not have automatically recognized a newly installed device.	<ol style="list-style-type: none"> <li>1. Run the Computer Setup (F10) Utility.</li> <li>2. If the system does not recognize the new device, verify that the device is listed in the Computer Setup (F10) Utility.  If it is listed, the probable cause is a driver problem. If it is not listed, the probable cause is a hardware problem.</li> <li>3. If this drive is newly installed, enter <b>Setup</b> and try adding a POST delay under Advanced&gt;Power-On.</li> </ol>
	Drive responds slowly immediately after power-up.	Run the Computer Setup (F10) utility, and increase the POST Delay in Advanced>Power-On Options.
Nonsystem disk or NTLDR missing message.	System is trying to start from a nonbootable diskette.	Remove the diskette from the drive.
	System is trying to start from a damaged hard drive.	<ol style="list-style-type: none"> <li>1. Insert a bootable diskette into the drive and restart the workstation.</li> <li>2. If the hard drive is still inaccessible and MBR Security is enabled, try restoring the previously saved MBR image by entering Setup and selecting <b>Security&gt;Restore Master Boot Record</b>.</li> </ol>
	System files missing or not properly installed.	<ol style="list-style-type: none"> <li>1. Insert a bootable system diskette and restart.</li> <li>2. Verify that the hard drive is partitioned and formatted.</li> <li>3. Install the system files for the appropriate operating system, if necessary.</li> </ol>
	Hard drive boot disabled in Computer Setup.	Run the Computer Setup (F10) Utility and enable the hard drive entry in the Storage>Boot Order list.
Workstation will not start.	Hard drive is damaged.	Replace the hard drive.

## Solving display problems

**Table 5-6 Display problems**

Problem	Cause	Solution
Blank screen (no video).	The cable connections are not correct.	Verify the cable connections from the monitor to the workstation and to a working electrical outlet.
	The monitor is off.	Turn the monitor on (LED is on). You might need to refer to the monitor manual for an explanation of LED signals.
	Screen blanking utility installed or energy saver features enabled.	Press a key or the mouse button and, if set, enter your password.
	System ROM is bad; system is running in FailSafe Boot Block mode (indicated by 8 beeps).	Reflash the ROM using a SoftPaq. (See <a href="#">ROM Flash on page 36.</a> )
	Fixed-sync monitor does not sync at the resolution specified.	Verify that the monitor can accept the same horizontal scan rate as the resolution specified.
	Computer is in Hibernate mode.	Press the power button to resume from Hibernate mode.
	Workstation monitor settings are not compatible with the monitor.	<ol style="list-style-type: none"> <li>1. When you see <b>Press F8</b> in the bottom-right corner of the screen, restart the workstation and press <b>F8</b> during startup.</li> <li>2. Using the keyboard arrow keys, select <b>Enable VGA Mode</b> and then press <a href="#">Enter</a>.</li> <li>3. For Windows, double-click the <b>Display</b> icon in the Control Panel and then select the <b>Settings</b> tab.</li> <li>4. Use the sliding control to reset the resolution.</li> </ol>
The display works properly during the POST but goes blank when the operating system starts.	The display settings in the operating system are incompatible with your graphics card and monitor.	<ol style="list-style-type: none"> <li>1. For Windows, restart your workstation in VGA mode.</li> <li>2. After the operating system starts, change the display settings to match those supported by your graphics card and monitor.</li> <li>3. Refer to your operating system and graphics card documentation for information about changing display settings.</li> </ol>
Power LED flashes red 6 times (once every second), followed by a 2-second pause, and then the workstation beeps 6 times.	Prevideo graphics error.	For systems with a graphics card: <ol style="list-style-type: none"> <li>1. Reseat the graphics card.</li> <li>2. Replace the graphics card.</li> <li>3. Replace the system board.</li> </ol>
Monitor does not function when used with Energy Saver features.	Monitor without Energy Saver capabilities is being used with Energy Saver features enabled.	Disable the monitor Energy Saver feature.
Dim characters	The brightness and contrast controls are not set properly.	Adjust the monitor brightness and contrast controls.
	Cables are not properly connected.	Verify that the graphics cable is connected to the graphics card and the monitor.

**Table 5-6 Display problems (continued)**

Problem	Cause	Solution
Blurry video or requested resolution cannot be set.	If the graphics controller was upgraded, the correct video drivers might not be loaded.	Install the video drivers included in the upgrade kit, or download and install the latest drivers for your graphics card from <a href="http://welcome.hp.com/country/us/en/support.html">http://welcome.hp.com/country/us/en/support.html</a> .
	Monitor cannot display requested resolution.	Change the requested resolution.
The picture is broken up, rolls, jitters, or flashes.	The monitor connections might be faulty, or the monitor might be incorrectly adjusted.	<ol style="list-style-type: none"> <li>1. Be sure the monitor cable is securely connected to the workstation.</li> <li>2. In a multiple CRT monitor system, ensure that the monitors' electromagnetic fields are not interfering with each other. Move them apart if necessary.</li> <li>3. Move fluorescent lights or fans that are too close to the CRT monitor.</li> </ol>
	Monitor must be degaussed.	Degauss the monitor.
Vibrating or rattling noise coming from inside a CRT monitor when powered on.	Monitor degaussing coil has been activated.	None. It is normal for the degaussing coil to be activated when the monitor is powered on.
Clicking noise coming from inside a CRT monitor.	Electronic relays have been activated inside the monitor.	None. It is normal for some monitors to make a clicking noise when turned on and off, when going in and out of Standby mode, and when changing resolutions.
High pitched noise coming from inside a flat-panel monitor.	Brightness and contrast settings are too high.	Lower brightness and contrast settings.
Fuzzy focus; streaking, ghosting, or shadowing effects; horizontal scrolling lines; faint vertical bars; or unable to center the picture on the screen (flat-panel monitors using an analog VGA input connection only.)	Flat-panel monitor's internal digital conversion circuits might be unable to correctly interpret the output synchronization of the graphics card.	<ol style="list-style-type: none"> <li>1. Select the monitor's <b>Auto-Adjustment</b> option in the monitor's onscreen display menu.</li> <li>2. Manually synchronize the Clock and Clock Phase onscreen display functions.</li> <li>3. Download SoftPaq SP20930 or SP22333 (depending on the monitor) to assist with the synchronization).</li> </ol>
Some typed symbols do not appear correctly.	The font you are using does not support that symbol.	<p>Use the Character Map to locate and select the appropriate symbol.</p> <p>Select <b>Start&gt;All Programs&gt; Accessories&gt;System Tools&gt;Character Map</b>. You can copy the symbol from the Character Map into a document.</p>

## Solving audio problems

**Table 5-7 Audio problems**

Problem	Cause	Solution
Sound does not come out of the speaker or headphones.	Software volume control is turned down.	Double-click the <b>Speaker</b> icon on the taskbar and use the volume slider to adjust the volume.
	The external speakers are not turned on.	Turn on the external speakers.
	External speakers plugged into the wrong audio jack.	See your sound card documentation for proper speaker connection.
	Digital CD audio is not enabled.	Enable digital CD audio: <ol style="list-style-type: none"> <li>1. From the Control Panel, select <b>System</b>.</li> <li>2. On the Hardware tab, select the <b>Device Manager</b> button.</li> <li>3. Right-click the <b>CD/DVD</b> device and select <b>Properties</b>.</li> <li>4. On the Properties tab, select <b>Enable digital CD audio for this CD-ROM device</b>.</li> </ol>
	Headphones or devices connected to the line-out connector have muted the internal speaker.	Turn on and use headphones or external speakers, if connected, or disconnect headphones or external speakers.
	Volume is muted.	<ol style="list-style-type: none"> <li>1. From the Control Panel, select <b>Sound, Speech and Audio Devices</b>, and then select <b>Sounds and Audio Devices</b>.</li> <li>2. Deselect the <b>Mute</b> checkbox.</li> </ol>
Noise or no sound comes out of the speakers or headphones.	Computer is in Standby mode.	Press the power button to resume from Standby mode.
		<ol style="list-style-type: none"> <li>1. If you are using digital speakers that have a stereo jack and you want the system to autoswitch to digital, use a stereo-to-mono adapter to engage the auto sense feature, or use multimedia device properties to switch the audio signal from analog to digital.</li> <li>2. If the headphones have a mono jack, use the multimedia device properties to switch the system to analog out.</li> </ol> <p><b>NOTE:</b> If you set digital as the Output Mode, the internal speaker and external analog speakers no longer output audio until you switch back to an auto sense or analog mode.</p> <p>If you set analog as the Output Mode, external digital speakers do not function until you change the output mode back to an auto-sense or digital mode.</p>
	Sound occurs intermittently.	Processor resources are being used by other open applications. Shut down all open processor-intensive applications.
Workstation appears to be locked up while recording audio.	The hard disk might be full.	<ol style="list-style-type: none"> <li>1. Before recording, be sure there is enough free space on the hard disk.</li> <li>2. Try recording the audio file in a compressed format.</li> </ol>

## Solving printer problems

**Table 5-8 Printer problems**

Problem	Cause	Solution
Printer does not print.	Printer is not turned on and online.	Turn the printer on and be sure it is online.
	The correct printer driver for the application is not installed.	<ol style="list-style-type: none"><li>1. Install the correct printer driver for the application.</li><li>2. Try printing using the MS-DOS command: <b>DIR C:\&gt; [printer port]</b> Replace <i>printer port</i> with the address of the printer used. If the printer works, reload the printer driver.</li></ol>
	If you are on a network, you might not have made a connection to the printer.	Make the proper network connection to the printer.
	Printer might have failed.	Run printer self-test.
Printer does not turn on.	The cables might not be connected properly.	Reconnect all cables.
Printer prints garbled information.	The correct printer driver is not installed.	Install the correct printer driver for the application.
	The cables might not be connected properly.	Reconnect all cables.
	Printer memory might be overloaded.	Reset the printer by turning it off for one minute, then turn it back on.
Printer is offline.	The printer might be out of paper.	<ol style="list-style-type: none"><li>1. Verify that the paper tray and refill it if it is empty.</li><li>2. Select <b>Online</b>.</li></ol>

## Solving keyboard and mouse problems

**Table 5-9 Keyboard and mouse problems**

Problem	Cause	Solution
Keyboard commands and typing are not recognized by the workstation.	Keyboard connector is not properly connected.	<ol style="list-style-type: none"><li>1. Power off the workstation.</li><li>2. Reconnect the keyboard to the back of the workstation and restart the workstation.</li></ol>
	Program in use has stopped responding to commands.	Shut down the workstation using the mouse, and then restart the workstation.
	Keyboard is defective.	Replace the keyboard.
	Keyboard key is stuck.	Remove debris from the keyboard.
	Workstation is in Hibernate mode.	Press the power button to resume from Hibernate mode.
Cursor will not move using the arrow keys on the keypad.	The <b>Num Lock</b> key might be on.	Press <b>Num Lock</b> . The Num Lock light should not be on if you want to use the arrow keys. The Num Lock key can be disabled or enabled in the Computer Setup (F10) Utility.



**Table 5-9 Keyboard and mouse problems (continued)**

Problem	Cause	Solution
Mouse does not respond to movement or is too slow.	Mouse connector is not properly plugged into the back of the workstation.	<ol style="list-style-type: none"> <li>1. Shut down the workstation using the keyboard.</li> <li>2. Plug the mouse connector into the PS/2 mouse connector slot in the workstation, and then restart the workstation.</li> </ol>
	Program in use has stopped responding to commands.	Shut down the workstation using the keyboard and then restart the workstation.
	Mouse is defective.	Replace the mouse.
	Workstation is in Standby mode.	Press the power button to resume from Standby mode.
Mouse only moved vertically or horizontally, or the movement is jerky.	Mouse rollerball is dirty.	Remove the rollerball cover from the bottom of the mouse, clean it, and then replace cover.

## Solving front panel component problems

If you are experiencing problems with a front panel port, you might be able to try your device in the corresponding port on the back side of the computer. If this does not fix the problem, or you if must use the front panel ports, continue troubleshooting.

**Table 5-10 Front panel component problems**

Problem	Cause	Solution
A USB device, headphone, or microphone is not recognized by the workstation.	The device is not properly connected.	<ol style="list-style-type: none"> <li>1. Power off the workstation.</li> <li>2. Reconnect the device to the front of the workstation and restart the workstation.</li> </ol>
	The device does not have power.	If the USB device requires AC power, be sure one end is connected to the device and one end is connected to a live outlet.
	The correct device driver is not installed.	<ol style="list-style-type: none"> <li>1. Install the correct driver for the device.</li> <li>2. Reboot the workstation if required by the device driver.</li> </ol>
	The cable from the device to the computer does not work.	<ol style="list-style-type: none"> <li>1. If possible, replace the cable.</li> <li>2. Reboot the workstation.</li> </ol>
	The device is not working.	<ol style="list-style-type: none"> <li>1. Replace the device.</li> <li>2. Reboot the workstation.</li> </ol>
A USB, audio, or IEEE-1394 device is not working.	The internal cables might not be connected to the system board or the PCI card.	<ol style="list-style-type: none"> <li>1. Power off the workstation.</li> <li>2. Connect the cables correctly.</li> <li>3. Reboot the workstation.</li> </ol>

**Table 5-10 Front panel component problems (continued)**

Problem	Cause	Solution
A device in the IEEE-1394 port is not responsive.	Cables of the external device are loose, or power cables are unplugged.	Verify that all cables are properly connected.
	The power switch on the device is not turned on.	Power off the workstation, power on the external device, then power on the workstation to integrate the device with the workstation system.
The IEEE-1394 port is not active.	The port is not there because it was not purchased with the system.	Obtain an IEEE 1394 PCI adapter card. Contact HP sales.

## Solving hardware installation problems

You might need to reconfigure the workstation when you add or remove hardware, such as an additional diskette drive. If you install a Plug and Play (PnP) device, the operating system recognizes the device and configures the workstation. If you install a nonPnP device, you must reconfigure the workstation after installing the new hardware.

**Table 5-11 Hardware installation problems**

Problem	Cause	Solution
A new device is not recognized as part of the system.	Device is not seated or connected properly.	Verify that the device is properly and securely connected and that pins in the connector are not bent.
	Cables of the new device are loose, or power cables are unplugged.	Verify that all cables are properly and securely connected and that pins in the cable or connector are not bent.
	Power switch of the new device is not turned on.	Power off the workstation, power on the device, and then power on the workstation to integrate the device into the workstation system.
	When the system advises you about changes to the configuration, you do not accept them.	Reboot the workstation and follow the instructions for accepting the changes.
	A PnP board might not configure when added if the default configuration conflicts with other devices.	Use Windows XP Device Manager to deselect the automatic settings for the board and choose a basic configuration that does not cause a resource conflict.  You can also use the Computer Setup (F10) Utility to reconfigure or disable devices to resolve the resource conflict.
	Device hardware is not properly jumpered or otherwise configured.	Read the device-specific configuration information and check for incorrect settings or conflicts with other devices installed in the system.

**Table 5-11 Hardware installation problems (continued)**

Problem	Cause	Solution
Workstation does not start.	Wrong memory modules were used in the upgrade, or memory modules were installed in the wrong location.	<ol style="list-style-type: none"> <li>1. Review the documentation that came with the system to determine if you are using the correct memory modules and to verify the proper installation.</li> <li>2. Observe the beeps and LEDs on the front of the workstation. To determine possible causes. see <a href="#">POST error messages on page 138</a>.</li> </ol>
	PCI Express power cable might be plugged into the wrong connector on the system board.	Connect the auxiliary PCI Express power cable to the PCI Express card.

## Solving network problems

The following table provides repair suggestions for common network problems.

**Table 5-12 Network problems**

Problem	Cause	Solution
Wake-on-LAN feature is not functioning.	Wake-on-LAN is not enabled.	Use the network control application to enable Wake-on-LAN.
Network driver does not detect network controller.	Network controller is disabled.	Run the Computer Setup (F10) Utility to enable network controller.
	Incorrect network driver.	Obtain the latest driver from <a href="http://welcome.hp.com/country/us/en/support.html">http://welcome.hp.com/country/us/en/support.html</a> .
Network status link light does not illuminate or never flashes.	No active network is detected.	Verify cabling and network equipment for proper connection.
The network status light does not flash when there is network activity.	Network controller is not set up properly.	Use the network control application to verify that the device is working properly.
	Network driver is not properly loaded.	Reinstall network drivers.
	System cannot auto-sense the network.	Disable auto sensing capabilities and force the system into the correct operating mode.
Diagnostics reports a failure.	The cable is not securely connected.	Be sure that both ends of the data cable are securely connected.
	The cable is attached to the incorrect connector.	Be sure that the cable is attached to the correct connector.
	There is a problem with the cable or a device at the other end of the cable.	Be sure that the cable and device at the other end are operating correctly.
	Network controller interrupt is shared with an expansion board.	Under the Computer Setup (F10) Utility Advanced menu, change the resource settings for the board.
	The network controller is defective.	Replace the Network Interface Controller, or replace the system board if using an onboard NIC.

**Table 5-12 Network problems (continued)**

Problem	Cause	Solution
Diagnostics passes, but the workstation does not communicate with the network.	Network drivers are not loaded, or driver parameters do not match current configuration.	<ol style="list-style-type: none"> <li>1. Verify that the network drivers are loaded and that the driver parameters match the configuration of the network controller.</li> <li>2. Verify that the correct network client and protocol is installed.</li> </ol>
	The network controller is not configured for this workstation.	Double-click the <b>Network</b> icon in the Control Panel and configure the network controller.
Network controller stopped working when an expansion board was added to the workstation.	Network controller interrupt is shared with an expansion board.	In the Computer Setup (F10) Utility Advanced menu, change the resource settings for the board.
	The network controller requires drivers.	Verify that the drivers were not accidentally deleted when the drivers for the expansion board were installed.
	The expansion board installed is a network card and conflicts with the embedded network card.	Under the Computer Setup (F10) Advanced menu, change the resource settings for the board.
Network controller stops working without apparent cause.	The files containing the network drivers are corrupted.	Reinstall the network drivers using the <i>Restore Plus!</i> CD, or download and install the latest drivers from <a href="http://welcome.hp.com/country/us/en/support.html">http://welcome.hp.com/country/us/en/support.html</a> .
	The cable is not securely connected.	Be sure that both ends of the cable are securely attached to the correct devices.
	The network controller is defective.	Replace the Network Interface Controller, or replace the system board when using an onboard NIC.
New network card does not boot.	New network card might be defective or might not meet industry-standard specifications.	Install a working, industry-standard Network Interface Controller, or change the boot sequence to boot from another source.
Cannot connect to network server when attempting remote system installation.	The network controller is not configured properly.	Verify that: <ul style="list-style-type: none"> <li>• Network connectivity is functioning</li> <li>• A DHCP server is present</li> <li>• Remote System Installation Server contains the Network Interface Controller drivers for your NIC</li> </ul>
Computer Setup (F10) Utility reports unprogrammed EEPROM.	Unprogrammed EEPROM.	Flash the ROM.

## Solving memory problems

- △ **CAUTION:** For systems that support ECC memory, HP does not support mixing ECC and nonECC memory. The operating system does not boot with mixed-ECC memory.

**Table 5-13 Memory problems**

Problem	Cause	Solution
System does not boot (or does not function) after installing additional memory modules.	A memory module is not the correct type or speed, or the new memory module is not seated properly.	Replace the module with the correct, industry-standard device for the workstation.  On some models, ECC and nonECC memory modules cannot be mixed.

**Table 5-13 Memory problems (continued)**

Problem	Cause	Solution
Out of memory error.	Memory configuration might not be set up correctly.	Verify proper workstation memory configuration. (See <a href="#">Memory on page 72.</a> )
	You have run out of memory to run the application.	Review the application documentation to determine the memory requirements.
Memory count during POST is wrong.	The memory modules might not be installed correctly.	Verify that the memory modules are installed correctly and that proper modules are used.
Insufficient memory error during operation.	Too many Terminate and Stay Resident (TSR) programs are installed.	Delete TSRs that you do not need.
	You have run out of memory for the application.	Verify the memory requirements for the application or add more memory to the workstation.
Power LED flashes red 5 times (once every second), followed by a 2-second pause, and then the workstation beeps 5 times.	Memory is installed incorrectly or is bad.	1. Reseat DIMMs.
		2. Replace DIMMs one at a time to isolate the faulty module.
		3. Replace third-party memory with HP memory.
		4. Replace the system board.

## Solving processor problems

**Table 5-14 Processor problems**

Problem	Cause	Solution
Poor performance is experienced.	Processor is hot.	1. Be sure the airflow to the workstation is not blocked.
		2. Be sure the fans are connected and working properly. Some fans only operate when needed.
		3. Be sure the processor heatsink is installed properly.
Power LED is red and stays on.	Processor is not seated properly or is not installed.	1. Verify that the processor is present.
		2. Reseat the processor.

## Solving DVD problems

**Table 5-15 DVD problems**

Problem	Cause	Solution
System does not boot from DVD drive.	The DVD boot is not enabled through the Computer Setup (F10) Utility.	Run the Computer Setup (F10) Utility and enable booting to removable media and verify boot order settings.
	Nonbootable CD in drive.	Try a bootable DVD in the drive.
DVD devices are not detected or the driver is not loaded.	Drive is not connected properly or not properly configured.	1. Reconnect power and data cables to the drive.
		2. Install correct device driver.

**Table 5-15 DVD problems (continued)**

Problem	Cause	Solution
Movie does not play in the DVD drive.	Movie might be regionalized for a different country.	See the documentation included with the DVD drive.
	Decoder software is not installed.	Install decoder software.
Cannot eject DVD (tray-load unit).	Disc not properly seated in the drive.	1. Power off the workstation and insert a thin metal rod (such as a paper clip) into the emergency eject hole and push firmly.
		2. Slowly pull the tray out from the drive until the tray is fully extended, and then remove the disc.
Optical drive cannot read a disc or takes too long to start.	The DVD has been inserted upside down.	Reinsert the DVD with the label facing up.
	The optical drive takes longer to start because it has to determine the type of media played, such as audio or video.	Wait at least 30 seconds to let the optical drive determine the type of media being played. If the disc still does not start, read the other solutions listed for this topic.
	The DVD is dirty.	Clean the DVD with a cleaning kit.
	Windows does not detect the optical drive.	1. Use Device Manager to remove or uninstall the device.
		2. Restart the workstation and allow Windows to detect the device.
Recording audio DVDs is difficult or impossible.	Wrong or poor-quality media type.	1. Use a slower recording speed.
		2. Verify that you are using the correct media for the drive.
		3. Try a different brand of media. Quality varies widely between manufacturers.

## Solving Internet access problems

**Table 5-16 Internet access problems**

Problem	Cause	Solution
Unable to connect to the Internet.	Internet Service Provider (ISP) account is not set up properly.	Verify Internet settings or contact the ISP for assistance.
	Modem is not set up properly.	Reconnect the modem and use the quick setup documentation to verify the connections are correct .
	Web browser is not set up properly.	Verify that the Web browser is installed and set up to work with your ISP.
	Cable/ DSL modem is not plugged in.	Plug in cable/DSL modem. When properly connected, the power LED on the front of the cable/DSL modem should be illuminated.
	Cable or DSL service is not available or has been interrupted because of bad weather.	Try connecting to the Internet at a later time, or contact your ISP. If the cable/DSL service is connected, the cable LED light on the front of the cable/DSL modem is on.
	The CAT5 10/100/1000 cable is disconnected.	Connect the CAT5 10/100/1000 cable between the cable modem and the workstations RJ-45 connector.  If the connection is good, the LED on the front of the cable/DSL modem is on.
	IP address is not configured properly.	Contact the ISP for the correct IP address.
	Cookies are corrupted.	<ol style="list-style-type: none"> <li>1. Select <b>Start&gt;Control Panel</b>.</li> <li>2. Double-click <b>Internet Options</b>.</li> <li>3. On the General tab, select the <b>Delete Cookies</b> button.</li> </ol>
Cannot automatically launch Internet programs.	You must log on to the ISP before some programs will start.	Log on to the ISP and launch the desired program.
Internet takes too long to download web sites.	Modem is not set up properly.	<ol style="list-style-type: none"> <li>1. Select <b>Start&gt;Control Panel</b>.</li> <li>2. Double-click <b>System</b>, and then select the <b>Hardware</b> tab.</li> <li>3. In the Device Manager area, select the <b>Device Manager</b> button.</li> <li>4. Double-click <b>Ports</b> (COM &amp; LPT).</li> <li>5. Right-click the COM port that your modem uses, and then select <b>Properties</b>.</li> <li>6. Under Device status, verify that the modem is working properly.</li> <li>7. Under Device usage, verify that the modem is enabled.</li> <li>8. If there are further problems, select the <b>Troubleshoot</b> button and follow the onscreen instructions.</li> </ol>

## Troubleshooting checklist

Before running diagnostic utilities, use the following checklist to find possible solutions for workstation or software problems.

- Is the workstation and monitor connected to a working electrical outlet?
- Is the workstation powered on?
- Is the green power light illuminated?
- Is the monitor on?
- Is the green monitor light illuminated?
- If the monitor is dim, adjust the monitor brightness and contrast controls.
- Press and hold any key. If the system beeps, the keyboard is operating correctly.
- Check cables for loose or improper connections.
- After installing a non-PnP expansion board or other option (such as a diskette drive), reconfigure the workstation.
- Are all necessary device drivers installed?
- Have all printer drivers been installed for each application?
- Have you removed diskettes and CDs from the drives before you power on the workstation?
- Are you running the latest version of BIOS, drivers, and software?

## LED color definitions

The following table describes what each LED light on your workstation front panel signifies.

**Table 5-17 LED color definitions**

LED state	LED color	System status
Solid	Green	System is on.
Flashing	Green	System is in Standby.
Solid or flashing	Red	System has experienced an error. See <a href="#">Diagnostic LED codes on page 114</a> .
None	No light	System is in Hibernate, or is off.

## HP Insight Diagnostics Offline Edition

The diagnostics utility enables you to perform testing and to view critical computer hardware and software configuration information from various sources. This utility enables you to:

- Run diagnostics
- View the hardware configuration of the system



## Key features and benefits

The HP Insight Diagnostics Offline Edition simplifies the process of identifying, diagnosing, and isolating hardware issues.

The HP Insight Diagnostics Offline Edition offers these functions:

- Testing and diagnosing apparent hardware failures
- Documenting system configurations for upgrade planning, standardization, inventory tracking, disaster recovery, and maintenance
- Sending configuration information to another location for more in-depth analysis

## Theory of operation

Insight Diagnostics Offline Edition operates in offline mode only. The operating system is not running and software information from the system is not available to the utility.

Offline Survey is available to display the current system configuration.

The Insight Diagnostics Test feature provides the capability to test functionality of all major hardware components in the system. The Test feature is designed with flexibility to enable you to customize test selections by specifying different modes and types of testing.

A Quick Test provides a predetermined script where a sample of each hardware component is tested and requires no user intervention.

A Complete Test provides a predetermined script during which each hardware component is fully tested. You can select Interactive or Unattended tests. This changes the devices tested during the Complete Test. More tests are available in the interactive mode, but these require user intervention.

A Custom Test provides the most flexibility in controlling the testing of a system. The Custom Test mode enables you to specifically select which devices, tests, and test parameters are run. You can select tests that do not require user interaction through the Interactive and Unattended tests modes.

## Diagnostic utility on CD

HP Insight Diagnostics is available on the Documentation Library CD included with your workstation.

To start the diagnostic utility on the Documentation Library CD:

1. Enter the Computer Setup (F10) Utility by powering on power on your workstation and pressing **F10** during the initial boot process.
2. Select your language from the list and press **Enter**.  
  
Four headings are displayed in the Computer Setup Utilities menu: **File**, **Storage**, **Security**, and **Advanced**. There might be other headings, depending on your workstation.
3. Use the right arrow key to select **Storage**.
4. Use the down arrow key to select **Boot Order**, and then press **Enter**.
5. Select **CD-ROM Drive**, and then press **F5** to enable it as a bootable device.  
  
If the CD drive is not enabled, pressing **F5** again disables it. The default setting is Enabled.
6. Set the optical drive at the top of the boot order by selecting **CD-ROM**, pressing the **Enter** key, and then using the up arrow to move it to the top of the boot order.
7. To apply and save changes, press **F10**, and then select **File>Save Changes and exit**.

8. Insert the Documentation Library CD into the workstation.
9. Restart your system and HP Insight Diagnostics launches automatically.

## Downloading the latest diagnostic utility

1. Go to <http://www.hp.com>.
2. Select the **Support & Drivers** link.
3. Select the **Download driver and software** radio button.
4. Enter your product number (for example, xw8600) in the text box, and then press **Enter**.
5. Select your operating system.
6. Select the **Diagnostic** link.
7. Locate **HP Insight Diagnostics Offline** and select **Download**.
8. After the .iso file is downloaded, use CD-ROM burning software to copy the .iso file to an optical medium.

## User Interface

### Navigation

The Insight Diagnostics home page contains these tabs: Survey, Test, Status, Log, and Help. These tabs categorize the major functions of Insight Diagnostics.

### Survey tab

When you select the Survey tab, the Survey menu is displayed. It enables you to view important system configuration information.

The Summary view limits the amount of data displayed, while the Advanced view shows the data in the selected category. Regardless of whether you choose **Advanced** or **Summary**, the following categories of information are available on the Survey menu:

- **Overview**—Provides a list of general information about the computer.
- **All**—Provides a list of *all* information about the computer.
- **Architecture**—Displays the workstation bus type and BIOS information. In addition, if the bus is PCI, it also displays information about the PCI configuration.
- **Asset Control**—Displays the serial number of the computer and provides processor information.
- **Communication**—Displays information about the computer parallel (LPT) and serial (COM) port settings, USB, and network controller information.
- **Graphics**—Displays information about the graphics subsystem of the computer.
- **Input Devices**—Displays information about the type of keyboard and mouse.
- **Memory**—Displays information about memory in the computer, including memory on the board and memory modules.
- **Miscellaneous**—Displays information obtained from the computer configuration memory (CMOS), BIOS data area, Interrupt Vector table, and diagnostics component information.

- **Storage**—Displays information about storage media connected to the computer, including fixed disks, diskette drives, and optical drives.
- **System**—Displays product type, processor type and speed, coprocessor information, and information about ROMs in the computer.

## Test tab

The Insight Diagnostics utility provides the capability to test major hardware components in the workstation. You can select from several types of tests:

- **Quick Test**—Provides a script that samples most hardware components and requires no user intervention.
- **Complete Test**—Provides a script during which most hardware components are tested. You can select **Interactive** or **Unattended** tests. This changes the devices tested during the Complete Test. More tests are available in interactive mode, but these require user intervention.
- **Custom Test**—Provides the most flexibility in controlling the testing of a system. This mode enables you to select which devices, tests, and test parameters to run. You can select tests that do not require user interaction through the Interactive and Unattended test modes. More tests are available in interactive mode, but these tests require user intervention.

To begin diagnostics testing:

1. Select the **Test** tab.
2. Select **Type of Test** to perform, select **Test Mode**, and then select **Interactive** or **Unattended**.
3. Choose how you want the test to be executed, either **Number of Loops** or **Total Test Time**.
  - To run the test over a specified number of loops, enter the number of loops to perform.
  - To run the diagnostic test for a specified time, enter the amount of time in minutes.
4. To start the test, select **Begin Testing** in the lower right corner of the display.

While tests are performed, you can monitor the progress by viewing the Status tab. Errors detected are summarized in the Error Log. Select **Save** to save the report to a diskette or a USB key drive (if attached).

If the diagnostics utility detects an error during a test, the user can mouse-over the failed text in the Status tab to display information about the type of error and the error code.

To view all test failure information, select **Error Log**.

To view the status of all testing that has been performed, select the **Log** tab.

## Status tab

The Status tab displays the status of selected tests. The type of test executed (for example, Quick, Complete, or Custom) is displayed. The main progress bar displays the percentage of completion of the current set of tests. While testing is in progress, the Cancel Testing button is displayed. Select this to cancel the test.

After testing is complete, the Cancel Testing button is replaced with the Select New Tests and Retest buttons. Select **New Tests** to go back to the previous test selection page and select a new set of tests. Select **Retest** to retest the last set of tests executed. This enables you to rerun a set of tests without going back to the test selection page.

The Status page also shows:

- Devices being tested
- Tests currently running
- Overall test time
- Individual test times
- Condition status of each test

## Log tab

The Log tab consists of the following views.

**Test Log**—Displays all tests that have been executed, the number of times a test was executed, the number of times a test failed, and the time it took to complete the test.

The Clear Test Log button clears the contents of the Test Log.

**Error Log**—Displays the tests that have failed during diagnostic testing. In addition to displaying the device and test, this section might also include error details. The description section describes the error that the diagnostic test found. The Recommended Repair section gives a recommended action you should perform to resolve the hardware problem. The error count is the number of times the test has failed. The Clear Error Log button clears the contents of the Error Log.


## Help tab

The Help tab provides these views:

- **HP Insight Diagnostics**—Provides introductory and detailed information about Insight Field Diagnostics.
- **Error Codes**—Provides error code listings, including devices tested, messages, and recommended repair information.
- **Test Components**—Reloads and refreshes all components and displays component details after the refresh.

## POST error messages

Power On Self Test (POST) is a program run at startup that initializes and runs tests on installed hardware. An audible and/or visual message appears if the POST encounters a problem. POST checks the following items to ensure that the workstation system is functioning properly:

 **NOTE:** If the power-on password is set, a key icon appears on the screen while POST is running. You must enter the password before continuing.

**Table 5-18 POST error messages**

Screen message	Probable cause	Recommended action
101—Option ROM Error	System ROM checksum.	Verify the correct ROM: <ol style="list-style-type: none"><li>1. Flash the ROM, if needed.</li><li>2. If an expansion card was recently added, remove it to find out if the problem remains.</li></ol>

**Table 5-18 POST error messages (continued)**

Screen message	Probable cause	Recommended action
		<ol style="list-style-type: none"> <li>3. Clear CMOS. If the message disappears, there might be a problem with the expansion card</li> <li>4. Replace the system board.</li> </ol>
102—System Board Failure	DMA, timers, and so forth, might be set improperly or might be defective.	<ol style="list-style-type: none"> <li>1. Clear the CMOS.</li> <li>2. Remove the expansion boards.</li> <li>3. Replace the system board.</li> </ol>
110—Out of Memory for Option ROMs	Option ROM for a device could not run because of memory constraints.	Run the Computer Setup (F10) Utility to disable unneeded option ROMs, and to enable ACP0/USB Buffers at Top of Memory under the Advanced>Power-On options.
163—Time and Date Not Set	<ul style="list-style-type: none"> <li>• Invalid time or date in configuration memory.</li> <li>• RTC battery might need replacement.</li> <li>• CMOS jumper might not be properly installed.</li> </ul>	<ol style="list-style-type: none"> <li>1. Set the date and time from the Control Panel or in the Computer Setup (F10) Utility (depending on the operating system).</li> <li>2. If the problem persists, replace the RTC battery.</li> </ol>
164—Memory Size Error	Memory configuration is incorrect.	<ol style="list-style-type: none"> <li>1. Run the Computer Setup (F10) Utility or the Windows utilities.</li> <li>2. Verify that the memory modules are installed properly.</li> <li>3. If third-party memory has been added, test the memory configuration using HP memory.</li> <li>4. Verify the memory module type.</li> </ol>
201—Memory Error	RAM failure.	<ol style="list-style-type: none"> <li>1. Run the Computer Setup (F10) utility or the Windows utilities.</li> <li>2. Be sure that memory and continuity modules are installed correctly.</li> <li>3. Verify the memory module type.</li> <li>4. Remove and replace memory modules one at a time to isolate faulty modules.</li> <li>5. Replace faulty memory modules.</li> <li>6. If the error persists after replacing memory modules, replace the system board.</li> </ol>
202—Memory Type Mismatch	Memory modules do not match.	Replace the memory modules with matched sets.
203—Memory module failed self-test and failing rank was disabled	Defective memory module.	Replace the memory module.
204—Memory loaded incorrectly	Improper module load.	Reseat the memory module correctly.
205—Memory high temperature detected	Insufficient memory module cooling.	Verify that a memory module cooling fan is installed and operating.
206—Memory setup invalid	Memory configured incorrectly.	Reconfigure the memory modules in the proper slots.

**Table 5-18 POST error messages (continued)**

Screen message	Probable cause	Recommended action
207—Incompatible memory modules detected	Single-bit ECC error.	<ol style="list-style-type: none"> <li>1. Verify the memory module type.</li> <li>2. Insert the DIMM in another memory socket.</li> <li>3. Replace the memory module if the problem persists.</li> </ol>
208—Two-DIMM configurations use slots one and five	DIMMs are loaded in incorrect slots for a two-DIMM configuration.	Verify that the two DIMMs are installed in slots one and five only.
209—Incompatible memory (FBDs) detected	Incorrect memory module type in use.	Verify that the memory modules are compatible with workstation requirements.
210—Mismatched memory (AMBs) detected	Different memory module types are matched.	Verify that compatible memory module types are used in matched pairs.
211—Memory warning condition detected	Improper or defective memory module.	Replace the memory module.
212—Failed Processor	Processor has failed to initialize.	<ol style="list-style-type: none"> <li>1. Reseat the processor in its socket.</li> <li>2. If the processor does not respond, replace it.</li> </ol>
213—Incompatible Memory Modules	A memory module in the memory socket identified in the error message is missing critical SPD information, or is incompatible with the chipset.	<ol style="list-style-type: none"> <li>1. Verify the memory module type.</li> <li>2. Insert the DIMM in another memory socket.</li> <li>3. Replace the module with a DIM conforming to the SPD standard.</li> </ol>
214—DIMM Configuration Warning	DIMMs are not installed correctly (not paired correctly).	See the service label on the workstation access panel for the correct memory configurations, and reseat the DIMMs accordingly.
216—Memory Size Exceeds Maximum Supported	The amount of memory installed exceeds that supported by the hardware.	<ol style="list-style-type: none"> <li>1. Verify how much memory your system supports.</li> <li>2. Remove the excess memory.</li> </ol>
301—Keyboard Error	Keyboard failure.	<ol style="list-style-type: none"> <li>1. Reconnect the keyboard with the workstation powered off.</li> <li>2. Check the connector for bent or missing pins.</li> <li>3. Be sure that none of the keys are pressed.</li> <li>4. Replace the keyboard.</li> </ol>
303—Keyboard Controller Error	I/O board keyboard controller is defective or is not set properly.	<ol style="list-style-type: none"> <li>1. Reconnect the keyboard with the workstation powered off.</li> <li>2. Replace the system board.</li> </ol>
304—Keyboard or System Unit Error	Keyboard failure.	<ol style="list-style-type: none"> <li>1. Reconnect the keyboard with the workstation powered off.</li> <li>2. Be sure that none of the keys are pressed.</li> <li>3. Replace keyboard.</li> <li>4. Replace system board.</li> </ol>
510—Splash Screen image corrupted	Splash Screen image has errors.	Update system BIOS.

**Table 5-18 POST error messages (continued)**

Screen message	Probable cause	Recommended action
511—CPU. CPU A, or CPU B Fan not detected	Fan is not connected or is defective.	<ol style="list-style-type: none"> <li>1. Reseat the fan cable.</li> <li>2. Reseat the fan.</li> <li>3. Replace the fan.</li> </ol>
512—Chassis, rear chassis, or front chassis fan not detected	Fan is not connected or it might be defective.	<ol style="list-style-type: none"> <li>1. Reseat the chassis, rear chassis, or front chassis fan cable.</li> <li>2. Reseat the chassis, rear chassis, or front chassis fan.</li> <li>3. Replace the chassis, rear chassis, or front chassis fan.</li> </ol>
513—Memory fan not detected	Missing or disconnected memory fan.	<ol style="list-style-type: none"> <li>1. Ensure the memory fan is installed.</li> <li>2. Ensure proper memory fan connections.</li> </ol>
514—CPU or Chassis Fan not detected	CPU or chassis fan is missing, is not connected, or is defective.	<ol style="list-style-type: none"> <li>1. Verify that the processor or chassis fan is installed and connected properly.</li> <li>2. Replace the processor fan or the chassis fan.</li> </ol>
515—CPU Overtemp occurred	Insufficient processor cooling or processor defect.	<ol style="list-style-type: none"> <li>1. If necessary, add a heatsink to the processor and ensure proper operation.</li> <li>2. Replace the processor.</li> </ol>
516—PCI fan not detected	Missing PCI fan or disconnected fan cable.	<ul style="list-style-type: none"> <li>• Add a PCI fan if necessary.</li> <li>• Verify proper PCI fan cable connection and operation.</li> </ul>
517—Low power CPU heatsink(s) detected for high power CPUs	Inadequate heatsink is installed.	Replace the low power heatsink with a high power heatsink.
518—Power supply wattage insufficient for hardware configuration	Workstation configuration requires more power than the power supply can provide.	<ul style="list-style-type: none"> <li>• Reduce the workstation power consumption.</li> <li>• Replace the power supply with a high output power supply.</li> </ul>
601—Diskette Controller Error	Diskette controller circuitry or diskette drive circuitry incorrect.	<ol style="list-style-type: none"> <li>1. Run the Computer Setup (F10) utility.</li> <li>2. Verify cabling and replace defective cables if necessary.</li> <li>3. Clear CMOS.</li> <li>4. Replace the diskette drive.</li> <li>5. Replace the system board.</li> </ol>
605—Diskette Drive Type Error	Mismatch in drive type.	<ol style="list-style-type: none"> <li>1. Run the Computer Setup (F10) Utility.</li> <li>2. Disconnect any other diskette controller devices (tape drives).</li> <li>3. Clear the CMOS.</li> </ol>
610—External Storage Device Failure	External storage device is not detected, is improperly connected, or is defective.	<ol style="list-style-type: none"> <li>1. Verify that the external device is present and connected properly.</li> <li>2. Replace the external device.</li> </ol>

**Table 5-18 POST error messages (continued)**

Screen message	Probable cause	Recommended action
912—Computer Cover Has Been Removed Since Last System Start Up	N/A	No action required.
914— Hood Lock Coil is not Connected	Mechanism is missing or is not connected.	<ol style="list-style-type: none"> <li>1. Reconnect or replace the missing mechanism.</li> <li>2. Reseat or replace the missing mechanism cable.</li> </ol>
917—Front Audio Not Connected	Mechanism is missing or is not connected.	<ol style="list-style-type: none"> <li>1. Reconnect or replace the missing mechanism.</li> <li>2. Reseat or replace the missing mechanism cable.</li> </ol>
918—Front USB Not Connected	Mechanism is missing or is not connected.	<ol style="list-style-type: none"> <li>1. Reconnect or replace the missing mechanism.</li> <li>2. Reseat or replace the missing mechanism cable.</li> </ol>
919—Multi-Bay Riser Not Connected	Mechanism is missing or is not connected.	<ol style="list-style-type: none"> <li>1. Reconnect or replace the missing mechanism.</li> <li>2. Reseat or replace the missing mechanism cable.</li> </ol>
921—Device in PCI Express Slot failed to initialize	Missing, improperly seated, or defective card.	<ol style="list-style-type: none"> <li>1. Verify that the card is installed.</li> <li>2. Reseat the card.</li> <li>3. Replace the card.</li> </ol>
922—Fatal error in slot #	Fatal error occurred in the designated slot.	Move the card to a different slot. If the problem persists, replace the card.
923—Non fatal uncorrectable PCI error in slot #	A PCI or PCIe nonfatal error occurred for the card in the designated slot.	Move the card to a different slot. If the problem persists, replace the card.
924—Non fatal correctable PCI error	A PCI or PCIe nonfatal error occurred for the card in the designated slot.	Contact HP support.
925—Non fatal uncorrectable ESI error	Nonfatal, uncorrectable ESI error on slot # occurred.	Contact HP support.
926—Non fatal correctable ESI error	Nonfatal, correctable ESI error on slot # occurred.	Contact HP support.
927—Non fatal FSB error	Nonfatal FSB error on FSB # occurred.	Contact HP support.
928—Non fatal uncorrectable FBD error	Nonfatal, uncorrectable FBD error on DIMM # occurred.	Contact HP support.
929—Non fatal correctable FBD error	Nonfatal, correctable FBD error on (DIMM is identified).	Contact HP support.
930—Non fatal internal Northbridge error	Nonfatal, Internal Northbridge error.	Contact HP support.
1720—SMART Hard Drive Detect Imminent Failure	Hard drive is about to fail. (Some hard drives have a firmware patch that fixes erroneous error messages.)	<ol style="list-style-type: none"> <li>1. Determine if the hard drive is giving a correct error message.</li> <li>2. Run the Drive Protection System test (if applicable).</li> <li>3. Apply firmware patch (if applicable). See <a href="http://www.hp.com/support">http://www.hp.com/support</a>.</li> <li>4. Back up contents and replace the hard drive.</li> </ol>
1783—Fixed Disk 0/1 locked	Hard disk drive failure.	Diagnose the hard drive, and replace it if necessary.



**Table 5-18 POST error messages (continued)**

Screen message	Probable cause	Recommended action
1794—Inaccessible devices attached to SATA 1 and/or SATA 3	Missing or improperly attached cable.	Verify that a cable is attached. Reattach the cable.
1796—SATA Cabling Error	Missing or improperly attached cable.	Verify that a cable is attached. Reattach the cable.
1801—Microcode Patch Error	Processor not supported by ROM BIOS.	Upgrade BIOS to proper version.
1802—Processor Not Supported	The system board does not support the processor.	Replace the processor with a compatible one.
ERROR: An unsupported processor is installed. System halted	Unsupported processor detected.	Replace the processor.
ERROR: A processor requiring too much power is installed. System halted	Unsupported processor detected.	Replace the processor.
ERROR: Mixing processors with different power requirements. This is not supported. System halted.	Mixed type processors detected.	Replace the processors with matched processors.
Invalid electronic serial number	Incorrect serial number registered in the system.	Use the Computer Setup (F10) Utility to reset the serial number.
Mixing processors with different power requirements. This is not supported. System halted.	Mixed type processors detected.	Replace the processors with matched processors.
Mixing Two Different Processor Types MP and DP!!!	Mixed type processors detected.	Replace the processors with matched processors.
Network Server Mode Active and No Keyboard Attached	Keyboard not detected.	Verify that a functioning keyboard is attached to the workstation.
Processor initialization fails!!!	Processor defective.	Replace the processor.
The installed CPUs have different voltage requirements. This is not supported. System halted.	Mixed type processors detected.	Replace processors with matched processors.
Two processors do not have the same frequency operating ranges!!!	Mixed type processors detected.	Replace processors with matched processors.



---

## 6 Configuring RAID devices

This chapter describes how to configure SAS and SATA RAID devices:


- [Configuring SAS RAID devices on page 145](#)
- [Configuring SATA RAID devices on page 147](#)

For additional information about configuring RAIDs, see [http://www.hp.com/support/RAID\\_FAQs](http://www.hp.com/support/RAID_FAQs). For information about preparing your workstation for RAID configuration, see [http://www.hp.com/support/workstation\\_manuals](http://www.hp.com/support/workstation_manuals).

### Configuring SAS RAID devices

#### Supported configurations

The following RAID configurations are supported on HP xw8600 Workstations:

 **NOTE:** This section does not apply to configuring SAS RAID in the Linux environment. For Linux SAS RAID information, including supported configurations, refer to *Installing and Configuring SAS Hardware RAID on HP Linux Workstations* at [http://www.hp.com/support/xw8600\\_manuals](http://www.hp.com/support/xw8600_manuals).

- Up to five internal SAS hard disk drives
- SAS-to-SATA data and power converter
- LSI MegaRAID Storage Manager (MSM) for Windows

The following RAID configurations are supported on HP xw8600 Workstations:

- RAID 0 – Striped disk array
  - Two drive minimum
  - Improved I/O performance
  - No fault tolerance
- RAID 1 — Mirrored disk array
  - Two drives
  - 100% redundancy
  - Can recover from single drive failure
  - Improved read performance
- RAID 1E
  - Two drives minimum
  - Can be an odd number of drives
  - Can always recover from a single drive failure and, in some cases, can recover from two drive failures

## SAS RAID 0 configuration

Use the following procedure to configure an Integrated Striped (IS) volume with the BIOS-based configuration utility. The procedure assumes that the system has the required disks and disk controllers.

1. On the Main menu of the BIOS-based configuration utility, use the arrow keys to select an adapter.
2. Press **Enter** to go to the Adapter Properties screen.
3. On the Adapter Properties screen, use the arrow keys to select **RAID Properties**, and press **Enter** to go to the RAID Properties screen.
4. In the RAID Properties screen, use the arrow keys to select the first disk for the IS volume. Then use the arrow keys to move to the Array Disk column for this disk, and press Space and **+** or **-** to select **Yes** as the value for this column.

If partitions are defined on the selected disk, a message appears warning you that data on the disk will be lost when the striped volume is created.

5. Press **M** to migrate, or **D** to delete the data on the drive.
6. To select up to three more disks for the striped volume, repeat the previous steps.
7. After you choose all drives, press **C** to create the array once, and then press **Esc** and select **Save**.

## SAS RAID 1 configuration

Use the following procedure to configure an Integrated Mirroring (IM) volume with the BIOS-based configuration utility. The procedure assumes that the system has the required disks and disk controllers.

1. On the Main menu of the BIOS-based configuration utility, use the arrow keys to select an adapter.
2. Press **Enter** to go to the Adapter Properties screen.
3. On the Adapter Properties screen, use the arrow keys to select **RAID Properties**, and then press **Enter** to go to the RAID Properties screen.
4. Configure a two-disk mirrored volume with an optional hot spare disk:

- a. In the RAID Properties screen, use the arrow keys to select the primary disk for the IM volume (the disk with the data you want to mirror.)
- b. Use the arrow keys to move to the Array Disk column for this disk and press Space to select **Yes** as the value.

If partitions are defined on the selected disk, a message appears warning you that data on the disk will be lost when the striped volume is created.

- c. Press **M** to migrate or **D** to delete the data on the drive.
- d. When the Keep Data/Erase Disk message appears, press **F3** to keep the data on this disk.  
The value in the Array Disk column changes to Primary.
- e. Use the arrow keys to select the secondary (mirrored) disk for the IM volume, and then select **Yes** as the value for the Array Disk column.

If partitions are defined on this disk, a message warns that data on the disk will be lost when the mirrored volume is created.

- f. Press **Delete** to confirm erasing data from the disk, or press any other key to deselect the disk.

## SAS RAID 1E configuration

Use the following procedure to configure an Integrated Mirroring Extended (IME) volume with the BIOS-based configuration utility. The procedure assumes that the system has the required disk and disk controllers.

1. On the Main menu of the BIOS-based configuration utility, use the arrow keys to select an adapter.
2. Press **Enter** to go to the Adapter Properties screen.
3. On the Adapter Properties screen, use the arrow keys to select **RAID Properties**, and then press **Enter** to go to the RAID Properties screen.
4. To configure a mirrored volume with three to six disks, or three to five disks with an optional hot spare disk, do the following:
  - a. In the RAID Properties screen, use the arrow keys to select the first disk for the IME volume.
  - b. Use the arrow keys to move to the Array Disk column for this disk, and then use the **+** or **-** keys to select **Yes** as the value.
  - c. When the **Keep Data/Erase Disk** message appears, press **Delete** to erase the disk.
  - d. Use the arrow keys to select the next disk for the IME volume, and then select **Yes** as the value for the Array Disk column.

If partitions are defined on this disk, a message warns you that data on the disk will be lost when the mirrored volume is created. Press **Delete** to confirm erasing data from the disk, or press any other key to deselect the disk.
  - e. Repeat the previous steps to select up to four more disks for the IME volume.

If you want to configure a hot spare disk for the volume, you can only select up to three more disks.
5. (Optional) Use the arrow keys to select a hot spare disk for the IME volume, and then select **Yes** as the value for the Hot Spare column.
6. After you select all disks for the IME volume, press **Esc** and select **Save changes, then exit this menu**.

The IME volume exists when you save the changes. The RAID Properties screen displays the IME volume properties and status.
7. If you do not want to create the IME volume, select **Discard changes, then exit this menu**.

## Configuring SATA RAID devices

This section describes how to use the Intel Matrix Storage Manager option ROM Configuration utility to set up and manage SATA RAID volumes.

The following SATA RAID configurations are supported on HP xw8600 Workstations:

- Up to five internal SATA hard disk drives
- Up to two eSATA drives if you use an optional eSATA cable
- Intel Matrix Storage Manager (MSM) for Windows

If only a single HDD is attached, the Intel Matrix Storage Manager option ROM does not execute. Associated messages are not displayed.

The Intel SATA AHCI BIOS executes when you select **RAID/AHCI** for the SATA emulation mode. This BIOS is only used to support serial-attached optical drives.

This section does not apply to configuring SATA RAID in the Linux environment. For Linux SATA RAID, refer to the Software RAID in Linux Workstations section in the *HP Workstations for Linux User Guide* at [http://www.hp.com/support/linux\\_user\\_manual](http://www.hp.com/support/linux_user_manual).

## Attaching SATA HDDs

Attach the required minimum number of SATA hard drives for the desired RAID level:

- RAID 0: two hard drives
- RAID 1: two hard drives
- RAID 5: three hard drives
- RAID 10: four hard drives

## Configuring system BIOS

Configure the system BIOS to enable embedded SATA RAID functionality.

1. To enter the system BIOS setup, press **F10**.
2. Use the arrow keys to highlight the desired language, and then press **Enter**.
3. Use the arrows to highlight **Storage>Storage Options**, and then press **Enter**.
4. Use the up or down arrow key to highlight **SATA Emulation**.
5. Use the left or right arrow key to select **RAID/AHCI**.
6. To accept the new setting, press **F10**.
7. Use the arrows to highlight **Advanced>Power-On Options**, and then press **Enter**.
8. Use the up or down arrow key to highlight **POST Messages**.
9. Use the left or right arrow key to select **Enable**.
10. To accept the new setting, press **F10**.
11. Use the arrow keys to highlight **Advanced>Device Options**, and then press **Enter**.
12. Use the up or down arrow key to highlight **SATA RAID Option ROM Download**, and then press **Enter**.
13. Use the left or right arrow key to select **Enable**.
14. To accept the new setting, press **F10**.
15. Use the arrows to highlight **File>Save Changes and Exit**, and then press **Enter**.
16. Press **F10** when prompted.

## Creating RAID volumes

To create RAID volumes, use the Intel Matrix Storage Manager option ROM Configuration utility.

1. To enter the Intel Matrix Storage Manager option ROM Configuration utility, press **Ctrl+I** when prompted
2. If required, see [Deleting RAID volumes on page 149](#) to make enough physical drives available to create the RAID volume.
3. Use the up or down arrow key to highlight **1. Create RAID Volume**, and then press **Enter**.
4. Type the desired RAID volume name in the "Name:" field, and then press **Tab**.
5. Use the up or down arrow key to select the RAID level in the RAID Level: field, and then press **Tab**.
6. To display the Select Disks dialog, press **Enter**.
7. Use the up and down arrow keys and Space to mark individual physical disks as members of the volume.
8. To exit the Select Disks dialog and return to the Create Volume Menu dialog, press **Enter**.
9. If appropriate, use the up or down arrow key to select the Strip Size in the Strip Size: field, and then press **Tab**.
10. Enter the desired volume size in the Capacity: field, and then press **Tab**.
11. Press **Enter** to initiate volume creation.
12. When prompted, press **Y** to acknowledge the warning message and create the volume.
13. Return to step 3 to create additional RAID volumes, or use the up or down arrow key to highlight **4. Exit**, and then press **Enter**.
14. Press **Y** when prompted to confirm the exit.

## Deleting RAID volumes

Use the Intel Matrix Storage Manager option ROM Configuration utility to delete RAID volumes.

1. Use the up or down arrow key to highlight **2. Delete RAID Volume**, and then press **Enter**.
2. Use the up or down arrow key to highlight the RAID volume to be deleted, and then press **Delete**.
3. When prompted, press **Y** to confirm the deletion of the selected RAID volume.
4. Choose one of the following actions:
  - Return to Step 1 to delete additional RAID volumes.
  - To create RAID volumes, see [Creating RAID volumes on page 149](#).
  - Use the up or down arrow key to highlight **4. Exit**, and then press **Enter**.
  - Use the up or down arrow key to highlight **3. Reset Disks to Non-RAID**, and then press **Enter**.
5. Use the up and down arrow keys and Space to mark individual physical disks to be reset.
6. Press **Enter** to complete the selection.

7. When prompted, press **Y** to confirm the reset action.
8. Choose one of the following actions:
  - To delete additional RAID volumes, return to Step 1.
  - To create RAID volumes, see [Creating RAID volumes on page 149](#).
  - Use the up or down arrow key to highlight **4. Exit**, and then press **Enter**.



---

## 7 Configuring password security and resetting CMOS

This chapter describes how to configure password security and to reset CMOS, and includes these topics:

- [Preparing to configure passwords on page 151](#)
- [Resetting the password jumper on page 152](#)
- [Clearing and Resetting the CMOS on page 152](#)

### Preparing to configure passwords

The Computer Setup (F10) Utility enables you to create setup and power-on passwords.

There are three possibilities for setting passwords:

- Define a setup password only
- Define a power-on password only
- Define both

When defining a setup password only, you cannot enter the setup utility without the password.

No password is needed to boot from power-on.


When defining a power-on password only, the power-on password is needed to enter F10 Setup or to boot from power-on.


When defining both, the setup password is needed to enter F10 setup and can be used to boot from power-on.

The power-on password cannot be used to enter the F10 Setup Utility, but it can be used to boot from power-on.

One of the passwords will be required to boot from power on.

After you create both passwords, you can use the setup password in place of the power-on password as an override to log into the workstation (a useful feature for a network administrator).

 **NOTE:** You can only clear the passwords with the password jumper. Clearing CMOS does not clear the passwords.

 **CAUTION:** Before pressing the Clear CMOS button, back up your workstation CMOS settings.


Pressing the Clear CMOS button resets CMOS values to factory defaults and erases customized information, including passwords, asset numbers, and special settings.

To back up the CMOS settings, run the Computer Setup (F10) Utility and select **Save to Diskette** from the File menu.

---

## Resetting the password jumper

Use the following procedure to disable the power-on or setup password features and clear the power-on and setup passwords.

- ⚠ **WARNING!** To reduce the risk of personal injury from electrical shock and hot surfaces, be sure to disconnect the power cord from the wall outlet and allow the internal system components to cool before touching.
  - ⚠ **CAUTION:** When the workstation is plugged in, the power supply has voltage applied to the system board, even when the workstation is turned off. Failure to disconnect the power cord can result in damage to the system.
  - ⚠ **CAUTION:** Static electricity can damage the electronic components of the workstation or optional equipment. Before beginning these procedures, be sure that you are discharged of static electricity by briefly touching a grounded metal object.
1. Shut down the operating system, power off the workstation and external devices, and disconnect the workstation power cord and external devices from power outlets.
  2. Disconnect the keyboard, monitor, and other external devices that are connected to the workstation.
  3. Remove the access panel.
  4. Locate the password header and jumper.  
The password header is E49.
  5. Verify that the AC power cord is disconnected from the power outlet.  
The password jumper is green so it can be easily identified.
  6. Remove the jumper from pins 1 and 2, then replace it.
-  **NOTE:** You have to reboot to at least the point where you get video before you can shut down again and replace the jumper to clear the passwords.
7. Replace the access panel.
  8. Reconnect the external equipment.
  9. Connect AC power to the workstation, power on the workstation, and then boot to the F10 (Setup) Utility.
  10. To create new passwords, repeat steps 1 through 8, and then create the new passwords using the F10 (Setup) Utility.

## Clearing and Resetting the CMOS

This section describes the steps necessary to successfully clear and reset the CMOS. The CMOS of the workstation stores password information and information about the workstation configuration.

### Using the CMOS Button

To clear CMOS using the Clear CMOS button, use the following procedure:

- ⚠ **WARNING!** To reduce the risk of personal injury from electrical shock and hot surfaces, disconnect the power cord from the wall outlet and allow the internal system components to cool before touching.

- △ **CAUTION:** When the workstation is plugged in, the power supply has voltage applied to the system board, even when the workstation is powered off. Failure to disconnect the power cord can result in damage to the system.

Static electricity can damage the electronic components of the workstation or optional equipment. Before beginning these procedures, be sure that you are discharged of static electricity by briefly touching a grounded metal object.


1. Shut down the operating system, power off the workstation and any external devices, and then disconnect the workstation power cord and external devices from power outlets.
2. Disconnect the keyboard, monitor, and other external devices that are connected to the workstation.
3. Remove the access panel.

- △ **CAUTION:** Before pressing the Clear CMOS button, back up your workstation CMOS settings.

Pressing the Clear CMOS button resets CMOS values to factory defaults and erases customized information, including passwords, asset numbers, and special settings.

To back up the CMOS settings, run the Computer Setup (F10) Utility and select **Save to Diskette** from the File menu.

4. Locate, press, and hold the CMOS button for five seconds.

-  **NOTE:** Verify that the AC power cord is disconnected from the power outlet.

The CMOS button does not clear CMOS if the power cord is connected.

For assistance locating the CMOS button and other system board components, see [System board components on page 52](#).

5. Replace the access panel.
  6. Reconnect external devices.
  7. Plug in and power on the workstation.
  8. Reset the workstation passwords and configuration information, such as the system date and time.
- The workstation powers up for three to five seconds, then powers down.


## Using the Computer Setup (F10) Utility to Reset CMOS

1. Access the Computer Setup (F10) Utility menu.
2. When the Computer Setup message appears in the lower-right corner of the screen, press **F10**, and then press **Enter** to bypass the title screen, if necessary.

If you do not press **F10** while the message is displayed, the workstation must be rebooted to access this utility.
3. From the Computer Setup (F10) Utility menu, select **File>Default Setup**.

This restores the settings that include boot sequence order and other factory settings. However, it does not force hardware rediscovery.
4. Choose **Restore Factory Settings as Default**, and then press **F10** to accept.
5. Select **File->Apply Defaults and Exit**, and then press **F10** to accept.
6. Reset the workstation passwords and configuration information, such as the system date and time.

---



 **NOTE:** This step does not clear the passwords.



---



# A Appendix A—Connector pins


## Connector pin descriptions


Not all of these connectors might be installed in your workstation.


Rear panel PS2 keyboard connector	Pin	Signal
 	1	Data
	2	Unused
	3	Ground
	4	+5 VDC
	5	Clock
	6	Unused


Rear panel PS2 mouse connector	Pin	Signal
 	1	Data
	2	Unused
	3	Ground
	4	+5 VDC
	5	Clock
	6	Unused

Rear panel RJ45 Ethernet connector	Pin	10/100-Mb Signal	1000-Mb signal		
 	1	(+) Transmit Data	TX/RX	0	+
	2	(-) Transmit Data	TX/RX	0	-
	3	(+) Receive Data	TX/RX	1	+
	4	Unused	TX/RX	2	+
	5	Unused	TX/RX	2	-
	6	(-) Receive Data	TX/RX	1	-
	7	Unused	TX/RX	3	+
	8	Unused	TX/RX	3	-


Rear panel RS-232 serial connector	Pin	Signal
	1	Carrier Detect
	2	Receive Data
	3	Transmit Data
	4	Data Terminal Ready
	5	Signal Ground
	6	Data Set Ready
	7	Request to Send
	8	Clear to Send
	9	Ring Indicator


Front/rear panel (internal Type A) USB connector	Pin	Signal
	1	+5 VDC
	2	- Data
	3	+ Data
	4	Ground


Front/rear IEEE 1394a connector	Pin	Signal
	1	Power
	2	GND
	3	TPB-
	4	TPB+
	5	TPA-
	6	TPA+


Internal IEEE 1394b connector	Pin	Signal
	1	TPB-
	2	TPB+
	3	TPA-
	4	TPA+
	5	TPA (R)
	6	VG
	7	SC
	8	VP


	9	TPB (R)
--	---	---------

Front/rear panel microphone cable connector (1/8 inch)	Pin	Signal
	1 (Tip)	Audio Left/Power
	2 (Ring)	Audio Right/Power
	3 (Shield)	Ground


Front panel headphone cable connector (1/8 inch)	Pin	Signal
	1 (Tip)	Audio Left
	2 (Ring)	Audio Right
	3 (Shield)	Ground

Rear panel line-in audio cable connector (1/8 inch)	Pin	Signal
	1 (Tip)	Audio In Left
	2 (Ring)	Audio In Right
	3 (Shield)	Ground

Rear panel line-out audio cable connector (1/8 inch)	Pin	Signal
	1 (Tip)	Audio Out Left
	2 (Ring)	Audio Out Right
	3 (Shield)	Ground

SATA drive connector					
					
Data Cable		Power Cable		Power Cable	
Pin	Signal	Pin	Signal	Pin	Signal
S1	Ground	P1	3.3V power	P8	5V power
S2*	A+	P2	3.3V power	P9	5V power
S3*	A-	P3	3.3V power	P10	Ground
S4	Ground	P4	Ground	P11	Reserved


### SATA drive connector



Data Cable		Power Cable		Power Cable	
Pin	Signal	Pin	Signal	Pin	Signal
S5**	B-	P5	Ground	P12	Ground
S6**	B+	P6	Ground	P13	12V power
S7	Ground	P7	5V power	P14	12V power
				P15	12V power

\* S2 and S3 differential signal pair  
 \*\*S5 and S6 differential signal pair


### SAS drive connector



Segment	Pin	Backplane receptacle	Plug and cable receptacles
Primary signal segment	S1	SIGNAL GND	SIGNAL GND
	S2	TP+	RP+
	S3	TP-	RP-
	S4	SIGNAL GND	SIGNAL GND
	S5	RP-	TP-
	S6	RP+	TP+
	S7	SIGNAL GND	SIGNAL GND
Secondary signal segment	S8	SIGNAL GND	SIGNAL GND
	S9	TS+	RS+
	S10	TS-	RS-
	S11	SIGNAL GND	SIGNAL GND
	S12	RS-	TS-
	S13	RS+	TS+
	S14	SIGNAL GND	SIGNAL GND
Power segment	P1	V <sub>33</sub> <sup>c</sup>	
	P2	V <sub>33</sub> <sup>c</sup>	
	P3	V <sub>33</sub> <sup>c</sup> precharge <sup>c</sup>	
	P4	GROUND	





### SAS drive connector




Segment	Pin	Backplane receptacle	Plug and cable receptacles
	P5	GROUND	
	P6	GROUND	
	P7	V <sub>5</sub> <sup>c</sup> precharge <sup>c</sup>	
	P8	V <sub>5</sub> <sup>c</sup>	
	P9	V <sub>5</sub> <sup>c</sup>	
	P10	GROUND	
	P11	READY LED <sup>d</sup>	
	P12	GROUND	
	P13	V <sub>12</sub> precharge <sup>c</sup>	
	P14	V <sub>12</sub> <sup>c</sup>	
	P15	V <sub>12</sub> <sup>c</sup>	

### VGA connector




Pin	Signal	Pin	Signal	Pin	Signal
1	Red Analog	6	GND	11	Monitor ID
2	Green Analog	7	GND	12	DDC Serial Data
3	Blue Analog	8	GND	13	Horizontal Sync
4	Monitor ID	9	+5 VDC	14	Vertical Sync
5	GND	10	GND	15	DDC Serial Clock

### DVI-I cable connector




Pin	Signal	Pin	Signal
1	T.M.D.S DATA 2-	16	HOT PLUG DETECT

DVI-I cable connector			
2	T.M.D.S DATA 2+	17	T.M.D.S DATA 0-
3	T.M.D.S DATA 2/4 SHIELD	18	T.M.D.S DATA 0+
4	T.M.D.S DATA 4-	19	T.M.D.S DATA 0/5 SHIELD
5	T.M.D.S DATA 4+ 2	20	T.M.D.S DATA 5-
6	DDC CLOCK	21	T.M.D.S DATA 5+
7	DDC DATA	22	T.M.D.S CLOCK SHIELD
8	ANALOG VERT. SYNC	23	T.M.D.S CLOCK+
9	T.M.D.S DATA 1-	24	T.M.D.S CLOCK-
10	T.M.D.S DATA 1+	C1	ANALOG RED
11	T.M.D.S DATA 1/3 SHIELD	C2	ANALOG GREEN
12	T.M.D.S DATA 3-	C3	ANALOG BLUE
13	T.M.D.S DATA 3+	C4	ANALOG HORZ SYNC
14	+5V POWER	C5	ANALOG GROUND
15	GND		

P1 Main power 24-pin system board connector							
							
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	+3.3V	7	GND	13	+3.3V	19	GND
2	+3.3V	8	POK	14	-12V	20	PS_ID*
3	GND	9	+5 VSB	15	GND	21	+5V
4	No load	10	+12 V-B	16	PS_ON_L	22	+5V
5	GND	11	+12 V-B	17	GND	23	No load
6	+5V	12	No load	18	No load	24	GND

\* GND on 1050W power supply; unused on 800W power supply.


#### P18 Memory riser power 10-pin cable connector\*



Pin	Color	Signal	Pin	Color	Signal
1	Black	GND	6	Black with yellow stripe	V 12-D
2	Black	GND	7	Black with yellow stripe	V 12-R
3	Black with purple stripe	5 VSB	8	Black with purple stripe	V 5SB
4	Black	GND	9	Black with yellow stripe	V 12-R
5	Black	GND	10	Black with yellow stripe	V 12-R


\* Used with 1050-watt power supply only.

#### P3 CPU power 8-pin system board connector





Pin	Signal
1	GND
2	GND
3	GND
4	GND
5	V12-CPU0
6	V12-CPU0
7	V12-CPU1
8	V12-CPU1


#### P2 Memory power 6-pin system board connector




Pin	Signal
1	V12-D
2	GND
3	GND
4	V12-M
5	GND
6	V12-M


PCI Express auxiliary power 6-pin cable connector	Pin	Color	800W P16 P17	1050W P16	1050W P17
	1	Yellow	12 V-G	12 V-G1	12 V-G2
	2	Yellow	12 V-G	12 V-G1	12 V-G2
	3	Yellow	12 V-G	12 V-G1	12 V-G2
	4	Black	GND	GND	GND
	5	Black	GND	GND	GND
	6	Black	GND	GND	GND
<p>Verify that you can differentiate between the power cable that connects to the PCI Express x16 card, and the power cable that connects to the system board.</p> <p>These two cables have different pin counts and different colors. The PCI Express power cable has a 6-pin black connector, and the system board power cable has a 4-pin white connector.</p> <p>When power is present, <i>never</i> connect the PCI Express power cable to the system board or the system board can be damaged.</p> <p>For proper PCI card installation information, see <a href="#">PCI Express cards on page 92</a>.</p>					

CPU fan system board connector	Pin	Signal
	1	GND
	2	+12V
	3	Tach 1
	4	PWM
	5	Tach 2

PCI, memory, and rear chassis fan power system board connector	Pin	Signal
	1	Ground
	2	+12V
	3	Tach
	4	PWM


AUX IN system board connector	Pin	Signal
	1	AUX LEFT
	2	AGND
	3	AGND


AUX IN system board connector	Pin	Signal
	4	AUX RIGHT

Front USB system board 2x5 connector	Pin	Signal
	1	+5V
	2	+5V
	3	USB6-
	4	USB7-
	5	USB6+
	6	USB7+
	7	GND
	8	GND
	9	Key (no pin)
	10	Connector Present Detect

**CAUTION:** The 2x5 system board connector can be mated to a wide 2x5 option cable connector or a narrow 1x5 option cable connector.


To prevent damage to connectors, connect a narrow 1x5 option cable connector to pins 1,3,5, and 7 only of the 2x5 system board connector. (Pin 9 is not keyed on the system board connector.)

P25 Internal USB, CPU heatsink power system board 1x5 connector	Pin	Signal
	1	+5V
	2	USB3-
	3	USB3+
	4	GND
	5	Key (no pin)

FDD system board connector	Pin	Signal	Pin	Signal
	1	Ground	18	FLP_DIR#
	2	FLP_LOWDEN#	19	Ground
	3	Key (no pin)	20	FLP_STEP#
	4	FLP_WDO	21	Ground
	5	Key (no pin)	22	FLP_WDATA#
	6	Unused	23	Ground
	7	Ground	24	FLP_WRTEN#


FDD system board connector	Pin	Signal	Pin	Signal
	8	FLP_INDEX#	25	Ground
	9	Ground	26	FLP_TRACK#
	10	FLP_MOTOR#	27	Ground
	11	Ground	28	FLP_WP#
	12	Unused	29	Ground
	13	Ground	30	FLP_RD_D#
	14	FLP_SEL_A#	31	Ground
	15	Ground	32	FLP_HD_SEL#
	16	Unused	33	Ground
	17	Ground	34	FLP_DSKCHG#

MiniSAS 4i cable connector




Pin 1	Pin 2	Pin 3	Pin 4	Signal
A2	A2	A2	A2	Rx 0+
A3	A3	A3	A3	Rx 0–
N/C*	A5	A5	A5	Rx 1+
N/C	A6	A6	A6	Rx 1–
A8	A8	A8	A8	Sideband 7
A9	A9	A9	A9	Sideband 3
A10	A10	A10	A10	Sideband 4
A11	A11	A11	A11	Sideband 5
N/C	N/C	A13	A13	Rx 2+
N/C	N/C	A14	A14	Rx 2–
N/C	N/C	N/C	A16	Rx 3+
N/C	N/C	N/C	A17	Rx 3–
B2	B2	B2	B2	Tx 0+
B3	B3	B3	B3	Tx 0–
N/C	B5	B5	B5	Tx 1+
N/C	B6	B6	B6	Tx 1–

MiniSAS 4i cable connector				
B8	B8	B8	B8	Sideband 0
B9	B9	B9	B9	Sideband 1
B10	B10	B10	B10	Sideband 2
B11	B11	B11	B11	Sideband 6
N/C	N/C	B13	B13	Tx 2+
N/C	N/C	B14	B14	Tx 2-
N/C	N/C	N/C	B16	Tx 3+
N/C	N/C	N/C	B17	Tx 3-
A1, A4, A7, A12, A15, A18, B1, B4, B7, B12, B15, B18				SIG GND
* N/C = not connected				

MiniSAS 4x cable connector				
				
Pin 1	Pin 2	Pin 3	Pin 4	Signal
S1	S1	S1	S1	Rx 0+
S2	S2	S2	S2	Rx 0-
N/C	S3	S3	S3	Rx 1+
N/C	S4	S4	S4	Rx 1-
N/C	N/C	S5	S5	Rx 2+
N/C	N/C	S6	S6	Rx 2-
N/C	N/C	N/C	S7	Rx 3+
N/C	N/C	N/C	S8	Rx 3-
N/C	N/C	N/C	S9	Tx 3-
N/C	N/C	N/C	S10	Tx 3+
N/C	N/C	S11	S11	Tx 2-
N/C	N/C	S12	S12	Tx 2+
N/C	S13	S13	S13	Tx 1-
N/C	S14	S14	S14	Tx 1+
S15	S15	S15	S15	Tx 0-

MiniSAS 4x cable connector				
S16	S16	S16	S16	Tx 0+
G1 - G9				SIG GND
Housing				CHASSIS GND
* N/C = not connected				

eSATA cable connector				
				
Name	Type	Description	Cable Usage	Backplane Usage
S1	GND		1st mate	2nd mate
S2	A+	Differential signal pair A	2nd mate	3rd mate
S3	A-		2nd mate	3rd mate
S4	GND		1st mate	2nd mate
S5	B-	Differential signal pair B	2nd mate	3rd mate
S6	B+		2nd mate	3rd mate
S7	GND		1st mate	2nd mate



## B Appendix B—System board designators

This appendix lists the system board designators for this system.

Designator	Silk screen	Component
MTG1-MTG10	N/A	Mounting holes
E15	E15	Crisis recovery header/jumper
E49	E49	Clear password header/jumper
J20	J20 SLOT1 PCI	PCI-32 33-MHz slot
J21	J21 SLOT7 PCI-X 133	PCI-X 133-MHz slot
J31	J31 SLOT3 PCIe x8(4)	PCIe Express slot
J32	J32 SLOT4 PCIe2 x16(16,8) 75W + 75W	PCIe2 Express slot
J33	J33SLOT5 PCIe x8(1), PCIe2 x8	PCIe Express slot
J34	J34 SLOT6 PCIe x8(4)	PCIe Express slot
J41	J41 SLOT2 PCIe2 x16 75W + 75W	PCIe2 Express slot
J68	J68	Stacked keyboard/mouse connector
J9	J9	Stacked RJ-45 / dual USB
J10	J10	Single rear USB
J11	J11	Stacked RJ-45 / dual USB
J12	J12 1394	Single rear 1394
J13	J13 FRONT 1394	Front 1394 header
J83	J83	Triple stacked audio jacks
J85	J85	Slot2 PCIe x16 retention clip
J86	J86	Slot4 PCIe x16 retention clip
SW50	SW50 CMOS	Clear CMOS switch/push button
P1	P1	Power supply connector (24-pin)
P2	P2	Memory power connector (6-pin)
P3	P3	Processor power connector (8-pin)
P5	P5	Power button / HDD LED / Power LED / Hood switch / Temperature header
P8	P8 PCI FAN	PCI fan header
P10	P10 FDD	Diskette drive connector

Designator	Silk screen	Component
P11	P11 AUX IN	Auxiliary audio connector
P12	P12	MCH fan header
P20	P20 IDE	IDE connector
P23	P23 FRONT AUDIO	Front panel audio header
P24	P24	Front panel USB header
P25	P25	Internal USB header
P29	P29	HDD LED connector
P53	P53	Serial port connector
P60-P63	SATA0 - SATA3	SATA Connectors
P66-P67	SATA4 - SATA5	SATA Connectors
P70	P70	Primary processor fan header
P71	P71 CPU1 FAN	Second processor fan header
P80-P87	SAS0 - SAS7	SAS/SATA connectors
P124	P124	Hood lock header
P130	P130 PCI FAN	System fan header
P131	P131	Memory fan header
XBT2	XBT2 BAT	Battery socket
XMM1 – XMM8	XMM1 – XMM8	Memory slots
	DIMM1 – DIMM8	
U1	U1	Primary processor socket
U2	U2	Second processor socket

---

# C Appendix C—Routine care

## General cleaning safety precautions

- Never use solvents or flammable solutions to clean the workstation.
- Never immerse any component in water or cleaning solutions; apply any liquids to a clean cloth and then use the cloth on the component.
- Always unplug the workstation before cleaning the keyboard, mouse, or air vents.
- Always disconnect the keyboard before cleaning it.
- Wear safety glasses equipped with side shields when cleaning the keyboard.

## Cleaning the workstation case

- Follow the service consideration ([Service considerations on page 48](#)) presented before cleaning the workstation.
- To remove light stains or dirt, use plain water with a clean, lint-free cloth or swab.
- For stronger stains, use a mild dish washing liquid diluted with water. Rinse well by wiping it with a cloth or swab dampened with clear water.
- For stubborn stains, use isopropyl (rubbing) alcohol. No rinsing is required because the alcohol evaporates quickly and does not leave a residue.
- After cleaning, always wipe the workstation with a clean, lint-free cloth.
- Occasionally, clean the air vents on the workstation. Lint and other foreign matter can block the vents and limit the airflow.

## Cleaning the keyboard

△ **CAUTION:** Use safety glasses equipped with side shields before attempting to clean debris from under the keys.

- Follow the safety precautions presented in [Service considerations on page 48](#) before cleaning the keyboard.
- Visible debris underneath or between the keys can be removed by vacuuming or shaking.
- Canned, pressurized air can be used to clean debris from under the keys. Use caution because too much air pressure can dislodge lubricants applied under the wide keys.
- If you remove a key, use a specially designed key remover to prevent damage to the keys. This tool is available from many electronic supply outlets.

△ **CAUTION:** Never remove a wide key (like the space bar key) from the keyboard. If these keys are improperly removed or installed, the keyboard might not function properly.

- Clean under a key with a swab moistened with isopropyl alcohol and squeezed out. Be careful not to wipe away lubricants necessary for proper key functions. Allow the parts to air dry before reassembly.
- Use tweezers to remove any fibers or dirt in confined areas.

## Cleaning the monitor

- Follow the safety precautions presented in [Service considerations on page 48](#) before cleaning the monitor.
- To clean the monitor, wipe the monitor screen with a towelette designed for cleaning monitors or a clean cloth moistened with water.

△ **CAUTION:** Do not use sprays or aerosols directly on the screen—the liquid might seep into the housing and damage a component.

Never use solvents or flammable liquids on the monitor because display or housing damage may result.

---

## Cleaning the mouse

1. Follow the safety precautions presented in [Service considerations on page 48](#) before cleaning the mouse.
2. Remove the mouse ball from the housing by removing the retaining plate.
3. Clean the mouse ball.
4. Pull out any debris from the ball socket, and wipe the ball with a clean, dry cloth.
5. Reassemble the mouse.