
Figure 1-13 Remove the cassette tray



Step 2: Remove the cassette tray separation roller assembly


- 1. Turn the printer front side up, so that it is resting on the rear door or duplexer. Remove the separation roller cover (callout 1).
- TIP: Use a small, flat-blade screwdriver to release the cover.

Figure 1-14 Remove the separation roller cover



Release one tab (callout 1), and then remove the separation roller (callout 2). 2.

Figure 1-15 Remove the separation roller




- Reverse the removal steps to install the assembly. Also use the following special installation instructions.
- NOTE: Continue to reverse the removal steps to finish installing the assembly.

Special installation instructions: Cassette tray separation roller

When installing the separation roller (callout 1), position the D-shaped locator on the end of the roller into the D-shaped opening on the guide (callout 2).

Figure 1-16 Install the separation roller



Step 3: Unpack the replacement assembly

- Dispose of the defective part.
- NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

- **IMPORTANT:** Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.
- To install an assembly, reverse the removal steps.
- NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.