

Lync_Provision.pdf - Adobe Reader

Attachments

Name	Description	Modi
lyncPerPhoneExample.cfg		18/11
lyncPerPhoneLCExample...		18/11
lyncSharedExample.cfg		24/11

The following illustration shows all of the parameters in the **lyncPerPhoneExample.cfg** template configuration file attached to this guide. Use this file if you want to enter Lync login credentials in the configuration file. Polycom recommends using this file only if you are using a secure provisioning system using HTTPS file transport, preferably in addition to encrypted configuration files. These parameters must be set for each phone in your deployment.

XML Notepad - C:\Documents and Settings\Desktop\Lync\LyncPerPhoneExamp

File Edit View Insert Window Help

C:\Documents and Settings\Desktop\Lync\LyncPerPhoneLCExample.dg

Tree View XSL Output

- lyncPerPhoneLC
 - reg.1.address user1@example.com
 - reg.1.auth.userId user1
 - reg.1.auth.password
 - reg.1.auth.domain example.com
 - reg.svr.1.callBackMode contact
 - reg.svr.1.callBack sip:user1@example.com:opaque@appvoiceemail
 - roaming_buddies
 - roaming_buddies.reg 1

See Table 4: Per-Phone Settings for values and a description of each of the per-phone Lync parameters when entering login credentials to the configuration file.

Table 4: Per-Phone Settings for Secure Provisioning Systems

Parameter	Assigned Value
reg.1.address	Lync sign-in address
Enter a Lync sign-in address.	
reg.1.auth.userId	Lync user ID

11:17 30/12/2011